

SERVICE BULLETIN

CUMULATIVE SERVICE BULLETIN INDEX COVERING BULLETINS ISSUED FROM DECEMBER, 1940 TO JANUARY, 1949 NUMBERS 124 TO 215 INCLUSIVE

This Service Bulletin Index lists articles which appeared in Service Bulletins Nos. 124 through 215 covering both passenger cars and trucks. It should be filed in a binder containing those issues of the Service Bulletin. Service Bulletins Nos. 116 through 123 should be filed with Index Bulletin No. 134 in another binder.

The index is entirely alphabetical by article title or subject, liberally cross-referenced so that an article concerning bleeding of hydraulic brake systems, for example, can be found by reference to one of several places in the alphabetical arrangement: "brakes" "Hydraulic" or "bleeding"

Immediately following the reference title the Service Bulletin number and page in which the article appears is given; also the vehicle models to which the article applies. Model references are always given inclusively so that "4G-8G" indicates that the article applies to the 4G (1942) 5G (1946). 6G (1947). 7G (1948) and 8G (1949) Champions. In the reference to models, the word "all" means the article refers to all of the models listed in the following paragraph.

Individual model numbers refer to the following vehicles:

Champions		Commanders		Presidents	
4G	1942	12A	1942	8C	1942
5G	1946	None	1946	-	
6G	1947	14A	1947	-	
7G	1948	15A	1948	-	
8G	1949	16A	1949	-	

In such cases where an article refers to models of earlier production than those listed above, the earlier model designation is also given.

In each future year, that year's accumulation of Service Bulletin material will be added to the Index and the oldest year's material dropped, thus giving an index always covering the last five production models at the time of publication

REFERENCE	Bul No.	PAGE NO.	MODEL
A			
ACCELERATING PUMP, CARBURETOR.	160	4	ALL
ACCURATE DIAGNOSIS AIDED BY motophone.	195	4	ALL
acid COOLING SYSTEM.	208	3	
ADAPTER AND SOCKETS FOR ALLEN TYPE SCREW REMOVAL . . .	189	2	6G, 14A
ADJUSTING FIXTURE CONE ASSEMBLY. BRAKE SHOE.	134	8	2G-5G; 9 A 2A: 4C-8C
ADJUSTMENT. BRAKE COMPLETE (MAJOR)	162	6	-2G-5G; 9A- 2A: 4C-8C
BRAKE. NORMAL (MINOR).	162	5	2G-5G; 9A- 2A: 4C-8C
PARKING BRAKE.	162	21	2G-5G; 9A- 2A: 4C-8C
SERVICE BRAKE.	195	1	6G, 14A
STEERING WHEEL	186	3	14A
WHEEL.	191	2	M SERIES
ADJUSTMENTS, STRIPPED ENGINE SHOULD RECEIVE SERVICE.	197	4	ALL
ADJUSTMENTS TO DRIVERS' HEIGHT	193	9	14A, 14AY,
ADVANTAGES AND OPERATION OF OVERDRIVE.	193	2	ALL
AIR CLEANER. CARBURETOR.	159	8	ALL
CARBURETOR.	160	5	ALL
HIGH OIL LEVEL.	150	4	ALL
MAINTENANCE	212	1	ALL
WET (OIL BATH). SERVICE INSTRUCTIONS.	169	2	ALL
AIR LEAK AT KICK PAD, LEFT	139	3	4G, 12A, 8 C
AIR LEAKS, WATER, AND DUST CONVERTIBLES.	201	3	6G, 14A
ALCOHOL BASE ANTIFREEZES	199	1	ALL
Aligning EQUIPMENT. BEAN'S VISUALiner.	206	8	
ALLEN TESTING EQUIPMENT (VARIOUS).	203	8	
ALLEN TYPE SCREW REMOVAL, ADAPTER AND SOCKETS FOR. . .	189	2	6G, 14A
ANTENNA, SERVICE	214	4	ALL
ANTIFREEZE AND INHIBITORS. REINSTALLATION OF	152	8	ALL
AND RUST INHIBITORS	159	4	ALL
CONSERVATION OF	149	14	ALL
HARMFUL SOLUTIONS	149	10	ALL
HARMFUL SOLUTIONS	150	8	ALL
IN FACTORY-SHIPED VEHICLES	213	1	7G,8G; 15 A 16A
KEROSENE. FUEL OIL. CALCIUM CHLORIDE TYPE!	147	19	ALL
SAVING.	154	6	ALL
TEST OF	149	10	ALL
WARNING TAG W1075	183	2	6G, ,14A, M SERIES
ANTIFREEZES: OF FOUR MAJOR TYPES. TWO ARE SAFE TO USE.	199	1	ALL
APPEARANCE, CAR CONSERVATION	147	24	ALL
ARMATURE LATHE, JOHNSON.	203	8	
ARO LUBRICATION EQUIPMENT.	191	3	ALL
ASH TRAYS, LOOSE	187	3	14AY
ASSEMBLY EXCHANGES, REAR AXLE. TRANSMISSION.	133	2	ALL
Authorized PHILCO DISTRIBUTORS AND SERVICE STATIONS, NEW LIST MAILED.	214	2	ALL
AUTOMATIC COOLING SYSTEM CLEANER (Brady)	206	7	
AXLE ASSEMBLY. FRONT, NEW KITS	197	6	M15A
AXLE. REAR. Pinion SHAFT BEARING OIL SEAL DRIVER J2037	175	2	6G, 14A, M5
RATIO CHANGE	203	6	M15A
SHAFT INNER BEARING GREASE SEAL.	136	3	4G, 11A, 8C, M5
SHAFT OUTER SEAL LOCATOR J2027	175	2	6G
SHAFT OUTER SEAL LOCATOR J2032	175	3	14A, M5
SINGLE SPEED, PROPELLER SHAFT VIBRATION.	201	2	M15A, M16
SPACER, REAR SPRING TO	170	3	M15, M16
TWO-SPEED SELECTOR VALVE	204	5	M SERIES
TWO-SPEED, TAG W969.	183	2	M SERIES
TWO-SPEED, VACUUM SHIFT.	171	3	M16
WIDE TREAD	203	6	M16
AXLE, Timken. SERVICE PROCEDURES	206	6	2R16, 2R17
AXLE VENT. LUBRICANT LEAK AT TWO-SPEED	200	2	M SERIES
B			
BALSAM GREEN METALLIC PAINT FORMULA.	197	3	
BATTERY. CHARGER AND ANALYZER. HARTMAN	189	4	ALL
CHARGING: "quick CHARGE" SERVICE	147	21	ALL
CONSERVATION OF	150	10	ALL
GUARANTEE POLICY. WILLARD	201	1	

REFERENCE	BUL NO.	PAGE NO.	MODEL
B-CON'TD.			
BATTERY * CONT'D,			
PAINT	153	12	ALL
PREVENTIVE MAINTENANCE CHECKS	171	1	ALL
SERVICE	147	2,2	ALL
TIPS FOR COLD WEATHER OPERATION	201	3	
WILLARD REGISTRATION CARD DESCRIBED	183	3	6G, 14A
WINTER SERVICE CONDITIONING	159	5	ALL
BEAN VISUALINER.	206	8	
BEARING, PROPELLER SHAFT SUPPORT	195	4	M15-28. M15A,28. M16
BEARING WRENCH, REAR WHEEL. ORDERING	197	6	M15A-M16
BEARINGS CLEARANCE CHECKS. CONNECTING ROD AND MAIN.	187	2	6G, 14A
CRANKSHAFT AND. KIT EXCHANGE WITHDRAWN	171	2	3G,4G; 7A- 12A: 4C-8C
CRANKSHAFT MAIN.	172	1	2G-5G; 12A, M5,M15,M16
ENGINE: USE OF TOO MUCH OIL HARMFUL TO.	132	2	ALL
INSERTS. CONNECTING ROD AND.	178	2	M SERIES
INSERTS IN SERVICE ENGINES	179	2	3G-6G; 3A- 14A
,PLASTIGAGE OFFERS QUICK ACCURATE MEASURE- MENT OF TOLERANCES	199	5	
REMOVER. CLUTCH PILOT, J 164.	170	5	ALL BRONZE BEARING
BELL CRANK, THROTTLE CONTROL	215	3	M2R5, 2R10, 2R15
INTERFERENCE WITH CYLINDER HEAD CAPSCREW	215	3	2R16, 2R17
BEWARE PETROLEUM BASE HYDRAULIC FLUIDS	186	2	ALL
BINDING FRONT SHOCK ABSORBER ARM MAY CAUSE STIFF FRONT SPRING ACTION.	203	3	6G, 7G; 14A,15A
BLEEDING ENTIRE HYDRAULIC SYSTEM	162	20	ALL
BLEEDING HYDRAULIC SYSTEM AT ONE WHEEL	162	18	ALL
BODY, FRONT DOOR REMOTE CONTROL ADJUSTING LINK. RATTLE	189	2	6G, 14A
FRONT SEAT UPHOLSTERY TEARING AT BOTTOM OF PANEL	189	2	6G 14A
LOCATION OF DRAINS	172	3	6G. 14A
LUGGAGE COMPARTMENT BOLT CAP	177	3	,6G, 14A
PROPER MOUNTING OF FRONT LICENSE PLATE BRACKET	186	1	6G
SERVICE INFORMATION, VARIOUS LEAKS	181	1-4	6G, 14A
SERVICING HOOD LOCK RELEASE.	191	2	6G, 14A
UNDERCOATING, KNOCKS-SOUND	206	7	
BORG LOCK WARRANTY. SERVICE	207	6	ALL
BORG STATION LIST.	207	6	ALL
BOULEVARD GRAY ENAMEL.	199	3	7G, 15A
BRADY AUTOMATIC COOLING SYSTEM CLEANER	206	7	
BRAKE BOOSTER. HYDROVAC.	199	5	M16
BRAKES, ADJUSTMENT, COMPLETE (MAJOR)	162	6	2G-5G: 9A-12A: 4C-8C
ADJUSTMENT, COMPLETE (MAJOR) (CORRECTION TO SB 162. P.8, STEP No. 12B).	167	2	2G-5G; 9A-12A; 4C-8C
ADJUSTMENT (MINOR)	162	5	AL
ADJUSTMENT NORMAL (MINOR) (CORRECTION TO SB 162. P.5, STEP NO. 1)	167	2	ALL
BEWARE PETROLEUM BASE HYDRAULIC FLUIDS	186	2	ALL
BLEEDING HYDRAULIC SYSTEM.	162	18 & 20	ALL
CABLE. PARKING	133	2	11A, 7C
CYLINDER, REPAIR KITS.	142	2	ALL
FLUID. USE OF GENUINE LOCKHEED	134	3	ALL
GENERAL.	147	23	AL
HILL HOLDER INSTALLATION	180	1	M SERIES
HYDRAULIC SYSTEM CHECKS.	162	17	ALL
LININGS SAME. FRONT AND REAR	179	3	ALL
MASTER CYLINDER HOLE COVER WATER LEAK.	206	3	6G,7G; 14A,15A
MASTER CYLINDER PIPE CLIP.	208	6	2R SERIES
PARKING. ADJUSTMENT.	162	21	2G-5G; 9A-12A: 4C-8C
PARKING. COVER FASTENER, LEAK AT	198	1	6G. 14A
PARKING, RATCHET SPRING REPLACEMENT.	197	3	6G. 14A
PEDAL COVER WATER LEAK	206	3	6G, 7G; 14A,15A
PEDAL FREE TRAVEL.	203	2	6G, 7G; 14A,15A
PEDAL LENGTHENED	193	3	M16 BOOSTER EQUIPPED
PEDAL RETURN, POSITIVE	188	1	6G, 14A
PEDAL SPLASH SHIELD.	188	2	6G, 14A, 14AY
PETROLEUM BASE FLUID HARMFUL	163	5	ALL
REAR. BACKING PLATE INSTALLATION	177	1	M15, M15A, M16
RELINING OPERATION	162	9	ALL

REFERENCE	BUL NO.	PAGE NO.	MODEL
B-Cont'd.			
BRAKES - CONT'D			
SERVICE ADJUSTMENT	195	1	6G, 14A
SERVICE OF. IN RELATION TO SAFE STOPPING	140	10	ALL
SERVICING MASTER CYLINDER (CORRECTION TO SB 162. P. 16 STEPS NO. 6-9 INCL.)	167	3	ALL
SHOE CONE ASSEMBLY. ADJUSTING FIXTURE.	134	8	2G-5G; 9A-12A: 4C-8C
SQUEAK.	178	1	6G, 14A
STOPPING DISTANCE AT VARIOUS SPEEDS.	140	10	ALL
TEE TO AXLE HOUSING (REAR). CAPSCREW VENTED.	212	4	2R10
VACUUM POWER AND CLUTCH CONTROLS. SERVICE ADJUSTMENTS FOR.	190	1-7	3G-6G
BREATHER TUBE FILTER PACK.	130	3	2G, 3G, 4G
BREATHER TUBE TO INLET MANIFOLD PIPE	147	19	ALL
BREATHER TUBE TO MANIFOLD PIPE EQUIPMENT	138	6	ALL
BULLETINS. SERVICE, HOW TO USE	205		
BUMPERS. CARE OF	147	24	ALL
C			
C579. TRANSMISSION. REAR OIL SEAL INSTALLING DRIFT	170	5	ALL
CAB. BACK PANEL REINFORCEMENT.	209	3	2R SERIES
CABLE. HIGH TENSION. IT'S EASY TO FORGET.	156	2	ALL
CABLE. HORN BUTTON	138	3	4G, 12A, 8C
CAMBER ADJUSTMENT.	204	5	6G, 7G; 14A, 15A
AND TOE-IN.	147	12	ALL
CANOPY TOP SHRINKAGE COMPLAINTS.	191	2	M5, M15A
CARBON PASTE. USE OF	156	6	ALL
CARBURETOR ACCELERATING PUMP	160	4	ALL
AIR CLEANER	159	8	ALL
AIR CLEANER	160	5	ALL
AIR CLEANER. WET (OIL BATH) SERVICE INSTRUCTIONS.	169	2	ALL
EQUIPMENT. INSTALLATION OF.	124	5	2G 3G
EXCHANGE.	128	5	ALL
FLOAT LEVEL GAGE.	206	6	2R SERIES
GENERAL	159	9	ALL
HIGH ALTITUDE METERING RODS	176	2	6G
PARTS, CYLINDER HEAD, FOR HIGH ALTITUDE OPERATION	188	2	8A-14A
REPAIR KITS J505-SCT	170	5	ALL
TOOL KITS. NEW FLOAT LEVEL GAGE. 3/8 INCH, AVAILABLE FOR	200	2	
ZENITH.	203	5	M5, M15A
CAR CONSERVATION, APPEARANCE	147	24	ALL
CASTER ADJUSTMENT NOT RECOMMENDED.	176	2	ALL
CAUTION PLATE CHANGE	176	1	M5, M15A, M16
CHAMPION SERIES 500 SPARK PLUG TESTER. CLEANER	206	8	
CHASSIS LUBRICANTS	147	20	ALL
LUBRICATION RECOMMENDATIONS.	147	17	ALL
SPRING LUBRICATION	204	2	
STANDS SAVE TIME WITH TWO-POST LIFTS	191	4	ALL
CHECK INSTALLATION FIRST ON CANOPY TOP SHRINKAGE COMPLAINTS	191	2	M5, M15A
CHECKING CYLINDER DISTORTION	208	1	
CHECKING THE HYDRAULIC SYSTEM.	162	17	ALL
CHEROKEE RED ENAMEL.	209	2	2R SERIES
CHOKE AUTOMATIC	159	9	ALL
AUTOMATIC (ON CARTER EQUIPPED CARS	160	5	2G, 3G, 4G
AUTOMATIC, SLOUGGISH ACTION OF	154	3	ALL
VALVE SPRING KIT.	135	5	7C
CHROME PLATED PARTS, PAINTING.	150	10	ALL
CHROME PLATING PROTECTION.	172	5	ALL
CHROME YELLOW ENAMEL	209	2	ALL
CIGAR LIGHTER FAILURES	144	2	ALL
CIRCUIT BREAKER FOR CONVERTIBLE TOPS	207	3	6G, 7G; 14A, 14A,
CLAIMS. CREDIT, DAMAGED REAR AXLE ASSEMBLIES DO NOT MERIT FULL CLAIMS CREDIT	197	6	
GLASS.	175	1	ALL

REFERENCE	BUL. NO.	PAGE NO.	MODEL
C-CONT'D			
CLAIMS - CONT'D			
IDENTIFYING SHOCK ABSORBERS FOR EXCHANGE . . .	178	4	ALL
PROPER PACKING SUGGESTIONS	176	3	ALL
RADIATOR CORE, SHOW SERIAL NUMBER.	179	1	6G, 14A
VAPOR LOCK, RETURN REPLACED PARTS.	176	1	6G
CLAYBORNE STANDS. SOLD BY KMO,	193	10	ALL
CLEANER COOLING SYSTEM.	163	3	ALL
CLEANING THE HYDRAULIC SYSTEM.	162	17	ALL
CLEANLINESS AND ORDERLINESS.	163	2	
CLIMATIZER CONTROLS.	138	7	4G, 2A, 8C,
CONTROL VALVE	188	2	6G, 4A
DEFROSTER AIR DISTRIBUTION.	177	2	6G, 4A
DEFROSTER BLOWER MOTORS	163	6	ALL
DEFROSTER CHECK FOR PROPER AIR DISTRIBUTION	179	4	6G, 4A
FILTER REMOVED IN PRODUCTION.	182	1	6G, 4A
HEATER.	159	4	ALL
HEAT FLOW INTERFERENCE.	203	4	7G, 15A
HEAT FROM IN HOT WEATHER.	159	9	ALL
HOW TO GET BEST RESULTS	179	3	6G, 14A
INCREASE HEAT FLOW.	179	3	6G, 14A
NEW TYPE VALVE CONTROL CABLE. SOUND- DEADENING	182	2	6G
PROPER USE OF CONTROLS.	179	3	6G, 14A
SERVICING	147	19	ALL
TIRE STRIKES DUCT	173	3	6G
VALVE CONTROL CABLE REDUCES NOISE TRANSMITTAL	186	3	6G
CLINCHING TOOL, REAR WHEEL BEARING LOCK NUT. J2827 .	213	2	
CLOCK BORGWARRANTY AND SERVICE	207	6	ALL
SERVICE. BORGSTATIONS.	207	6	ALL
CLOVER GREEN ENAMEL.	209	2	2R SERIE
CLUTCH CONTROLS AND VACUUM POWER BRAKE. SERVICE ADJUSTMENTS FOR	190	1-7	3G, 6G
DRIVEN MEMBER. NOISE.	152	5	4G, 12A, 8C
FREEDING RELEASE SHAFT	187	4	6G, 14A
HEAVY DUTY LINKAGE.	178	2	M5, M15, M15A
HOUSING INSPECTION DOOR WATER LEAK.	205	2	6G,7G; 14A. 15A
HOUSING VENTILATION	187	3	14A
OIL LEAK AT HOUSING	182	3	5G
OPERATING SHAFT RATTLE.	179	1	6G
PEDAL PULLBACK SPRING REMOVER	193	4	6G, 14A, 14AS
PILOT BEARING REMOVER, J164	170	5	ALL BRONZE BEARING
PRESSURE PLATE SPRING SPECIFICATION	203	5	ALL
RELEASE FINGER. ADJUSTMENT OF	152	3	3G, 4G
RELEASE SHAFT GREASE RETAINER	215	2	7G,15A; 2R SERIES
COIL IGNITION.	160	8	ALL
COLD WEATHER, BATTERY TIPS FOR OPERATION	201	3	
COLOR. PAINT FORMULAS.	177	3	6G, 14A
COLOR, PAINT FORMULAS.	197	3	6G,7G; 14A. 15A
COLOR, PAINT FORMULAS.	203	4	M SERIES
COLOR, PAINT FORMULAS.	203	2	7G, 15A
COLOR, PAINT FORMULAS.	209	2	2R SERIES
COMMANDER ENGINE TURNING PLUG.	203	4	7A-15A INCL.
STRIPPED ENGINES. ORDER DATA	204	2	
TIRE PRESSURES	176	1	14A
COMPANION FLANGE HOLDING TOOL J2035	175	2	6G,, 14A, M SERIES
PULLER J2046.	175	2	6G, 14A, M SERIES
COMPRESSION,	160	8	4L
COMPLIMENTARY CAR INSPECTION, SEQUENCE OF PROCEDURE IN PERFORMING.	138	2	ALL
CONDENSATION DEVICE FOR DRAWING OFF	152	3	4L
CONNECTING ROD AND BEARING INSERTS	178	2	M SERIES
AND MAIN BEARING CLEARANCE CHECKS	187	2	6G, 14A
BEARING INSERTS. .001" UNDERSIZE	186	3	6G, 14A
CRANKPIN TOOL WILLIS,	140	10	ALL
CONTROL LINKS. DO NOT REMOVE FRONT SPRING.	158	8	3G,4G; 11A,12A; 7C, 8C
CONVERSION LIST FOR TRANSMISSION	138	4	4G, 12A; 8C

REFERENCE	BUL, NO	PAGE NO	MODEL
C-CONT'D			
CONVERTIBLE DOOR OPENING WEATHERSTRIP.	207	6	7G, 15A
TOP HEADER. WATER LEAKS.	207	5	7G, 15A
TOPS. NEW CIRCUIT BREAKER.	207	3	6G,7G; 14A, 15A
COOLING SYSTEM	147	18	ALL
CLEANER	163	3	ALL
COOLING SYSTEM. CORRECTING ACID CONDITION	208	3	
FAN DRIVE PULLEY. SMALLER	178	1	M5, M15, M15A
RADIATOR CORE SERIAL NUMBER LOCATION.	179	1	6G, 14A
REVERSE FLUSHING.	147	18	ALL
RUST. INHIBITOR TAG	172	2	ALL
SAVE OLD WATER PUMP GREASE CUPS	191	1	ALL
WARNING ANTI-FREEZE IN NEW CAR. W1075	183	2	6G, 14A, M SERIES
WARNING WATER ONLY. W1031	183	2	6G, 14A, M SERIES
CORK GASKETS, SALVAGING.	150	9	ALL
COWL. OPENING INTO FRONT SEAT COMPARTMENT. .	198	4	6G, 14A
SIDE PANEL WATER LEAK.	206	2	6G,7G; 14A, 15A
CRACKS. HOW TO DETECT.	153	12	ALL
CRANKCASE. CLEANING OF	155	6	ALL
SLUDGE.	145	5	ALL
SLUDGE ITS CAUSE. PREVENTION. AND CURE.	197	1	ALL
CRANKSHAFT AND BEARING KIT WITHDRAWN	171	2	2G,3G,4G; 7A-12A: 4C-8
AND CAM GEAR PUSHER SET. ADDITIONAL TO. .	137	7	4G
MAIN BEARINGS	172	11	2G-5G: 12A: M5,M15,M16
CRISS-CROSS TIRES TO EQUALIZE WEAR	195	2	ALL
CUBAN TAN ENAMEL	209	2	2R SERIES
CUMBERLAND BLUE PAINT FORMULA.	197	3	
CUMBERLAND BLUE ND.2 METALLIC BAKING ENAMEL. .	203	3	7G, 15A
CYLINDER BLOCK. 14A USED IN 15A CHASSIS.	203	2	15A
LOCATION OF DOWEL PILOT HOLES.	197	4	6G,7G; 14A, 15A
CYLINDER DISTORTION.	208	1	
CYLINDER HEAD AND CARBURETOR PARTS FOR HIGH ALTITUDE OPERATION.	188	2	8A- 14A
CAP SCREW TIGHTENING PROCEDURE	187	1	ALL
FOR HIGH ALTITUDE.	176	2	6G
KEEP GASKETS TIGHT	172	1	ALL
GASKETS, LEAKAGE	160	9	ALL
CYLINDER HEADS AND GASKET PILOTS	195	2	14A, M16
CYLINDER WATER MANIFOLDS DETERIORATED.	164	8	4C-8C
D			
DAMAGED REAR AXLE ASSEMBLIES DO NOT MERIT FULL CLAIMS CREDIT.	197	6	M15A, M16
DASH TIE ROD TO RADIATOR CORE SUPPORT.	193	4	M16
DEALER'S SERVICE POLICY DESCRIBED.	183	3	6G, 14A, M SERIES
REVISION	193	1	ALL PASS.
DEFROSTER AIR DISTRIBUTION	177	2	6G, 14A
BLOWER MOTORS.	163	6	ALL
CHECKS FOR AIR DISTRIBUTION.	179	4	6G, 14A
DETERGENT ENGINE OILS.	215	1	
DEVILBISS PAINT SHOPS.	204	6	
DIAGNOSIS BRAKES.	157	2	ALL
OVERDRIVE CHART	171	6	4G,5G; 11A,12A; 7C,8C (EXCEPT GOVERNOR CON. TROLLED)
OVERDRIVE CHART	212	4	6G,7G; 14A, 15A
RADIO, ELEMENTARY CHECKS.	167	3	ALL
DIFFERENTIAL CARRIER. SIDE CARRIER BEARING REPLACER J201-22	170	5	ALL
PINION BEARING PULLER.	137	7	ALL
DIFFERENTIAL AND TRANSMISSION LUBRICANTS	208	5	
DISTRIBUTOR. IGNITION.	160	7	ALL
DOLPHIN EYEBROW SEALER, SYMBOLS.	181	2	6G, 14A
DO NOT DRIVE OVER 25 MPH. W1073	183	2	M SERIES
DO NOT START ENGINE. WARNING W1189	183	2	6G, 14A, M SERIES
DOOR CENTER PILLAR POST SEAL.	198	3	6G, 14A
CENTER SECTION LEAKS	198	3	6G, 14A

REFERENCE	BUL. NO.	PAGE NO	MODEL
D-Cont' d.			
DOOR CONT'D.			
FRONT, GLASS RATTLES	173	1	6g
FRONT, REMOTE CONTROL ADJUSTING LINK, RATTLE	189	2	6G, 14A
HANDLE DRAIN	182	3	6G
LEAKS, WATER AND DUST, AT TOP AND BOTTOM	198	2	6G
LEFT FRONT, LOCK INSTALLATION.	171	4	3G, 4G, 5G; 11A, 12A; 7C LHC . 8C
LOCK REMOTE CONTROL MECHANISM.	180	2	6G, 14A
LOCKS, FREEING FROZEN.	148	6	ALL
SAFETY LOCK, REMOVAL AND REPLACEMENT	139	4	ALL
SEAL AT TOP AND BOTTOM	198	2	6G, 14A
STRAIGHTENER J1685	136	8	ALL
TRIM PANEL SEAL.	181	2	6G, 14A
DOOR DRAIN, DUST LEAK AT	198	1	6G, 14A
DOOR OPENING REAR WEATHERSEALS (CONVERTIBLE)	208	1	7G, 15A
WEATHERSTRIP WATER LEAK	206	2	6G, 7G; 14A, 15A
WEATHERSTRIP AT OPENING (CONVERTIBLE)	207	6	7G, 15A
DOOR WINDOW AND VENTILATORS, WATER LEAKS IN.	204	4	14AY, 15AY
BIND (CONVERTIBLE).	207	4	7G, 15A
BIND IN LOWER RUN	206	5	6G, 7G; 14A, 15A
DOUBLE VISION DIAGNOSING CLAIMS.	199	3	ALL
DRAINS, BODY. LOCATION OF.	172	3	6G, 14A
DOOR HANDLE.	182	3	6G
DRIP MOULDING, SEALING	181	2	6G, 14A
DRIVEN MEMBER, NOISE IN.	152	5	3G, 12A, 8C
RIVER'S COMPARTMENT WATER LEAKS	206	2	6G, 7G; 14A, 15A
RIVER'S HEIGHT, ADJUSTMENTS FOR	193	9	14A, 14AY
RIVING SPEEDS, EFFECT ON TIRE LIFE.	143	11	ALL
DRIVING SUGGESTIONS AND OPERATING PRECAUTIONS.	160	9	ALL
DROWSINESS WHILE DRIVING, USE OF AMMONIA FOR	132	2	ALL
DUST LEAK AT DOOR DRAIN.	198	1	6G, 14A
DUST LEAKS, AND WATER, TOP AND BOTTOM OF DOORS	198	2	6G
DUST PLATE	213	1	2R SERIES
DUST, WATER, AND AIR LEAKS	198		6G, 14A
DUST, WATER, AND AIR LEAKS * CONVERTIBLES.	201	3	6G, 14A
E			
ELECTRICAL, BATTERY, PREVENTIVE MAINTENANCE CHECKS	171	1	ALL
GENERAL SERVICE.	161	6	ALL
HARTMAN RAPID BATTERY CHARGER-ANALYZER	189	4	ALL
HORN BUTTON LOOSE.	178	1	6G, 14A
UNITS.	147	21	ALL
ELECTRICAL CIRCUIT BREAKER FOR CONVERTIBLE TOPS.	207	3	6G, 7G; 14A, 15A
ELECTRIC CLOCK (BORG) WARRANTY, SERVICE STATION LIST	207	6	
ELECTRIC DRILLS.	135	7	ALL
ELECTRIC IMPACT TOOL	208	6	
ELECTRIC SHOCK	177	2	6G, 14A REGALS
ENAMEL FINISH, BAKED	139	2	ALL
WAXING.	124	4	ALL
ENGINE, ASSEMBLY INSTALLATION, SERVICE ADJUSTMENT.	166	5	ALL
BEARING INSERTS USED	179	2	3G, 6G; 3A-14A
CONNECTING RODS AND BEARING INSERTS.	178	2	M SERIES
CRANKSHAFT AND BEARING KIT WITHDRAWN	171	2	2G-4G; 7A-12A; 4C-8C
CRANKSHAFT MAIN BEARING.	172	1	26-56; 12A; M5, M15, M16
CYLINDER BLOCK DOWEL PILOT HOLE LOCATION	197	4	6G, 7G, 14A, 15A
CYLINDER HEAD CAP SCREW TIGHTENING PROCEDURE	187	1	ALL
CYLINDER HEAD, HIGH ALTITUDE	176	2	6G
CYLINDER HEAD, KEEP GASKETS TIGHT.	172	1	ALL
DO NOT START, W1189,	183	2	6G, 14A, M SERIES
GOVERNOR INSTALLATION.	200	2	6G, 7G
IDLING SPEED RECOMMENDATIONS	147	22	ALL
MANIFOLD HEAT VALVE PLUG	176	2	4G, 5G, 6G; M5, M15
OIL, DETERGENTS & ADDITIVES.	215	1	
OIL LEAK AT FRONT.	182	3	6G
OIL VISCOSITY RECOMMENDATIONS.	215	1	ALL
REAR SUPPORT INSULATORS AND WASHERS APPROVED	172	7	6G
ROUGH IDLE	178	3	6G, 14A

REFERENCE	BUL. I	PAGE NC	MODEL
E-Cont'd.			
ENGINE " CONT'D.			
STARTING INFORMATION	15:	9	ALL
STRIPPED. COMMANDER TYPE. ORDER DATA	20:	2	
SUPPORT FASTENING STUDS.	20:	5	M5. M15A, M16
TUNE UP. SETTING OCTANE SELECTOR	169	3	ALL
TURNING PLUG. COMMANDER.	20 ³	4	7A- 15A
VALVE LIFTERS AND ADJUSTING SCREWS	188	2	6G, M5. M15A
EQUIPMENT. STANDARD PRODUCTION TRANSMISSION.	125	4	K SERIES
EQUIPMENT TRANSFERS.	145	2	ALL
EXHAUST FUME VENTILATION	204	6	
EXHAUST LINE . TRANSMISSION NOISE.	180	2	14A
SYSTEMS FOR SERVICE DEPARTMENTS	192	3	ALL
SYSTEM INSPECTIONS.	147	20	ALL
F			
FACTORY SERVICE SCHOOL	166	1	ALL
FAN BELT. CARE OF.	152	4	ALL
DRIVER PULLEY. SMALLER	178	1	M5. M15, M15A
FAN. SIX BLADE. CORRECT PART NUMBER.	203	1	M SERIES
FENDIX, PROTECTIVE CAR UNDERCOATING.	188	1	ALL
FILTER, CLIMATIZER, REMOVAL FOR INCREASED HEAT FLOW REMOVED IN PRODUCTION.	179	4	14A
FINISH PAINT FORMULAS	182	1	6G. 14A
	171	6	5G
	177	3	6G, 14A
	197	3	6G.7G: 14A. 15A
	199	2	76. 15A
	200	1	76. 15A
FIRESTONE WARRANTY. MEANING AND PROCEDURES	171	5	ALL
FIRSTAID CHECKS. PHILCO	180	1	ALL
FLARING TOOL FOR DOUBLE FLARING.	204	6	
FLEET ACCOUNT SERVICE.	204	2	
FLOAT LEVEL. CARBURETOR.	160	3	ALL
FLOAT LEVEL GAGE	206	6	2R SERIES
FLOOR PAN, RIGHT, LEAK AT.	198	1	6G. 14A
FLOOR-TANK INTERFERENCE.	177	3	66. 14A
FLUSHMASTER, SLUDGE AND CARBON REMOVAL	193	9	ALL
FORREST GREEN FORMULA	203	4	M SERIES
FORM H353 DISCONTINUED	197	6	M SERIES
FORTIFY AND IMPROVE YOUR CUSTOMER RELATIONSHIPS.	156	1	
FRAM FILTER COVERS, TIGHTENING	132	2	ALL
CHANGING OF.	147	17	ALL
INSTALLATION CAUTION	171	7	5G
INSTALLATION REVISED	179	2	6G
AMP (MOTOR PROTECTOR) CAMPAIGN,	156	7	4LL
REPLACEMENT CARTRIDGE.	126	7	4LL
FREEING CLUTCH RELEASE SHAFT	187	4	1G. 14A
FREIGHT AND EXPRESS CARTAGE.	145	3	ALL
FRONT DOOR REMOTE CONTROL ADJUSTING LINK. RATTLE	189	2	1G, 14A
FRONT SEAT. ADDITIONAL SUPPORT FOR BACK.	177	4	1G 2-DOOR
ADJUSTING MECHANISM.	136	2	1G, 12A, 8C
BACK SLIPS PAST STOP	177	5	1G 2-DOOR
CUSHION TRIM WEAR.	173	3	1G
NOISE FROM UNDER	195	3	1G, 14A
UPHOLSTERY TEARING AT BOTTOM OF PANEL.	189	2	1G, 14A
FRONT SPRING CHECKS FOR SAG, ETC.	172	4	1G, 4G, 5G
METAL-TO-METAL CONTACT.	171	2	115
SHACKLE KIT	215	4	15A, M16
FRONT WHEEL BEARING LUBRICATION.	135	3	ALL
CAMBER ADJUSTMENT.	204	5	6G, 7G; 14A, 15A
SHAKE. LOW SPEED	211	1	4A, 15A
TOE-IN ADJUSTMENT.	203	2	6G, 7G; 14A, 15A
FUEL.	147	31	LL
PUMP.	160	6	LL
PUMP DIAPHRAGM REPAIR KITS.	130	3	LL
PUMP FILTER	159	9	LL
PUMP INSPECTION	157	4	LL
REMOVE AND INSTALL, CORRECTION IN TIME.	213	1	5A
TANK INTERFERENCE WITH FLOOR.	177	3	G, 14A

REFERENCE	BUL. NO.	PAGE NO	MODEL
F-Cont'd.			
FUEL SYSTEM: SEE GASOLINE SYSTEM.			
FUEL-VACUUM PUMP IN t4A CYLINDER BLOCK	203	2	14A. 15A
INSTALLATION.	208	6	7G
REPAIR KITS	206	5	7G, 15A. 2R SERIES
SERVICE TOOLS	203	8	15A
FUSES. NUMBER.	169	2	4G-5G;; 12A; 8 C
OVERDRIVE SOLENOID CONTROL RELAY.	180	2	6G, 14A
G			
GALA BROWN PAINT FORMULA	197	3	
GASKET CABINET	155	3	ALL
GASKET CEMENT, PERFECT SEAL.	136	6	ALL
GASKETS. CYLINDER HEAD. CHECKING FOR LEAKS	148	6	ALL
CYLINDER HEAD. KEEP TIGHT	172	1	ALL
CYLINDER HEAD (WARTIME)	154	2	ALL
GASOLINE. CONSERVATION OF.	153	11	ALL
CONSUMPTION.	137	4	ALL
CONSUMPTION. EXCESSIVE	150	4	ALL
ECONOMY.	160	2	ALL
ECONOMY. SETTING OCTANE SELECTOR	169	3	ALL
GAGE AND GASOLINE MILEAGE.	133	2	ALL
GAGE READING	148	6	ALL
GAGE SYSTEM, TESTING	158	6	ALL
STRAINER, CLEANING OF.	149	6	ALL
TANKS AND LINES.	160	6	ALL
TANKS. WELDING	152	7	ALL
GASOLINE SYSTEM: HAND THROTTLE CONTROL.	203	4	M SERIES
MILEAGE TESTER (GAUTHIER).	207	8	
ZENITH CARBURETOR.	203	5	M5, M15A
GAUTHIER GASOLINE MILEAGE TESTER	207	8	
GEAR SHIFTING, TRANSMISSION.	191	2	14A
GEARSHIFT FT LEVER, RATTLE.	207	4	76. 15A
GEARSHIFT MECHANISM. WIRES CONTACTING.	173	2	6G
GENERATOR EARLY CUT-IN.	209	2	6G,76: 14A. 15A
GENERATOR, HIGH OUTPUT	203	3	14A. 15A
GET THE NEW OWNER OFF TO A GOOD START.	207	2	
GLASS CLAIMS	175	1	ALL
IN CHANNEL, POSITIONING OF	137	6	ALL
GLASS REPLACEMENT SOURCES.	209	1	
GLOVE COMPARTMENT DOOR LATCH SCREW AND NUT	136	2	12A. 8C
LAMP CABLE, BREAKAGE OF.	140	9	46. 12A. 8C
GLYCOL BASES FOR ANTIFREEZES	199	2	ALL
GOVERNOR ENGINE INSTALLATION.	200	2	6G. 7G;
FOR GOVERNOR-CONTROLLED OVERDRIVE			
TRANSMISSION. SUBSTITUTED.	166	12	8C
FOR PASSENGER CARS	145	5	ALL
GREASE GUNS, REFILLING OF.	148	7	ALL
GREASE LEAKS, FRONT WHEEL. ELIMINATING	162	12	ALL
REAR WHEEL, ELIMINATING.	162	12	ALL
LEAK AT SPEEDOMETER CABLE	177	1	6G. 14A
GUARANTEE POLICY. WILLARD BATTERY.	201	1	
GM REMOVER FOR GAS LINES.	155	3	ALL
H			
1350. PREPARATION OF VEHICLE FOR DELIVERY.	183	1	ALL
1353 FORM DISCONTINUED	197	6	M SERIES
HANDTHROTTLE CONTROL.	203	4	M SERIES
HARD STARTING CAUSED BY WET OR DAMP IGNITION			
SERVICE HINT ON.	139	3	ALL
HARDWARE CLEANING SILVERED FINISH	149	5	46. 12A. 8C
HARTMAN RAPID BATTERY CHARGER-ANALYZER	189	4	ALL
HEADLAMP TESTER, ROBOT	192	3	ALL
TESTING EQUIPMENT	135	9	ALC
HEADLIGHT AIMING SCREENS	197	7	
HEAVY DUTY CLUTCH LINKAGE.	178	2	M5. M15. M15A
HEAVY DUTY FRONT SPRINGS WITH OVERSIZE TIRE			
EQUIPMENT. USE	179	4	6G

REFERENCE	BUL. NO.	PAGE NO.	MODEL
H-Cont'd.			
HEAVY DUTY RADIATOR CORE EQUIPMENT	199	5	M SERIES
HEAVY DUTY REAR SPRING REAR HANGERS.	187	2	M15, M16
HEAVY DUTY SPRING BUSHING SPACERS.	188	4	M15, M16
HEAVY DUTY SPRINGS. SAG CHECKS	172	5	3G, 4G, 5G
HELPFUL COMBINATIONS OF SERVICE OPERATIONS	146		
HIGH ALTITUDE EQUIPMENT.	176	2	6G
HIGH OIL LEVEL IN OIL BATH TYPE AIR CLEANER.	150	4	ALL
HIGH OUTPUT GENERATOR.	203	3	14A, 15A
HIGH TENSION WIRING.	160	8	ALL
HILL-HOLDER ADJUSTMENT	162	22	ALL
INSTALLATION	180	1	M SERIES
REPAIR KIT	215	2	ALL
HM-925- 17- 18- 19 FRONT SPRING UNLOADER.	175	2	6G, 14A
HOLD DOWN CLIPS FOR DISPLAY CARS	130	3	ALL
HOOD , HINGE WATER LEAK	206	3	6G, 7G; 14A, 15A
LEAK AT HINGE SUPPORT.	198	5	6G, 14A
LOCK RELEASE. SERVICING.	191	2	6G, 14A
TO OPEN LATCH IF CABLE BROKEN.	182	1	6G, 14A
HORN . BUTTON AND CABLE	138	3	4G, 12A, 8C
BUTTON, DELUXE STEERING WHEEL.	137	3	4G, 12A, 8C
BUTTON LOOSE, OUT OF POSITION.	178	1	6G, 14A
SHOCK AT RING.	177	2	6G, 14A REGALS
WIRE INSTALLING TOOL	155	3	ALL
HORN PUSH BUTTON RATTLE.	201	1	6G, 14A
HOUDAILLESHOCK ABSORBER FILLING EQUIPMENT	149	6	ALL
HOW TO GET THE BEST RESULTS FROM CLIMATIZER.	179	3	6G, 14A
HOW TO MAKE PILOT STUDS.	197	5	ALL
Hue AND DRUM. WHEEL. AND TIRE RUN-OUT SPECIFICATIONS	197	4	6G, 7G; 14A, 15A
HYDRAULIC FLUID, PETROLEUM BASE HARMFUL.	163	5	ALL
HYDRAULIC SYSTEM, BLEEDING	162	18 & 20	ALL
HYDROMETER AND ANTIFREEZES	199	1	ALL
HYDROVAC, BRAKE BOOSTER.	199	5	M16
TESTING.	213	1	2R SERIES
HYPoid, TYPE TWO-SPEED VACUUM SHIFT REAR AXLE	189	2	M16
I			
IDLER LEVER, STEERING.	207	4	6G
IDLE. ROUGH.	178	3	6G, 14A
IDLE SPEED AND IDLE MIXTURE SETTING. CARBURETOR.	160	5	ALL
IGNITION* SEE ALSO DISTRIBUTOR: SPARK PLUGS			
CABLES . IT'S EASY TO FORGET.	156	2	ALL
COIL.	160	8	ALL
SETTING OCTANE SELECTOR	169	3	ALL
SPARK PLUG LIST	172	1	ALL
IGNITION TIMING LIGHT (PEERLESS)	207	8	
INFRA-RED DRYING FOR REFINISHING	136	4	ALL
INGERSOLL-RAND IMPACT TOOL	208	6	
INNER TUBES, HOW TO MOUNT CORRECTLY.	163	6	ALL
INSPECTION OF TIRES.	147	13	ALL
INSTALLATION OF VACUUM BOOSTER PUMP ON CERTAIN M5 AND ~ 1 TRUCKS.	200	2	M5, M15A
INSTALLATION OF SWAY BAR ANCHOR BOLTS.	197	5	14AS, 14AY
INSTALLING PUSH BUTTON STARTER	199	4	M SERIES
INSTRUMENT BOARD. SPECIAL STEERING POST SUPPORT TO	179	2	14A
INSULATOR. STEERING KNUCKLE SUPPORT ARM.	170	3	2G, 5G
INTERCHANGE OF TRANSMISSIONS	152	10	3G, 4G
IROQUOIS BLUE BAKING ENAMEL.	200	1	7G, 15A
IROQUOIS BLUE.	209	2	2R SERIES
J			
J207-22 DIFFERENTIAL CARRIER. SIDE CARRIER BEARING	170	5	ALL
J505-SCT CARBURETOR REPAIR KIT	170	5	ALL
J505-SD CARBURETOR TOOL KIT	206	6	ALL
J553-5 REAR SPRING SHACKLE BUSHING REMOVER AND REPLACER	170	5	ALL

REFERENCE	BUL. NO.	PAGE NO.	MODEL
J-Cont'd.			
J1294-4 ADAPTER FOR J1294 STEERING KNUCKLE BUSHING AND BEARING INSERTER	175	3	6G
J1308-B TRANSMISSION SHIFT ROD ADJUSTING GAGE.	175	2	6G, 14A, M5
J1685 DOOR STRAIGHTENER.	136	8	ALL
J2027 REAR AXLE SHAFT OUTER SEAL LOCATOR	175	2	6G
J2031 STEERING KNUCKLE PIN TO UPPER SUPPORT ARM DRIVER	175	2	6G, 14A
J2032 REAR AXLE SHAFT OUTER SEAL LOCATOR	175	3	14A, M5
J2033 STEERING BELL CRANK NEEDLE BEARING REMOVER AND REPLACER	175	2	14A
J2034 VALVE STEM GUIDE REMOVER AND REPLACER.	175	2	6G, 14A, M SERIES
J2035 COMPANION FLANGE HOLDING TOOL.	175	2	6G, 14A, M SERIES
J2036 CAMSHAFT BEARING REMOVER AND REPLACER SET.	175	2	6G, 14A, M5
J2037 REAR AXLE PINION SHAFT BEARING OIL SEAL DRIVER	175	2	6G, 14A
J2038 TRANSMISSION REAR FLANGE OIL SEAL DRIVER	175	2	6G, 14A, M5
J2039 TRANSMISSION THRUST YOKE	175	2	14A, M5
J2040 TRANSMISSION THRUST YOKE	175	2	6G
J2042 STEERING KNUCKLE BUSHING AND BEARING REMOVER AND REPLACER	175	2	14A
J2043 STEERING KNUCKLE SUPPORT ARM SPREADER (LARGE END).	175	2	6G, 14A
J2044 STEERING KNUCKLE SUPPORT ARM SPREADER (SMALL END).	175	2	6G, 14A
J2046 COMPANION FLANGE PULLER.	175	2	6G, 14A, M SERIES
J2200 STEERING ARM BALL BOLT PULLER.	211	5	
J2679 REMOTE CONTROL STARTER SWITCH.	211	5	
J2827 REAR WHEEL BEARING LOCK NUT CLINCHING TOOL	213	2	
J2975 WHEEL BEARING NUT WRENCH 2-3/8" HEX.	213	2	
JACKS, SHOP AND TOOL BOX: CARE OF	153	3	ALL
JETS	147	28	ALL
JOYCE-CRIDLAND LIFTS, TWO POST	189	3	ALL
K			
KEEP TIRE GAGES ACCURATE	180	2	ALL
KENT-MOORE TOOL AND EQUIPMENT CATALOG.	211	5	
KMO-570 WHEEL BEARING NUT WRENCH, 2-7/8" HEX.	213	2	
KMO-630 TRANSMISSION SNAP RING PLIERS.	211	5	
KMO-733 FLOAT LEVEL GAGE	206	6	2R SERIES
KNOCKS- SOUND UNDERCOATING.	206	6	
L			
LACQUER OR ENAMEL FINISH: CARE OF	147	24	ALL
LATHE, ARMATURE. BY JOHNSON.	203	8	
LEAK. (AIR, WATER OR DUST) BRAKE PEDAL COVER FASTENERS.	198	1	6G, 14A
CONVERTIBLES	201	3	6G, 14A
CONVERTIBLES, TOP HEADER	207	5	6G, 14A
COWL, FRONT SEAT COMPARTMENT	198	4	6G, 14A
DOOR CENTER PILLAR POST, TRIM PANEL.	198	2	6G, 14A
DOOR CENTER SECTION,	198	2	6G, 14A
DOOR DRAIN	198	1	6G, 14A
DOOR, TOP AND BOTTOM	198	2	6G, 14A
DOOR WINDOWS AND VENTILATORS	204	4	14AY, 15AY
DRIP MOULDINGS	198	4	6G, 14A
DRIVER'S COMPARTMENT	206	2	6G, 7G; 14A, 15A
HOOD HINGE SUPPORT	198	5	6G, 14A
LEFT KICK PAD.	139	3	4G, 12A, 8C
LUGGAGE COMPARTMENT FLOOR PAN.	198	6	6G, 14A
LUGGAGE COMPARTMENT TOP CORNERS,	198	6	6G, 14A
MATERIALS TO CORRECT	206	3	ALL
REAR SEAT COMPARTMENT, 2-DOOR SEDANS	198	6	6G, 14A
RIGHT FLOOR PAN.	198	1	6G, 14A
TRUNK.	198	7	6G
VARIOUS BODY LEAKS CORRECTED	198	1-7	6G, 14A
VENTILATOR WINDOW WEATHERSEAL.	198	3	6G, 14A
WINDSHIELD RUBBER WEATHERSTRIP	198	5	6G, 14A

REFERENCE	BUL. NO.	PAGE NO.	MODEL
L-Cont'd.			
LEAK, CARBURETOR. EXTERNAL	160	4	ALL
LEAK (OIL AND GREASE), CLUTCH HOUSING.	182	3	6G
FRONT OF ENGINE	182	3	6G
REAR WHEEL GREASE LEAK.	167	2	ALL
SPEEDOMETER CABLE	177	1	6G, 14A
TRANSMISSION.	187	4	6G
LEFT COWL VENTILATOR CLIMATIZER INTAKE	139	3	3G,4G; 11A,12A, 7C,8C
LET'S RESTORE SERVICE ROUTINES BY DON O. WILSON.	189	1	ALL
LICENSE PLATE BRACKET. PROPER MOUNTING OF FRONT.	186	1	6G
LIFT. TRUCKS, POINTS TO CONSIDER BEFORE PURCHASE	170	5	M SERIES
LIFTS, ELECTRIC (WALKER)	213	2	
LIGHTER FAILURES	144	2	ALL
LINING, BRAKE. USE SAME FRONT AND REAR	179	3	ALL
LININGS. UNNECESSARY REPLACEMENT OF.	137	2	ALL
LINKAGE SHAFT AND LEVERS, CLUTCH	158	3	M SERIES
LIQUID INSULATION, PIB	144	5	ALL
LOCATION OF CYLINDER BLOCK DOWEL PILOT HOLES	197	4	6G,7G; 14A, 15A
LOCKING N GEAR.	149	2	ALL
LOCKS. FREE FROZEN	148	6	ALL
LEFT FRONT DOOR, INSTALLATION	171	4	3G,4G,5G; 11A,12A
REMOTE CONTROL MECHANISM.	180	2	6G, 14A
LOOSE ASH TRAYS.	187	3	14AY
LUBRICANTS APPROVED FOR ROSS STEERING GEARS.	204	5	
LUBRICANTS. TRANSMISSION AND DIFFERENTIAL GEARS.	208	5	
LUBRICATION. CHASSIS SPRINGS	204	3	
LUBRICANT LEAK AT 2-SPEED AXLE VENT.	200	2	M SERIES
LUBRICATION. ARO EQUIPMENT	191	3	ALL
FRAMFIL FILTER INSTALLATION CAUTIONS	171	7	5G
FRAMFILTER INSTALLATION REVISED.	179	2	6G
GENERAL	161	5	ALL
LARGE CAPACITY OIL PUMP	176	1	2G- 5A; M5,M15
LARGE CAPACITY OIL PUMP FOR SERVICE	179	2	3A- 12A: J SERIES .
TRANSMISSION..	147	18	M SERIES
USE LOW PRESSURE ONLY IN LUBRICATING			ALL
UNIVERSAL JOINT	197	5	ALL
LUGGAGE COMPARTMENT BODY BOLT CAP.	177	3	6G. 14A
LUGGAGE COMPARTMENT FLOOR PAN, LEAK AT	198	6	6G, 14A
LUGGAGE COMPARTMENT, TOP CORNERS. LEAK AT.	198	6	6G. 14A
LOCK. OPENS WHEN LOCKED	182	2	6G
WATER LEAKS	172	6	6G
RM			
MACHINING DRUMS.	162	10	ALL
MANIFOLD HEATER VALVE.	159	7	ALL
HEATER VALVE. ENGINE, STICKING.	130	2	ALL
HEATER VALVE. STICKING.	160	6	ALL
HEAT VALVE PLUG	176	2	4G,5G,6G; M5,M15
PIPE, BREATHER TUBE TO.	147	19	ALL
PIPE, BREATHER TUBE EQUIPMENT	138	6	ALL
MAIN SHAFT SYNCHRONIZER SLEEVE	139	2	4G. 12A, 8C
MAINTENANCE OF NEW AUTOMOTIVE VEHICLES, STANDARDS.	141	2	ALL
OF STORED VEHICLES, STANDARDS FOR.	141	1	ALL
MANUAL, TRUCK REPAIR	149	15	
MARK ON STEERING WHEEL	213	1	15A
MASTER CYLINDER, BRAKE. HOLE COVER WATER LEAK.	206	3	6G,7G; 14A, 15A
PIPE CLIP, BRAKE.	208	6	2R SERIES
SERVICING	162	15	ALL
MASTER MECHANIC AWARD PROGRAM, REQUIREMENTS.	203	1	
MATERIALS FOR CORRECTION OF WATER. DUST, AND AIR			
LEAKS..	206	3	
MELODY BLUE BAKING EWAMEL.	200	1	7G, 15A
	209	2	2R SERIES
METERING ROD	147	28	ALL
METERING SYSTEM, MAIN. CARBURETOR.	160	4	ALL
MILEAGE. GASOLINE USAGE TESTER (GAUTHIER).	207	8	
MILEAGE LEFT IN TIRES.	147	14	ALL

REFERENCE	BUL. NO.	PAGE NO.	MODEL
M-Cont'd.			
MIRROR. REAR VIEW, LOCATION.	173	2	6G
M SERIES TRUCKS, LIFT DATA	170	6	M SERIES
MODIFICATION OF TRANSMISSION SYNCHRONIZER RING PROTECTOR.	201	4	15A
MOTOPHONE. ACCURATE DIAGNOSIS AIDED BY	195	4	ALL
MOTOR TUNE-UP (ANALYSIS) EQUIPMENT. ALLEN.	203	8	
MUFFLER AND EXHAUST PIPE, EARLY FAILURES	145	4	ALL
SLEEVES.	136	3	ALL
N			
NATIONAL SYSTEM OF GARAGE VENTILATION.	204	6	
NEW AUTOMOTIVE VEHICLES. STANDARDS FOR MAINTENANCE O NEW FLOAT LEVEL GAGE. 3/8 INCH. AVAILABLE FOR CARBURETOR TOOL KITS	141	2	ALL
NEW FRONT AXLE ASSEMBLY KITS	200	2	
NEW STARTER MOTOR SWITCH FASTENING CLIPS	197	6	M15A
NEW TYPE CLIMATIZER VALVE CONTROL CABLE REDUCES NOISE TRANSMITTAL.	191	1	M SERIES
NOISE FROM UNDER FRONT SEAT.	186	3	6G
REAR SEAT.	195	3	6G, 4A
TRANSMISSION-EXHAUST LINE.	195	1	6G, 4A
TRANSMISSION AND OVERDRIVE	180	2	14A
UNUSUAL ENGINE	137	4	4G, 2A, 8C
NO-OXID OIL PROTECTS METAL PARTS AGAINST CORROSION . NO-ROL UNIT ■■ SEE HILL HOLDER.	147	16	ALL
	144	2	ALL
O			
,001"UNDERSIZE CONNECTING ROD BEARING INSERTS	186	3	6G, 14A
OAKITE No. 70. CAR WASHING	209	4	
OCTANE SELECTOR, ADJUSTMENT PROCEDURE.	169	3	ALL
OIL BAFFLES. VALVE SPRING CHAMBER CHAMPION ENGINE. .	209	1	
OIL BATH (WET) AIR CLEANER. SERVICE INSTRUCTIONS . . .	169	2	ALL
OIL CONSUMPTION VS TORQUE WRENCHES	150	8	ALL
OIL. ENGINE FILLER PIPE INSTALLATION COMMANDER ENGINES .	211	2	
FILTER, FRAM,INSTALLATION CAUTION.	171	7	5G
FILTER, FRAMINSTALLATION REVISED.	179	2	6G
FILTERS	159	7	ALL
LEAK AT CLUTCH HOUSING.	182	3	6G
LEAK AT FRONT OF ENGINE	182	3	6G
LINE PLUG SOCKET. KMO-370	138	8	2G-4G
LUBRICANT SPECIFICATIONS.	125	3	ALL
OIL PRESSURE,	200	2	M16
PRESSURE.	147	17	ALL
PRESSURE, LOW	156	5	ALL
PRESSURE RELIEF VALVE. KEEP DRILLED HOLE OPEN	166	9	ALL
PUMP, LARGE CAPACITY.	170	3	7A-12A
PUMP, LARGE CAPACITY.	176	1	2G-5G; M5-M15
PUMP. LARGE CAPACITY FOR SERVICE.	179	2	3A-12A; J SERIES . M SERIES
PUMP, VACUUM BOOSTER. WINDSHIELD WIPER.	179	4	M SERIES
RECOMMENDATIONS	215	1	ALL
SPECIFICATIONS,	139	4	ALL
USE OF "10W" OR "20W":	126	2	ALL
OILPUMP DRIVE GEAR PULLER. J-2959	213	2	
WINDSHIELD WIPER VACUUM BOOSTER	195	2	6G, 14A
WINDSHIELD WIPER VACUUM BOOSTER CHECK VALVE ASSEMBLY.	193	3	6G,14A; M5,M16
OIL. SLUDGE ■ ITS CAUSE. PREVENTION, AND CURE. . . .	197	1	ALL
OPERATION K-69. CORRECTION IN TIME	213	1	15A
OPERATOR'S GUIDE DISCUSSED	183	4	M SERIES
ORDERING REAR WHEEL BEARING WRENCH	197	6	M15A, M16
OVERDRIVE. ADVANTAGES AND OPERATION.	193	2	ALL
ASSEMBLY EXCHANGES.	153	4	2G-4G; 9A-12A; 5C-8C

REFERENCE	BUL. NO.	PAGE NO.	MODEL
0-Cont'd.			
OVERDRIVE • CONT'D.			
DIAGNOSIS CHART	171	6	46.56: 11A, 12A; 7C, 8C (EXCEPT GOVERNOR CONTROLLED)
	212	4	66.76: 14A, 15A
RELAY CONTROL	172	6	ALL EXCEPT 6G AND 8C
SOLENOIDS, ALTERNATE MAKE	170	4	56
SOLENOID CONTROL RELAY FUSE	180	2	6G, 14A
SOLENOID SHIELD INTERFERENCE.	178	3	6G, 14A
TRANSMISSION. DISTINGUISHING GOVERNOR CONTROLLED.	138	3	8C
TRANSMISSION, GOVERNOR CONTROLLED	149	7	8C
OVERDRIVE GOVERNOR OPENING COVER WATER LEAK.	206	2	6G, 7G; 14A, 15A
OVERDRIVE TRANSMISSIONS ON M5 TRUCKS	197	6	M5
OVERHEATING. CYLINDER WATER MANIFOLDS DETERIORATED	164	8	ALL
LOSS OF COOLANT	159	5	ALL
OVERSIZE RINGS AND PISTON, .040"	201	1	
OWNER. NEW, GET OFF TO A GOOD START.	207	2	
OWNER'S GUIDE DESCRIBED.	183	4	6G, 14A
P			
PACKAGE COMPARTMENT CARD DESCRIBED	183	4	ALL
PAINT. INFRA-RED DYING	136	4	ALL
SPRAY EQUIPMENT	135	7	ALL
SYMBOL LOCATION	192	1	6G, 14A
PAINT FORMULAS	171	6	5G
	177	3	66: 14A
	197	3	66.76: 14A, 15A
	199	2	76. 15A
	200	1	7G, 15A
PAINT SHOPS (DEVILBISS)	204	6	
PARTS PRICE CATALOGUE, SERVICE INFORMATION ON.	130	2	ALL
PARTS REPLACEMENT.	147	24	ALL
PARKING BRAKE, APPLICATION	211	1	ALL
CABLE PIN AND STEERING .POST COLLAR INTERFERENCE.	203	4	7G, 15A
HANDLE TENSION ADJUSTMENT	203	3	6G, 7G; 14A, 15A
RATCHET SPRING REPLACEMENT.	197	3	6G. 14A
PARKWAY GREEN BAKING ENAMEL.	200	1	76. 15A
PEACOCK GREEN BAKING ENAMEL.	203	2	76. 15A
PEDAL. BRAKE, HOLE COVER WATER LEAK.	206	3	66.76: 14A, 15A
PEDAL FREE TRAVEL, BRAKE	203	2	66.76: 14A, 15A
PEERLESS POWER TIMING LIGHT.	207	8	
PETROLEUM EASE AVIATION BRAKE FLUID HARMFUL.	163	5	
PETROLEUM ANTIFREEZES.	199	1	ALL
PERFORMANCE, ENGINE.	161	5	ALL
PHILCO AUTHORIZED DISTRIBUTORS AND SERVICE STATIONS			
NEW LIST MAILED	191	3	ALL
CAR RADIO SPECIAL INSTALLATION AGREEMENT.	140	7	ALL
CUSTOMER PUBLICATIONS	125	2	ALL
DEALER LIST	214	2	
FIELD SERVICE	134	2	ALL
FIRST AID CHECKS.	180	1	ALL
PHILCOPHONE	135	6	ALL
PHILCO RADIO, IDENTIFICATION.	207	7	2R SERIES
PHILCO SERVICE STATION COOPERATION.	214	4	
PUBLICATIONS.	132	2	ALL
WARRANTY. DISTRIEUTORS.	129	5	ALL
PIB. LIQUID INSULATION	144	5	ALL
PICK-UP BOXES.	211	4	2R5, 2R10, 2R15
PILOTS. CYLINDER HEAD AND GASKET	195	2	14A, M16
PILOT STUDS, HOW TO MAKE	197	5	ALL
PINION BEARING PULLER ■ J1298.	137	7	ALL
PINION OIL SEAL, NOISE AT.	137	4	46. 12A, 8C
SQUEAKS AT THE.	148	9	ALL
PISTON. ALUMINUM REPLACEMENTS.	138	2	ALL
AND RINGS .040". OVERSIZE	201	1	

	IUL.NO.	PAGE NO	MODEL
Cont'd.			
PISTON * CONT'D.			
AND RING OPERATION	160	8	ALL
PINS AND BUSHINGS IN FERRIC-ALLOY PISTONS			
FITTING OF	137	3	ALL
PIN, HOW TO REMOVE AND INSTALL	163	6	2G-4G
RINGS.. . . .	136	5	8C
RING REPLACEMENT AFTER REBORING.	170	2	3G.4G. 5G: M5.M15
RING SETS (PERFECT CIRCLE CUSTOM MADE)	166	10	ALL
PLANAR FRONT SPRINGS. DO NOT REPLACE NEEDLESSLY.	162	8	ALL
SUSPENSION (SEE STEERING)	163	8	ALL
PLASTAHIDE SERVICE COVERS PROTECT CARS, CUT COSTS.	188	4	ALL
PLASTIGAGE OFFERS QUICK ACCURATE BEARING TOLERANCE			
MEASUREMENT.	199	5	
PLEDGE. STUDEBAKER SERVICE MAN'S	167	1	
PLEXITE GLASS DISTRIBUTORS	132	5	ALL
POSITIVE BRAKE PEDAL RETURN.	188	1	66. 14A
POWER TAKE-OFF DATA FOR TRU-STOP EQUIPPED M16.	191	4	M16
PREPARATION OF VEHICLE FOR DELIVERY			
DESCRIPTION, USE	183	1	66, 14A. M SERIES
PRIMARY CIRCUIT CHECK UNIT	135	8	ALL
PROB-O-PHONE AIDS DIAGNOSIS.	215	4	
PROPELLER SHAFT BEARING SUPPORT CROSS MEMBER	136	8	M15. M16
SLIP JOINT SPLINE, RUST SPOTS.	152	9	ALL
SUPPORT ASSEMBLY	209	3	2R10. 2R15. 2R16. 2R17
SUPPORT BEARING.	195	4	M15-28. M15A-28, M16
SUPPORT BEARING KIT.	211	3	M15A. M16
SUPPORT SCREW TENSION.	203	7	M SERIES
SUPPORT, SPACER FOR.	200	2	6G. 14A
VIBRATION. SINGLE SPEED AXLE	201	2	M15A. M16
PROPER MOUNTING OF FRONT LICENSE PLATE BRACKET	186	1	66
PROTECTIVE CAR UNDERCOATING.	188	1	ALL
PUMP. OIL. LARGE CAPACITY.	170	3	7A- 12A
LARGE CAPACITY.	176	1	2G-5G: M5. 5
LARGE CAPACITY IN SERVICE	179	2	3A-12A: J SERIES * M SERIES
WINDSHIELD WIPER VACUUM BOOSTER	195	2	66. 14A
PUMP. WATER, INLET HOSE REINFORCING CLIP	170	4	M16
PUSH BUTTON STARTER. INSTALLING.	199	4	M SERIES
SWITCH.	212	3	2R16. 2R17
R'			
RADIATOR CORE SERIAL LOCATION.	179	1	6G. 14A
CORE SUPPORT TO DASH TIE ROD ASSEMBLIES	193	4	M16
GRILLE AND OTHER PARTS. RUST STAINS ON.	137	2	4G. 12A. 8C
HEAVY DUTY. CORE EQUIPMENT.	199	5	M SERIES
SEAL.	163	4	ALL
RADIO. ADDITIONAL SUPPRESSION FOR UNUSUAL NOISE.	136	3	4G. 12A. 8C
ANTENNA SERVICE	214	4	
BENCH TEST...	214	2	
ELEMENTARY CHECKS	167	3	ALL
FIRST AID CHECKS, PHILCO.	180	1	ALL
FIRST AID CHECKS.	214	3	
IDENTIFICATION.	207	7	2R SERIES
INSTALLATION.	214	2	
INTERFERENCE IN CARS EQUIPPED WITH AC-1237			
ANTENNA.. . . .	137	3	4G. 12A. 8C
PHILCO REGISTRATION TAG DESCRIBED	183	3	6G. 14A. M SERIES
PHILCO SERVICE DATA	171	3	ALL
PHILCO SERVICE STATIONS	191	3	ALL
REGISTER NEW PHILCOS.	179	1	ALL
SERVICE PROCEDURE	214	3	
WARRANTY SERVICE.	214		
RATTLE. FRONT DOOR REMOTE CONTROL ADJUSTING LINK	189	2	6G, 4A
FRONT DOOR GLASS	173	1	6G
HORN PUSH BUTTON	201	1	6G. 4A
TRANSMISSION REMOTE CONTROL (GEARSHIFT LEVER	207	4	7G. 5A

REFERENCE	BUL. NO	PAGE NC	MODEL
R-Cont'd.			
REACH RODS, INSTALLATION OF	148	8	10A- 12A: 6C-8C
REAR AXLE ASSEMBLY, WIDE TREAD	203	6	M16
CODING..	211	2	2R SERIES
COMPANION FLANGE HOLDING TOOL J2035.	175	2	66. 14A. M SERIES
COMPANION FLANGE PULLER J2946	175	2	6G. 14A. M SERIES
DAMAGED ASSEMBLIES DO NOT MERIT FULL CLAIMS CREDIT.	197	6	M15A. M16
GEARSHIFT.	212	6	2R SERIES (2-SPEED)
HYPOID TYPE 2-SPEED VACUUM SHIFT	189	2	M16
LUBRICATION WARNING TAGS	130	4	ALL
LUBRICATION OF	147	18	ALL
PINION SHAFT BEARING OIL SEAL DRIVER J2037	175	2	6G. 14A. M SERIES
RATIO CHANGE	203	6	M15A
SHAFT INNER BEARING GREASE SEAL.	136	3	46. 11A. 8C. M5
SHAFT OUTER SEAL LOCATOR J2027	175	2	6G
SHAFT OUTER SEAL LOCATOR J2032	175	3	14A. M5
SPACER, REAR SPRING TO	170	3	M15, M16
TIMKEN, SERVICE PROCEDURES	206	6	2R16. 2R17
2-SPEED. SELECTOR VALVE.	204	5	M SERIES
2-SPEED TAG W969	171	3	M16
REAR AXLE ASSEMBLY. EXCHANGE	133	2	ALL
REAR BRAKE BACKING PLATE INSTALLATION.	177	1	M15, M15A, M16
?EAR SEAT. LEAK INTO COMPARTMENT. 2-DOOR SEDANS.	198	6	6G. 14A
NOISE	195	1	6G, 14A
REAR SPRING AND FRONT ASSEMBLIES	195	3	M5
BOLTS..	170	4	4G, 5G; 12A: 8C; M5
DATA FOR CHECKING.	172	5	3G, 4G, 5G
REBOUND CLIP KIT	193	2	6G. 14A
TO AXLE SPACER	170	3	M15, M16
U-BOLT NUTS.	203	6	M5
REAR VIEW MIRROR LOCATION.	173	2	6G
?EAR WHEEL, BEARING LOCK NUT CLINCHING TOOL J2827.	213	2	
BEARINGS, LUBRICATION OF	148	7	ALL
GREASE SEAL.	215	4	2R10
RUN-OUT.	172	5	ALL
REBOUND CLIP. REAR SPRING KIT.	193	2	6G, 14A
REAR SPRING.	209	1	7G, 15A
RECOMMENDED TIRE PRESSURES	191	3	6G, 14A
REFERENCE CARD, GLOVE COMPARTMENT.	183	4	ALL
REFINISHING MANUAL, ADDITIONS TO	140	9	ALL
RELAY CONTROL, OVERDRIVE	172	6	ALL EXCEPT 6G AND 8C GOVERNOR CONTROLLED
RELEASE FINGER. ADJUSTMENT OF.	152	3	3G, 4G
RELINE JOB.	162	9	ALL
REMOVAL OF PROTECTIVE COATING ON WHITE SIDEWALL TIRES..	191	1	ALL
REPAIR ORDER FORM S-180	139	1	ALL
REPOSITIONING TIRES AIDS SMOOTH RIDE	193	7	M15A-20
REVERSE FLUSHING. COOLING SYSTEM	147	18	ALL
RIN GEAR HEATER, STARTER. V91	170	5	ALL
RIGHT SHROUD VENTILATOR GASKET	206	3	6G, 7G; 14A. 15A
RIMS, NEW TYPE	206	6	2R SERIES
RINGS AND PISTONS. .040" OVERSIZE.	201	1	
ROBOT HEADLIGHT TESTER	192	3	ALL
RODEO TAN ENAMEL	199	2	7G, 15A
ROOF TRIM REINFORCING BOW.	213	2	2R SERIES
ROSS GEAR APPROVED LUBRICANTS.	204	5	
ROTO BEARING INSTALLATION.	208	4	
RUBY GLOW RED FORMULA.	203	4	M SERIES
RUN-OUT. REAR WHEEL.	172	5	ALL
SPECIFICATIONS. WHEEL, TIRE. HUB AND DRUM	197	4	6G. 7G, 14A. 15A
RUST INHIBITOR, STUDEBAKER COOLING SYSTEM.	166	6	ALL
RUST INHIBITOR TAG	172	2	ALL
RUST PREVENTIVE. REMOVE.	215	3	ALL
S			
SALT BASE ANTIFREEZES.	199	1	ALL
SANDER. NON-VIBRATING. WET OR DRY.	155	13	ALL

REFERENCE	BUL .NO	PAGE NO.	MODEL
S-Cont'd.			
SANDER. PORTABLE ELECTRIC BY STERLING.	203	7	
SAVE OLD WATER PUMP GREASE CUPS.	191	1	ALL
SCRAP. COLLECTION OF	150	14	ALL
SCUFF PLATES, RUBBER COVERED. DOOR	126	6	10A. 6C
SEALER. DOLPHIN EYEBROW AND SYMBOLS.	181	2	6G. 14A
SEAL. FLOOR PAN TRANSMISSION CLEARANCE COVER	211	5	2R SERIES (4-SPEED)
SEAT, FRONT. BACK OF, ADDITIONAL SUPPORT	177	4	6G 2-DOOR
BACK SLIPS PAST OUTER STOP.	177	5	6G 2-DOOR
CUSHION TRIM WEAR	173	3	6G
SQUEAK AT OUTER STOP.	177	5	6G 2-DOOR
SERVICE ADJUSTMENTS FOR VACUUM POWER BRAKE AND CLUTCH CONTROLS.	190	1 - 7	3G-6G
SERVICE BRAKES PEDAL ADJUSTMENT.	203	2	6G,7G; 14A,15A
SERVICE BRAKE ADJUSTMENT	195	1	6G, 14A
SERVICE BULLETINS. HOW TO USE.	205		
SERVICE COVERS, HOW TO MAKE.	172	2	6G, 14A
SERVICE COVERS PROTECT CARS, PLASTAHIDE	188	4	
SERVICE IS OUR BUSINESS.	200	1	
SERVICE MAN'S PLEDGE	167	1	
SERVICE MERCHANTISERS. A NOTE ON BUYING.	192	2	
SERVICE MERCHANTISERS (KENT-MOORE)	213	2	
SERVICE POLICY. DEALER, REVISED.	193	1	ALL PASS.
DEALER'S DESCRIBED	183	3	6G. 14A, M SERIES
SERVICE SCHOOL	166	1	ALL
SERVICE STATION CLEANING METHOD.	150	7	ALL
SERVICE SYSTEM. COMBINATION OF OPERATIONS.	146		
SERVICE UNIFORMS APPRECIATED BY STUDEBAKER DEALERS	192	2	
	204	6	
	197	7	
SERVICING HOOD LOCK RELEASE.	191	2	6G, 14A
SHIELD. BRAKE PEDAL SPLASH	188	2	6G. 14A, 14AY
SHIFT ROD ASSEMBLIES, TRANSMISSION REMOTE CONTROL.	187	4	6G
SHOCK ABSORBERS A FACTOR IN TIRE CONSERVATION.	144	2	ALL
FILLING EQUIPMENT.	149	6	ALL
FILLING OF	147	20	ALL
IDENTIFYING CHARACTERISTICS.	178	4	ALL
IMPROVEMENT, INSTALLATION.	172	3	M SERIES
LINK BOLT SPACER	192	2	6G, 14A
REMOVAL OF LEFT FRONT.	128	6	11A
REFERENCES	186	1	6G. 14A
STIFF PLANAR ACTION CAUSED BY BIND	203	3	6G,7G; 4A,15A
SHOP LIGHTS. KENT-MOORE.	211	5	
SHOPMASTER TWO-POST LIFTS	189	3	ALL
SHROUD VENTILATOR GASKET, RIGHT, WATER LEAK.	206	3	6G,7G; 4A,15A
WATER LEAK	206	3	6G,7G; 4A,15A
SIGNS. VALANCE AND REFLECTOR SERVICE DESIGNATIONS.	164	5	
SILVER FINISH BODY HARDWARE, POLISHING	145	2	ALL
SILVER GRAY ENAMEL	199	3	7G, 15A
SLUDGE. CARBON REMOVAL WITH FLUSH MASTER	193	9	ALL
ITS CAUSE, PREVENTION. AND CURE.	197	1	ALL
SOLV-ALL FOR DEGREASING SERVICES	163	6	
SOLENOID. OVERDRIVE, ALTERNATE MAKE.	170	4	5G
RELAY FUSE.	180	2	6G. 14A
SHIELD INTERFERENCE	178	3	6G, 14A
SOUNDING TOOL, MOTOPHONE	195	4	
SOUNDING TOOL, PROB-O-PHONE.	215	4	
SPACER. REAR SPRING TO AXLE.	170	3	M15, M16
SPARK PLUGS. CHAMPION 500 COMPARATOR	206	8	
LIST BY MODELS.	172	1	ALL
REVISION.	134	4	ALL
TERMINAL NUTS	148	11	ALL
SPECIAL CONTROL FOR DISABLED DRIVERS. SERVICE.	190	1 - 7	3G, 6G
SPECIFICATIONS ** SEE UNDER UNIT FOR WHICH SPECIFICATIONS ARE DESIRED			
SPEEDOMETER CABLE, INSTALLATION OF	150	7	ALL
GREASE LEAK AT CABLE	177	1	6G. 14A
PRECAUTION WHEN DISCONNECTING.	132	3	ALL
SPRING, BOLTS. REAR	170	4	4G,5G; 12A, 8C; M5
BUSHING SPACERS FOR HEAVY DUTY USE.	188	4	M15A, M16

REFERENCE	BUL. NO.	PAGE NO.	MODEL
S- CONT'D			
SPRING * CONT'D.			
DATA FOR CHECKING SAG. ETC., FRONT AND REAR,	172	4	3G, 4G, 5G
FRONT, HEAVY DUTY, USE WITH OVERSIZE TIRES .	179	4	SG
FRONT, METAL-TO-METAL CONTACT.	171	2	M15
FRONT, SHACKLE KITS.	215	4	M15A, M16
(FRONT): STIFF DUE TO SHOCK ABSORBER. . . .	203	3	6G, 7G; 14A, 15A
FRONT, UNLOADER HM-925-17-18-19	175	2	6G, 14A
LEAF BEARINGS AND SPREADER TOOLS	142	2	ALL
LEAF SPREADER TOOLS.	142	2	ALL
LUBRICATION OF	147	20	ALL
LUBRICATION OF	163	12	ALL
LUBRICATION.	204	2	7G, 15A
PREVENTIVE MAINTENANCE SUGGESTIONS	182	1	ALL
REAR HANGERS, HEAVY DUTY REAR.	187	2	M15, M16
REAR REBOUND CLIP KIT	193	2	6G, 14A
REAR, REBOUND CLIPS.	209,	1	7G, 15A
REAR, SHACKLE BUSHING REMOVER AND REPLACER .	170	5	ALL
REAR, TO AXLE SPACER	170	3	M15, M16
REAR, U-BOLT NUTS.	203	6	M5
SPRING LEAF (ROTO) BEARINGS.	208	4	
SQUEAK AT OUTER SEAT STOP.	177	5	6G 2-DOOR
SQUEAK, BRAKE.	178	1	6G, 14A
STARTER, INSTALLING PUSH BUTTON.	199	4	M SERIES
LOAD RHEOSTAT E215.	135	8	ALL
MOTOR SWITCH FASTENING CLIPS, NEW	191	1	M SERIES
RING GEAR HEATER, V91	170	5	ALL
STARTER SWITCH, PUSH-BUTTON.	212	3	2R16, 2R17
REMOTE CONTROL	211	5	J2679
STARTING, ENGINE: INFORMATION ON.	153	9	ALL
STEERING ADJUSTMENTS	193	8	14A
ARM BALL BOLT PULLER, J2200	211	5	
BELL CRANK NEEDLE BEARING REMOVER AND REPLACER, J2033	175	2	14A
CAMBER AND TOE-IN	147	12	ALL
CASTER ADJUSTMENT NOT RECOMMENDED	176	2	ALL
CONNECTIONS, LUBRICATION OF	147	20	ALL
KNUCKLE BUSHING AND BEARING INSERTER ADAPTER J1294-4	175	3	6G
KNUCKLE BUSHING AND BEARING REMOVER AND REPLACER J2042.	175	2	14A
KNUCKLE PIN TO UPPER SUPPORT ARM DRIVER J2031.	175	2	6G, 14A
KNUCKLE SUPPORT ARM INSULATOR	170	3	2G-5G
KNUCKLE SUPPORT ARM SPREADER (LARGE END) J2043.	175	2	6G, 14A
KNUCKLE SUPPORT ARM SPREADER (SMALL END) J2044.	175	2	6G, 14A
MAINTENANCE	157	5	ALL
SPECIAL SUPPORT	179	2	14A
TOE-IN.	143	9	ALL
TURNING RADIUS INTERFERENCE	182	2	6G
WHEEL ADJUSTMENT.	186	3	14A
WHEEL PULLER J1594.	130	10	ALL
STEERING SHAKE, FRONT WHEEL AT LOW SPEED	211	1	14A, 15A
STEERING GEAR ARM STUD PLAIN WASHERS	201	4	6G
LUBRICANTS	204	5	
STEERING IDLER LEVER	201	4	6G
STEERING IDLER LEVER BUSHING SERVICE SET, J1621. .	211	5	
STEERING POST COLLAR AND PARKING BRAKE CABLE INTERFERENCE	203	4	7G, 15A
STEERING TIE RODS, TIE ROD ENDS.	215	4	2R SERIES
TOE-IN, ADJUSTMENT.	203	2	6G, 7G; 14A, 15A
STEERING WHEEL, POSITION MARK.	213	1	15A
STORAGE OF CARS BY PRIVATE OWNERS.	142	3	ALL
STRIPPED ENGINE, COMMANDER TYPE, ORDER DATA. . .	204	2	
SHOULD RECEIVE SERVICE ADJUSTMENTS.	197	4	ALL
STUDEBAKER-PHILCO SERVICE GUIDE.	214		
STUDEBAKER SERVICE MAN'S PLEDGE.	167	1	
SUPER-SOAK PARTS WASHER.	208	6	

REFERENCE	BUL.NO.	PAGE NO	MODEL
S-CONT'D			
SUPPORT BEARING ** SEE PROPELLER SHAFT SUPPORT BEARING.			
SWAY BAR ANCHOR BOLTS, INSTALLATION OF	197	5	14AS, 14AY
SYNCHRONIZER RING PROTECTOR MODIFICATION OF TRANSMISSION	201	4	15A
SYNTHETIC TIRES AND TUBES.	166	6	ALL
SYNTHETIC TUBES, REMOUNTING.	156	4	ALL
T			
TAGS, STICKERS, CARDS, PACKAGE COMPARTMENT BOOKLETS IN NEW CARS, TRUCKS.	183	1 - 4	6G, 14A, M SERIES
TENSION WRENCH SPECIFICATIONS.	138	6	ALL
TEMPERATURES, EXCESSIVE ENGINE	152	6	ALL
THERMOLOY, ANTI-FREEZE.	145	3	ALL
THERMOSTAT	159	5	ALL
THROTTLE CONTROL BELL CRANK.	215	3	2R5, 2R10, 2R15, 2R16, 2R17
TIE RODS, TIE ROD ENDS, CHANGES.	215	4	2R SERIES
TIMKEN AXLE SERVICE PROCEDURES	206	6	2R16, 2R17
TIRES.	159	9	ALL
AND TUBES, REMOUNTING.	142	6	ALL
AND TUBES, STUDEBAKER RECOMMENDATIONS FOR STORAGE OF	141	6	ALL
BRANDING EQUIPMENT	142	3	ALL
CONSERVATION OF.	149	13	ALL
CRISS-CROSS TO EQUALIZE WEAR	195	2	ALL
DAMAGE FROM GREASE: CONSERVATION OF TIRES.	148	7	ALL
FACTS.	143	13	ALL
FIRESTONE WARRANTY, MEANING AND PROCEDURE.	171	5	ALL
GUIDE FOR INSPECTING AND CHECKING.	147	13	ALL
INNER TUBES, HOW TO MOUNT.	163	6	ALL
INSTRUCTIONS FOR CHANGING.	142	5	ALL
KEEP PRESSURE GAGES ACCURATE	180	2	ALL
PRESSURES, RECOMMENDED	191	3	6G, 14A
PRESSURES REVISED.	176	1	14A
REGROOVER.	142	4	ALL
REMOVAL OF PROTECTIVE COATING ON WHITE SIDEWALLS.	191	1	ALL
REPOSITIONING AIDS SMOOTH RIDE	193	7	M15A-20
ROTATION	149	2	ALL
STRIKE CLIMATIZER DUCT	173	3	6G
TREDO-GAUGE.	147	11	ALL
USE HEAVY DUTY FRONT SPRINGS WITH OVERSIZE EQUIPMENT.	179	4	6G
TIRE PRESSURES, KEEP CORRECT	208	3	
TIRE REPLACEMENT, NEW TYPE RIMS.	206	6	2R SERIES
TIRE, WHEEL, HUB AND DRUM RUN-OUT SPECIFICATIONS	197	4	6G, 7G; 14A, 15A
TOE-IN.	143	9	ALL
ADJUSTMENT, FRONT WHEEL	203	2	6G, 7G; 14A, 15A
AND CAMBER.	147	12	ALL
TOOLS AND EQUIPMENT CATALOG, KENT-MOORE.	211	5	
CLEAN AND CONVENIENTLY STORED.	164	1	
REQUIRED TO REMOVE AND REMOUNT TIRES	142	5	ALL
SPECIAL REQUIREMENTS	175	2	6G, 14A
TOP, CONVERTIBLE FOLDING, CIRCUIT BREAKER.	207	3	6G, 7G; 14A, 15A
CROSS BRACES, KEEP ADJUSTED	211	1	15AS
TORQUE DATA.	171	3	5G
	193	5	M5, M15, M15A
	193	6	M16
	193	4	M SERIES
TOURING SERVICE CUSTOMERS.	204	1	
TRAFFIC LANE MARKERS	192	4	
TRANSMISSION AND DIFFERENTIAL GEAR LUBRICANTS.	208	5	ALL
CLEARANCE COVER SEAL.	211	5	2R SERIES (4-SPEED)
EQUIPMENT, STANDARD PRODUCTION.	125	4	K SERIES
EXCHANGES	133	2	ALL
EXHAUST LINE NOISE.	180	2	14A
GEAR SHIFTING	191	2	14A
INSPECTION COVER WATER LEAK	206	3	6G, 7G; 14A, 15A

REFERENCE	SUL. NO.	PAGE NO.	MODEL
T-CONT'D.			
TRANSMISSION • CONT'D			
LUBRICANT LEAKAGE	187	4	6G
LUBRICANTS. REVISED SPECIFICATIONS. . .	155	3	ALL
LUBRICATION OF.	147	18	ALL
NEW PART NUMBER	199	3	6G, 7G; 14A, 15A
OVERDRIVE	197	6	M5
OVERDRIVE GOVERNOR OPENING WATER LEAK .	206	2	66.76: 14A, 15A
OVERDRIVE SOLENOID SHIELD INTERFERENCE.	178	3	6G, 14A
REAR FLANGE OIL SEAL DRIVER J2038 . . .	175	2	6G, 14A
REAR OIL SEAL INSTALLING DRIFT C-579 . .	170	5	ALL
REMOTE CONTROL GEARSHIFT LEVER RATTLE .	207	4	7G, 15A
REMOTE CONTROL SHIFT ROD ASSEMBLIES . .	187	4	6G
SHIFT ROD ADJUSTING GAGE J1308-R. . . .	175	2	6G, 14A, M5
SNAP RING PLIERS KMO-630.	211	5	
SYNCHRONIZER RING PROTECTOR MODIFICATION	201	4	15A
THRUST YOKE J2039	175	2	14A, M5
THRUST YOKE J2040	175	2	6G
TREDO-GAUGE.	147	11	ALL
TRIM WEAR, FRONT SEAT CUSHION.	173	3	6G
TRUCK INFORMATION CARD DISCONTINUED. . .	197	6	M SERIES
TRUCK LIFTS, POINTS TO CONSIDER BEFORE PURCHASE.	170	5	M SERIES
OPERATOR'S GUIDE DESCRIBED	183	4	M SERIES
SERIAL. RATING, ETC.	176	1	M5, M 5A, M16
TRUNK (SEE LUGGAGE COMPARTMENT).			
TULIP CREAM FORMULA.	197	3	
TURNING RADIUS INTERFERENCE.	182	2	6G
TWO-POST	189	3	ALL
T W O - S P E E D REAR AXLE SELECTOR VALVE . . .	204	5	M SERIES
U-V			
U-BOLT NUTS. REAR SPRING	203	6	M5
UNDERCOATING EQUIPMENT.	206	7	
UNDERCOATING. KNOCKS-SOUND	206	6	
UNDERSEAL (3M) PROTECTIVE CAR COATING	188	1	ALL
UNIFORMS. SERVICEMEN'S TWILL (UNITOG).	204	5	
UNITOG SERVICE UNIFORMS.	197	7	
UNIVERSAL COVERED SPRING LUBRICATOR.	204	7	
UNIVERSAL JOINT CLAMP J881-A	130	10	ALL
EQUIPPED WITH LUBRICATION FITTING.	148	11	26-46: 10A-12A: 6C-8C
FRONT, LUBRICATION OF.	164	3	ALL
LUBRICATION. FRONT	164	3	ALL
LUBRICATION OF	147	17	ALL
REPACKING AND REASSEMBLY OF.	136	4	ALL
USE LOW PRESSURE ONLY IN LUBRICATING	197	5	ALL
USE LOW PRESSURE ONLY IN LUBRICATING UNIVERSAL JOINT	197	5	ALL
UPHOLSTERY, CARE OF.	147	24	ALL
CLEANER.	128	3	ALL
FRONT SEAT TEARING AT BOTTOM OF PANEL. . .	189	2	66, 14A
UTILITY PULLER SET, ADDITION TO.	137	7	46
V91 STARTER RING GEAR HEATER	170	5	ALL
VACUUM BOOSTER. CHECK VALVE ASSEMBLY	179	4	M SERIES
	193	3	6G, 14A; M5, M16
	195	2	6G, 14A
EQUIPMENT.	206	5	6G, 7G
INSTALLATION OF ON CERTAIN M5 AND M15A TRUCKS.	200	2	M5, M15A
VACUUM-FUEL PUMP INSTALLATION.	208	6	7G
REPAIR KITS	206	5	7G, 15A, 2R SERIES
TOOLS	203	8	15A
VACUUM POWER BRAKE AND CLUTCH CONTROLS. SERVICE ADJUSTMENTS FOR.	190	1-7	3G-6G
VACUUM SHIFT REAR AXLE. HYPOID TYPE. TWO-SPEED	189	2	M16
VAL-LITE SIGNS (KENT-MOORE).	213	2	
VALVES...	159	8	ALL
LIFTERS AND ADJUSTING SCREWS.	188	2	6G, M5, M15A
STEM GUIDE REMOVER AND REPLACER. J2034.	175	2	6G, 14A, M SERIES
TAPPET CLEARANCE. IMPROPERLY ADJUSTED	160	8	ALL
IMPROPERLY SEATED	160	8	ALL

S E R V I C E B U L L E T I N

REFERENCE	BUL. NO.	PAGE NO.	MODEL
U-V CONT'D.			
VALVES * CONT'D.			
MANIFOLD HEAT RISER, FREEING.	148	10	ALL
VALVE SPRING OIL BAFFLES CHAMPION ENGINES.	209	1	
VALVE TAPPET ADJUSTING GAGES	203	7	ALL
VAPOR LOCK	172	7	6G
RETURN PARTS FOR CLAIMS CREDIT.	176	1	6G
VARSITY MAROON METALLIC BAKING ENAMEL.	203	2	7G, 15A
VEHICLE MAINTENANCE RELEASE. ODT	153	6	ALL
VEHICLES. REMOVING FROM STORAGE.	141	5	ALL
VELVET BLACK PAINT FORMULA	197	3	
VENTILATOR GLASS BREAKAGE AND HARD CLOSING.			
FRONT DOOR	142	7	4G, 12A, 8C
VENTILATORS AND DOOR WINDOWS. WATER LEAKS IN	204	4	14AY, 15AY
VISCOSITY, ENGINE OIL.	215	1	ALL
W			
WALKER ELECTRIC LIFT	213	2	
W969. TWO-SPEED REAR AXLE TAG.	183	2	M SERIES SO EQUIPPED
W11031. WARNING, WATER ONLY	183	2	6G 14A, M SERIES
W1073. WARNING, ANTI-FREEZE IN NEW CAR	183	2	6G, 14A, M SERIES
W1189. DO NOT START ENGINE	183	2	6G, 14A, M SERIES
WARRANTY. BATTERY. REGISTRATION CARD REQUIRED.	183	3	6G, 14A, M SERIES
CLOCK, BORG.	175	1	ALL
PHILCO REGISTRATION TAG REQUIRED FOR			
WARRANTY SERVICE	183	3	6G, 14A, M SERIES
RADIO, FILL OUT TAG.	179	1	ALL
TIRE MANUFACTURERS' STANDARD	155	8	ALL
GENERAL.	198	1-7	6G, 7G; 14A, 15A
WASHING CAR (OAKITE No. 70).	209	4	
WATER. DUST. AND AIR LEAKS	198		
CONVERTIBLES.	201	3	6G, 14A
WATER LEAKS. DOOR WINDOWS AND VENTILATORS.	204	4	14AY, 15AY
DRIVER'S COMPARTMENT.	206	2	6G, 7G; 14A, 15A
TOP AND BOTTOM OF DOORS	198	2	6G
TOP HEADER.	207	5	7G, 15A
TRUNK.	198	7	6G
WINDOWS. REAR QUARTER	135	5	11A, 7C
WATER PUMP GREASE CUPS. SAVE OLD	191	1	ALL
INLET HOSE REINFORCING SPRING	170	4	M16
REPAIR KIT (CHAMPION)	164	4	2G-4G
WEATHERSEALS. DOOR OPENING REAR (CONVERTIBLES)	208	1	7G, 15A
WEATHERSTRIP, DOOR OPENING. LEAK AT.	206	2	6G, 7G; 14A, 15A
DOOR OPENING (CONVERTIBLES).	207	6	7G, 15A
INSTALLATION	124	4	ALL
WET (OIL BATH) AIR CLEANER, SERVICE INSTRUCTIONS	169	2	ALL
WHEEL ALIGNER. BEANS VISUAL LINER	206	8	
ALIGNMENT.	143	9	ALL
ALIGNMENT.	191	9	ALL
BALANCE.	143	7	ALL
BALANCE. DYNAMIC	147	13	ALL
BALANCE. STATIC.	147	12	ALL
BALANCE. WEIGHTS	128	3	ALL
BALANCERS DESCRIBED.	197	8	
BALANCING.	144	8	ALL
BEARING. LUBRICATION OF.	147	17	ALL
CASTER ADJUSTMENT NOT RECOMMENDED.	176	2	ALL
CYLINDER, SERVICING.	162	14	ALL
DISCS. CLEANING. WHITEWALL PLASTIC	172	2	5G, 6G, 14A
PULLER. J1594.	130	10	ALL
REAR. RUN-OUT.	172	5	ALL
REAR. GREASE SEAL.	215	4	2R10
RUN-OUT SPECIFICATIONS	197	4	6G, 7G; 14A, 15A
SOCKET WRENCH.	180	1	6G, 14A
TURNING RADIUS INTERFERENCE STEERING TIE ROD			
ASSEMBLY	182	2	6G
WHEEL BEARING, NUT WRENCH 2-3/8" HEX., J-2975.	213	2	
NUT WRENCH 2- 7/8" HEX., KMO-570	213	2	
WRENCH. REAR. ORDERING.	197	6	M15A, M16

REFERENCE	BUL.NO.	PAGE NO.	MODEL
W-Cont'd.			
WHITE S DEWALL TIRES. REMOVAL OF PROTECTIVE			
COATING ON	191	1	
" WHITEWALL " PLASTIC WHEEL DISCS. CLEANING.	172	2	5G. 6G. 14A
WILLARD BATTERY. ADJUSTMENT POLICY. GUARANTEE, AND			
REGISTRATION.	127	2	ALL
FAST CHARGER.	137	8	ALL
GUARANTEE POLICY.	201	1	
REGISTRATION CARD DESCRIBED	183	3	6G. 14A
WILSON. DON O. . . "LET'S RESTORE SERVICE ROUTINES" . . .	189	1	
WIND NOISE AT BRAKE PEDAL.	132	2	ALL
AT CLUTCH PEDAL	132	2	ALL
WINDOW. BIND IN DOOR LOWER RUN	206	5	66.76: 14A. 15A
BIND (CONVERTIBLE) IN DOOR	207	4	7G. 15A
GLASS REPLACEMENT. CLAIMS COVERING			
ONE-PIECE CURVED	139	2	36.46; 11A. 12A: 7C.8C
REVEAL MOULDING CLIPS.	136	2	46. 12A. 8C
WINDSHIELD. CENTER STRIPS, WATER LEAKS AT.	128	3	ALL
LEAK AT RUBBER WEATHERSTRIP.	198	5	6G. 14A
WINDSHIELD WIPER HOSE REPAIRS.	148	7	ALL
DUAL. SYNCHRONIZING VACUUM TYPE	163	3	ALL
OIL PUMP VACUUM BOOSTER	179	4	M SERIES
OIL PUMP VACUUM BOOSTER	195	2	6G. 14A
OIL PUMP VACUUM BOOSTER ASSEMBLY.	193	3	66. 14A: M5.MI6
VACUUM BOOSTER EQUIPMENT.	206	5	6G,7G
WIRES CONTACTING GEARSHIFT MECHANISM	173	2	6G
WRENCHES AND TOOLS, SPECIAL.	138	8	ALL
Z			
ZENITH CARBURETOR.	203	5	M5. M15A
CENTRAL DISTRIBUTORS.	199	7	M SERIES