

# Studebaker SERVICE BULLETIN

JULY

NO. 241A



1950

## CUMULATIVE SERVICE BULLETIN INDEX COVERING BULLETINS ISSUED FROM MARCH 1946 TO JUNE 1950 NUMBERS 169 TO 241 INCLUSIVE

This Service Bulletin Index lists articles which appeared in Service Bulletin Nos. 169 through 241 covering both passenger cars and trucks. It should be filed in a binder containing those issues of the Service Bulletin. Service Bulletin Nos. 124 through 168 should be filed with Index Bulletin No. 215A in another binder.

The index is compiled alphabetically by article title or subject, and liberally cross-referenced.

Immediately following the reference title the Service Bulletin number and the page on which the article appears are given; also, the vehicle models to which the article applies. Model references are always given inclusively so that "5G-9G" indicates that the article applies to the 5G (1946), 6G (1947), 7G (1948), 8G (1949) and 9G (1950) Champions. In the reference to models, the word "All" means the article refers to all of the models listed in the following paragraph.

Individual model numbers refer to the following vehicles:

Champions		Commanders		Trucks	
5G	1946	None	1946		1946
6G	1947	14A	1947	M Ser IES	1947
7G	1948	15A	1948		1948
8G	1949	16A	1949	R Ser IES	1949
9G	1950	17A	1950		1950

In such cases where an article refers to models of earlier production than those listed above, the earlier model designation is also given.

In each future year, that YEAR'S accumulation of Service Bulletin material will be added to the Index and the oldest YEAR'S material dropped, thus giving an index always covering the last five production models at the time of publication.

REFERENCE	BUL. NO.	'AGE NO.	MODEL
<b>A</b>			
ACCELERATOR-TO-TRANSMISSION CONTROL LINKAGE			
ADJUSTMENT ■ AUTOMATIC DRIVE . . . . .	241	2	17A
ACCURATE DIAGNOSIS AIDED BY MOTOPHONE. . . . .	195	4	
ACID COOLING SYSTEM. . . . .	208	3	
ADAPTER AND SOCKETS FOR ALLEN TYPE SCREW REMOVAL . . . . .	189	2	6G. 14A
ADJUSTMENT, BRAKE, SERVICE . . . . .	195	1	6G. 14A
SEAT CUSHION (FOR DRIVER'S HEIGHT). . . . .	193	9	14A. 14AY
STEERING WHEEL. . . . .	186	3	14A
STEERING WHEEL. . . . .	193	9	14A. 14AY
WHEEL . . . . .	191	2	M SERIES
ADJUSTMENT POLICY, STRIPPED ENGINE . . . . .	197	4	
ADJUSTO-AIR SEAT CUSHION . . . . .	218	7	2R SERIES
ADVANTAGES AND OPERATION OF OVERDRIVE. . . . .	193	2	
AERO BLUE ENAMEL FORMULA . . . . .	237	2	9G. 7A
AIR CLEANER, EFFECT OF OIL LEVEL ON GASOLINE			
CONSUMPTION . . . . .	230	2	9G. 7A
HOW TO PREPARE FOR USE. . . . .	228	1	9G. 7A
MAINTENANCE . . . . .	212	1	
OPERATION (OIL BATH). . . . .	215	2	
SERVICE (OIL WETTED TYPE) . . . . .	169	2	
AIR LEAKS ■ CONVERTIBLES . . . . .	201	3	6G. 4A
2R SERIES . . . . .	218	8	
SEALING . . . . .	228	3	2R SERIES
ALIGNING EQUIPMENT, BEAN'S VISUALINER. . . . .	206	8	
ALLEN ELECTRIC, SERVICE EQUIPMENT. . . . .	216	6	
TESTING EQUIPMENT (VARIOUS) . . . . .	203	8	
ALLEN TYPE SCREW REMOVAL, ADAPTER AND SOCKETS. . . . .	189	2	6G. 14A
ANTENNA, PADDER ADJUSTMENT . . . . .	220	2	8G. 16A
SERVICE . . . . .	214	4	
ANTIFREEZE, ALCOHOL BASE . . . . .	199	1	
IN FACTORY-SHIPED VEHICLES . . . . .	213	1	7G. 8G; 15A 16A
OF FOUR MAJOR TYPES, TWO ARE SAFE . . . . .	199	1	
WARNING TAG 11075 . . . . .	183	2	
AQUA GREEN FORMULA . . . . .	230	2	9G. 17A
ARMATURE LATHE, JOHNSON. . . . .	203	8	
ARO LUBRICATION EQUIPMENT. . . . .	191	3	
ASH RECEIVER, LOOSE. . . . .	187	3	14AY
RATTLE ELIMINATED . . . . .	235	2	9G. 17A
AUTHORIZED PHILCO SERVICE STATION LIST . . . . .	237	6	
AUTOMATIC COOLING SYSTEM CLEANER, BRADY . . . . .	206	7	
AUTOMATIC DRIVE, ACCELERATOR-TO-TRANSMISSION CONTROL			
LINKAGE ADJUSTMENT. . . . .	240	2	17A
BACK-UP LIGHTS. . . . .	240	1	17A
CRATE IN ORIGINAL CONTAINERS FOR SAFE RETURN TO			
FACTORY . . . . .	240	1	17A
PULLBACK SPRING . . . . .	240	2	17A
TOWING INSTRUCTIONS . . . . .	240	1	17A
AXLE, FRONT, NEW KITS. . . . .	197	6	M15A
AXLE, REAR, DIFFERENTIAL CLEANER . . . . .	228	3	
DIFFERENTIAL GEAR KITS. . . . .	228	1	6G-8G; 14A-16A; 2R5
PINION SHAFT BEARING OIL SEAL DRIVER J2037. . . . .	175	2	6G. 14A. M5
RATIO CHANGE. . . . .	203	6	M15A
SELECTOR VALVE (2-SPEED) . . . . .	204	5	M SERIES
SHAFT OUTER SEAL LOCATOR J2027. . . . .	175	2	6G
SHAFT OUTER SEAL LOCATOR J2032. . . . .	175	3	14A. M5
SINGLE SPEED, PROPELLER SHAFT VIBRATION . . . . .	201	2	M15A. M16
SPACER, REAR SPRING TO. . . . .	170	3	M15. M16
TAG W969 (2-SPEED) . . . . .	183	2	M SERIES
TIMKEN, SERVICE PROCEDURES . . . . .	206	6	2R16. 2R17
2-SPEED REMOVAL TOOL. . . . .	226	2	2R SERIES
VACUUM SHIFT (2-SPEED) . . . . .	171	3	M16
VENT (2-SPEED), LUBRICANT LEAK. . . . .	200	2	M SERIES
WIDE TREAD. . . . .	203	6	M16
<b>B</b>			
BACK-UP LIGHTS FOR AUTOMATIC TRANSMISSIONS . . . . .	240	1	17A
BAKING OVENS (OURABAKE) . . . . .	233	3	

REFERENCE	SUL.NO.	PAGE NO.	MODEL
<b>B-Cont'd.</b>			
BALSAM GREEN METALLIC PAINT FORMULA . . . . .	197	3	6G, 7G; 14A, 15A
BATTERY, CHARGER AND ANALYZER, HARTMAN . . . . .	189	4	
CRADLE REINFORCED . . . . .	226	1	2R SERIES
GUARANTEE POLICY, WILLARD . . . . .	201	1	
KEEP FULLY CHARGED IN STORAGE . . . . .	235	1	
PREVENTIVE MAINTENANCE CHECKS . . . . .	171	1	
TIPS FOR COLD WEATHER OPERATION . . . . .	201	3	
WILLARD REGISTRATION CARD . . . . .	183	3	6G, 14A
BEAN, JOHN, CAR WASHER (FUTURFORM) . . . . .	235	5	
VISUALINER . . . . .	206	8	
BEARING, CLUTCH, pilot REMOVER J164, ALL BRONZE BEARING . . . . .	170	5	
BEARING, ENGINE, CONNECTING ROD-AND BEARING INSERTS, . . . . .	178	2	M SERIES
CONNECTING ROD AND MAIN, CLEARANCE CHECKS . . . . .	187	2	6G, 14A
CRANKSHAFT MAIN . . . . .	172	1	2G-5G, 12A M5, M15, M16
INSERTS IN SERVICE ENGINES . . . . .	179	2	3G-6G; 3A, AA
PLASTIGAGE MEASUREMENT METHOD . . . . .	199	5	
BEARING, SUPPORT, PROPELLER SHAFT . . . . .	195	4	M15-28, M1 A, 28, M16
BEARING WRENCH, REAR WHEEL, ORDERING . . . . .	197	6	M15A, M16
BELL CRANK, THROTTLE CONTROL . . . . .	215	3	2R5, 2R10, 2R15
INTERFERENCE WITH CYLINDER HEAD CAPSCREW . . . . .	215	3	2R16, 2R17
BEWARE PETROLEUM BASE HYDRAULIC FLUID . . . . .	186	2	
BINDING FRONT SHOCK ABSORBER ARM CAUSING STIFF SPRING . . . . .	203	3	6G, 7G; 14A, 15A
BLACK CHERRY FORMULA . . . . .	230	2	9G, 17A
30DY, DOOR (FRONT) RATTLE IN REMOTE CONTROL LINK . . . . .	189	2	3G, 14A
DOOR REPAIR PANELS . . . . .	237	1	ALL PASSENGER
DRAINS, LOCATION OF . . . . .	172	3	6g 14A
HOOD LOCK RELEASE, SERVICING . . . . .	191	2	6G 14A
LEAKS, SERVICE INFORMATION . . . . .	181	1-4	6G 14A
LICENSE PLATE BRACKET, FRONT, PROPER MOUNTING . . . . .	186	1	6G
LUGGAGE COMPARTMENT BOLT CAP . . . . .	177	3	6G 14A
SEALER GUN . . . . .	226	4	
SEAT (FRONT) UPHOLSTERY TORN AT BOTTOM OF PANEL . . . . .	189	2	6G, 14A
UNDERCOATING, KNOCKS-SOUND . . . . .	206	7	
B O R C L O C K W A R R A N T Y, S E R V I C E P R O V I S I O N S . . . . .	241	5	
BOULEVARD GRAY ENAMEL . . . . .	199	3	7G 15A
BRADY AUTOMATIC COOLING SYSTEM CLEANER . . . . .	206	7	
BRAKE BOOSTER, HYDROVAC . . . . .	199	5	M16
HY-POWER DIAGNOSIS CHART . . . . .	229	7	2R16A, 2R16A
BRAKE, LATHE, VAN NORMAN . . . . .	223	4	
BRAKES, PARKING, ANTIRATTLE FOR RELEASE BUTTON . . . . .	225	2	8G, 16A
COVER FASTENER, LEAK AT . . . . .	198	1	6G 14A
RATCHET SPRING REPLACEMENT . . . . .	197	3	6G 14A
BRAKES, SERVICE, ADJUSTMENT . . . . .	195	1	6G 14A
BACKING PLATE (REAR) INSTALLATION . . . . .	177	1	A15, M15A, M16
FLUID, BEWARE PETROLEUM BASE . . . . .	186	2	
HILL HOLDER, INSTALLATION . . . . .	180	1	M SERIES
HILL HOLDER REPAIR KIT . . . . .	215	2	
HY-POWER BRAKE BOOSTER UNIT . . . . .	229	4	2R16A, 2R17A
INTERFERENCE RIGHT REAR PIPE-EXHAUST TAIL PIPE . . . . .	235	3	3G, 17A
LININGS, FRONT AND REAR MUST BE SAME TYPE . . . . .	179	3	
MASTER CYLINDER, PIPE CLIP . . . . .	208	6	2R SERIES
MASTER CYLINDER, WATER LEAK AT HOLE COVER . . . . .	206	3	6G, 7G; 14A, 15A
PEDAL COVER WATER LEAK . . . . .	206	3	6G, 7G; 14A, 15A
PEDAL FREE TRAVEL . . . . .	203	2	6G, 7G; 14A, 15A
PEDAL LENGTHENED, BOOSTER EQUIPPED . . . . .	193	3	M16
PEDAL RETURN, POSITIVE . . . . .	188	1	6G 14A
PEDAL SPLASH SHIELD . . . . .	188	2	6G, 14A, 14AY
PEDAL SPLASH SHIELD (AND CLUTCH) . . . . .	222	2	6G, 7G; 14A, 15A
SQUEAK AT SELF-ADJUSTING PLUG . . . . .	234	6	6G-9G; 14A-17A; 2R5
TEE TO AXLE HOUSING (REAR), CAPSCREW VENTED . . . . .	212	4	2R 10
VACUUM POWER AND CLUTCH CONTROLS, SERVICE ADJUSTMENTS FOR . . . . .	190	1-7	36-66
BULLETIN BOARD FOR SHOP USE . . . . .	216	6	
BULLETIN, SERVICE, HOW TO USE . . . . .	205	1-4	
REFERENCE PAGES, IN YOUR SHOP MANUALS . . . . .	239	2	

REFERENCE	BUL. NO.	PAGE NO.	MODEL
<b>C</b>			
C579 TRANSMISSION REAR OIL SEAL INSTALLING DRIFT . . . . .	170	5	
CAB BODY, AUXILIARY STEP . . . . .	229	2	2R16-16
BACK PANEL REINFORCEMENT . . . . .	209	3	2R SERIES
CAMBER . . . . .	217	3	6G-8G: 14A-16A
ADJUSTMENT . . . . .	204	5	6G.7G: 14A, 15A
CAMSHAFT BEARING SETS . . . . .	222	5	ALL
CANOPY TOP SHRINKAGE COMPLAINTS . . . . .	191	2	M5, M15A
CARBURETOR, ACCELERATING PUMP PISTON AND SPRINGS . . . . .	230	1	14A-16A
ADJUSTMENTS TO . . . . .	230	2	17A
CARTER VE 715S . . . . .	222	4	8G
FLOAT LEVEL GAGE . . . . .	206	6	2R SERIES
GASKET . . . . .	226	1	2R SERIES
HIGH ALTITUDE METERING RODS . . . . .	176	2	6G
1950 COMMANDER DATA . . . . .	227	5	17A
PARTS AND CYLINDER HEAD FOR HIGH ALTITUDES . . . . .	188	2	8A-14A
SPEED CONTROL DISCONTINUED . . . . .	235	4	9G.17A
TOOL KITS J505-SCT . . . . .	170	5	
VACUUM STEP-UP JET . . . . .	229	2	2R16A, 2R17A
ZENITH . . . . .	203	5	M5, M15A
CARBURETOR AIR CLEANER, OIL BATH, EFFECT OF OIL LEVEL ON GASOLINE CONSUMPTION . . . . .	230	2	9G.17A
OPERATION (OIL WETTED TYPE) . . . . .	215	2	
PREPARE FOR USE . . . . .	228	1	9G, 17A
SERVICE INSTRUCTIONS (OIL WETTED TYPE) . . . . .	169	2	
CARPETS AND MATS, INSTALLATION . . . . .	234	2	9G, 17A
CARTER VE 715S CARBURETOR . . . . .	222	4	8G
CASTER . . . . .	217	3	6G-9G: 14A-16A
ADJUSTMENT NOT RECOMMENDED . . . . .	176	2	
SHIMS . . . . .	223	3	2R5
SPECIFICATIONS REVISED . . . . .	235	3	9G.17A
CAUTION PLATE CHANGE, LOCATION OF SERIAL NUMBERS . . . . .	176	1	M5, M15A, M16
CHAMPION SERIES 500 SPARK PLUG TESTER, CLEANER . . . . .	206	8	
CHAMPION TIRE REGROOVER . . . . .	235	5	
CHASSIS, SPRING LUBRICATION . . . . .	204	2	
STANDS USED WITH 2-POST LIFTS . . . . .	191	2	
CHECK INSTALLATION OF CANOPY TOPS . . . . .	191	2	M5, M15A, M16
CHECKING CYLINDER DISTORTION . . . . .	208	1	
CHEROKEE RED ENAMEL . . . . .	209	2	2R SERIES
CHROME HEADLAMP RIMS . . . . .	240	3	17A
CHROME PLATING PROTECTION . . . . .	172	5	
CHROME YELLOW ENAMEL . . . . .	209	2	2R SERIES
CHUCKLE, STEERING STRAIGHT AHEAD . . . . .	217	5	6G-8G; 14A-16A
WHEN TURNING . . . . .	217	5	6G-8G; 14A-16A
CIRCUIT BREAKER FOR CONVERTIBLE TOPS . . . . .	207	3	6GS-7GS; 14AS, 15a5
CLAIMS, CREDIT REFUSED ON DAMAGED REAR AXLE ASSEMBLIES . . . . .	197	6	
GLASS . . . . .	175	1	
IDENTIFYING SHOCK ABSORBERS FOR EXCHANGE . . . . .	178	4	
PACKING PARTS FOR SHIPMENT . . . . .	176	3	
RADIATOR CORE, SHOW SERIAL NUMBER . . . . .	179	1	
WHY SETTLEMENTS BOG DOWN . . . . .	240	3	
CLAYBORNE ENGINE STANDS (KMO) . . . . .	193	10	
CLAYTON VEHICLE ANALYZER . . . . .	235	6	
CLEANER, VIBROMATIC AIR OPERATED . . . . .	225	2	
CLIMATIZER, CONTROL VALVE . . . . .	188	2	6G, 14A
CONTROL VALVE CABLE, DEADENING SOUND IN NEW TYPE . . . . .	182	2	6G
CONTROL VALVE CABLE REDUCES NOISE TRANSMITTAL . . . . .	186	3	6G
DEFROSTER AIR DISTRIBUTION . . . . .	177	2	6G, 14A
DEFROSTER AIR DISTRIBUTION, CHECK FOR . . . . .	179	4	6G, 14A
DEFROSTER INSTALLATION WITH AC-1392 . . . . .	220	1	8G, 16A
DUCT, INTERFERENCE WITH TIRE . . . . .	173	3	6G
FILTER REMOVED IN PRODUCTION . . . . .	182	1	6G, 14A
HEAT FLOW, INCREASE . . . . .	179	3	6G, 14A
HEAT FLOW INTERFERENCE . . . . .	203	4	7 G, 15A
HEAVY DUTY CORE IDENTIFICATION . . . . .	237	4	2R
HOSE INSTALLATION . . . . .	234	1	9G.17A
HOSE INSTALLATION . . . . .	236	2	ALL

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>C.Contfd .</b>			
CLIMATIZER ■ CONT'D.			
HOW TO GET BEST RESULTS . . . . .	179	3	6G, 14A
MOTOR AND CORE REMOVAL . . . . .	218	6	2R SERIES
CLINCHING TOOL. REAR WHEEL BEARING LOCK NUT J2827. . .	213	2	
CLOCK SERVICE. BORGSTATIONS . . . . .	207	6	
BORGSTATIONS (ADDITIONAL). . . . .	218	2	
BORGSTATIONS (ADDITIONAL) . . . . .	223	2	
CLOVER GREEN ENAMEL . . . . .	209	2	2R SERIES
CLUTCH. CHATTER ELIMINATION. . . . .	239	3	6G, 7G, 8G, 9G
CONTROLS AND VACUUM POWER BRAKE. SERVICE			
ADJUSTMENTS FOR . . . . .	190	1-7	3G-6G
DRIVEN PLATE ASSEMBLY . . . . .	216	4	2R5, 2R10
DRIVEN PLATE FACING . . . . .	223	3	M16, 2R16, 2R17
GREASE LEAK AT RELEASE SHAFT RETAINER . . . . .	234	7	6G-9G; 14A-17A
HOUSING . . . . .	218	6	2R SERIES
HOUSING VENTILATION . . . . .	187	3	14A
HOUSING. WATER LEAK AT INSPECTION DOOR. . . . .	205	2	6G, 7G; 14A, 15A
LINKAGE. HEAVY DUTY . . . . .	178	2	M5, M15, M15A
OPERATING SHAFT RATTLE. . . . .	179	1	6G
OPERATING SHAFT RATTLE. . . . .	234	2	6G-9G; 14A-17A
PEDAL PULLBACK SPRING REMOVER . . . . .	193	4	6G, 14A, 14AS
PEDAL SPLASH SHIELD (AND BRAKE) . . . . .	222	2	6G, 7G; 14A, 15A
PILOT BEARING REMOVER. J164 . . . . .	170	5	ALL BRONZE BEARING
PRESSURE PLATE HOLDING CLIPS. . . . .	220	1	5C-8C; M16; 2R16, 2R16A, 2R17, 2R17A
PRESSURE PLATE SPRING SPECIFICATIONS. . . . .	203	5	
RELEASE BEARING COLLAR SPRING . . . . .	230	2	6G-8G; 14A-16A
RELEASE SHAFT. FREEING. . . . .	187	4	6G, 14A
RELEASE SHAFT GREASE RETAINER . . . . .	215	2	7G, 15A; 2R SERIES
COLD WEATHER. BATTERY TIPS . . . . .	201	3	
COLOR FORMULAS. ENAMEL . . . . .	177	3	6G, 14A
ENAMEL . . . . .	197	3	6G, 7G; 14A, 15A
ENAMEL . . . . .	203	2	7G, 15A
ENAMEL . . . . .	203	4	M SERIES
ENAMEL . . . . .	209	2	2R SERIES
ENAMEL . . . . .	218	1	8G, 15A
ENAMEL . . . . .	230	2	9G, 17A
ENAMEL . . . . .	239	4	2R SERIES
COMANCHE RED FORMULA . . . . .	230	2	9 G 17A
COMMANDER CYLINDER HEADS AND GASKETS . . . . .	241	2	
COMMANDER ENGINE. STRIPPED . . . . .	224	1	7A-15A: K5, K15, 15, M16, 2R16, 2R17
STRIPPED. ORDER DATA . . . . .	204	2	
TURNING PLUG. . . . .	203	4	7A-15A
COMMANDER TIRE PRESSURES . . . . .	176	1	14A
COMPANION FLANGE. HOLDING TOOL J2035 . . . . .	175	2	6G, 14A: M SERIES
PULLER J2046. . . . .	175	2	6G, 14A: M SERIES
CONNECTING ROD. AND MAIN BEARING CLEARANCE CHECKS. .	187	2	6G, 14A
AND BEARING INSERTS . . . . .	178	2	M SERIES
BEARING INSERTS .001"UNDERSIZE . . . . .	186	3	6 G 14A
CONVERTIBLE. DOOR OPENING WEATHERSTRIP . . . . .	207	6	7GS, 15AS
TOP CIRCUIT BREAKER . . . . .	207	3	6G, 7G; 14A, 15A
TOP HEADER. LOCK SHAFT REPLACEMENT. . . . .	216	4	7G, 1 5 A
TOP HEADER. WATER LEAKS . . . . .	207	5	7g5, 15AS
COOLING SYSTEM. ACID CONDITION CORRECTION. . . . .	208	3	
FAN DRIVER PULLEY. SMALLER. . . . .	178	1	M5, M15, M15A
LEAK AT WATER PUMP GASKET . . . . .	230	1	6G-8G
RADIATOR CORE SERIAL NUMBER LOCATION. . . . .	179	1	6G, 14A
RUST INHIBITOR TAG. . . . .	172	2	
SURGE TANK INSTALLATION . . . . .	218	4	6G, 7G; 2R SERIES
WARNING TAG W1031 . . . . .	183	2	6G, 14A, M SERIES
WARNING TAG w1075 . . . . .	183	2	6G, 14A, M SERIES
WATER PUMP GREASE CUPS. SAVE. . . . .	191	1	
CORE. RADIATOR. REPAIRS DURING WARRANTY. . . . .	220	1	8G, 16A
CORNWELL SERVICE TOOLS . . . . .	223	4	
COWL. OPENING INTO FRONT SEAT COMPARTMENT. . . . .	198	4	6G, 14A
OUTER SCREEN OF LEFT VENTILATOR NO LONGER USED. . . . .	235	2	9G, 17A
SIDE PANEL WATER LEAK . . . . .	206	2	6G, 7G; 14A, 15A
CRADLE. BATTERY ■ REINFORCED . . . . .	226	1	2R SERIES

REFERENCE	BUL. NO.	'AGE NO.	MODEL
<b>C-Cont'd.</b>			
CRANES, HYDRAULIC PORTABLE (STRATTON) . . . . .	228	3	
CRANKCASE, BREATHER KIT FOR COMMANDER ENGINES. . . . .	235	2	9G, 17A
SLUDGE, CAUSE, PREVENTION, CURE. . . . .	231	2	
CRANKSHAFT, BEARINGS (MAIN) . . . . .	172	1	2G-5G; 12A: M5.M15-M16
OIL LEAK AT FRONT END . . . . .	240	2	9G: 17A
OIL PAN BAFFLE INTERFERENCE . . . . .	234	7	9G: 2R5, 2R10, 2R15
REAR BEARING OIL SEAL . . . . .	216	2	6G-8G: 14A-16A: M SERIES: 2R SERIES
CRATE AUTOMATIC TRANSMISSION IN ORIGINAL CONTAINERS FOR SAFE RETURN TO FACTORY. . . . .	240	1	
CRISS-CROSS TIRES TO EQUALIZE WEAR . . . . .	195	2	
CUBAN TAN ENAMEL . . . . .	209	2	2R SERIES
CUMBERLAND BLUE ENAMEL . . . . .	197	3	6G, 14A
CUMBERLAND BLUE No. 2 ENAMEL . . . . .	203	3	7G, 15A
CURRENT AND VOLTAGE REGULATOR. . . . .	227	2	17A
CYLINDER BLOCK, DEFINED. . . . .	240	3	
DOWEL PILOT HOLES LOCATION. . . . .	197	4	6G, 7G; 14A, 15A
14A USED IN 15A CHASSIS . . . . .	203	2	15A
CYLINDER DISTORTION. . . . .	208	1	
CYLINDER HEAD, CAP SCREW TIGHTENING PROCEDURE. . . . .	187	1	ALL
GASKETS, COMMANDER . . . . .	241	2	
GASKET INSTALLATION . . . . .	239	5	2R SERIES
GASKETS, KEEP TIGHT . . . . .	172	1	ALL
HIGH ALTITUDE . . . . .	188	2	8A-14A
PILOTS. . . . .	195	2	14A, M16
<b>D</b>			
DAMAGED REAR AXLES DO NOT MERIT FULL CLAIMS. . . . .	197	6	M15A, M16
DASH TIE ROD TO RADIATOR CORE SUPPORT. . . . .	193	4	M16
DEALER'S SERVICE POLICY, DESCRIBED . . . . .	183	3	
REVISED . . . . .	193	1	
DEE-TEE VAPOR CLEANER. . . . .	228	3	
DEFINITION OF TERMS "CYLINDER BLOCK", "FITTED BLOCK", "STRIPPED ENGINE ASSEMBLY". . . . .	240	3	
DEFROSTER, AIR DISTRIBUTION. . . . .	177	2	6G, 14A
AIR DISTRIBUTION CHECKS . . . . .	179	4	6G, 14A
INSTALLATION WITH AC-1392 CLIMATIZER. . . . .	220	1	8G, 16A
DEMONSTRATORS, PREPARATION, CARE, AND MAINTENANCE OF DETERGENT ENGINE OILS. . . . .	232	1-4	
DEVILBISS PAINT SHOPS. . . . .	204	6	
DIAGNOSIS, OVERDRIVE CHART . . . . .	212	4	6G, 7G; 14A, 15A
DIFFERENTIAL AND TRANSMISSION LUBRICANTS CLEANER (DEE-TEE) . . . . .	208	5	
GEAR KITS . . . . .	228	3	
DIRECTION SIGNAL AND FOG LAMP, WIRING HARNESS EQUIPMENT . . . . .	228	1	6G-8G; 14A-16A: 2R5
DIRECTION SIGNAL AND FOG LAMP, WIRING HARNESS EQUIPMENT . . . . .		3	9G, 17A
DISPLAY CORPORATION MERCHANDISER DESK. . . . .	235	5	
DISTRIBUTOR, NEW MODEL INFORMATION, ADDITIONAL NEW MODEL INFORMATION . . . . .	230	1	9G
DISTRIBUTOR, NEW MODEL INFORMATION. . . . .	227	1	9G
DOLPHIN EYEBROW SEALER, SYMBOLS . . . . .	181	2	
DO NOT DRIVE OVER 25 MPH, FORM W1073 . . . . .	183	2	M SERIES
DO NOT START ENGINE, FORM W1189. . . . .	183	2	6G, 14A, M SERIES
DOOR, DRAIN, DUST LEAK AT. . . . .	198	1	6G, 14A
FRONT, GLASS RATTLES. . . . .	173	1	6G
FRONT, REMOTE CONTROL ADJUSTING LINK, RATTLE. . . . .	189	2	6G, 14A
HANDLE DRAIN. . . . .	182	3	6G
LEAKS AT CENTER SECTION . . . . .	198	3	6G, 14A
LOCK INSTALLATION ON LEFT FRONT . . . . .	171	4	3G-5G; 11A, 12A, 7C LHC, 8C
LDCK REMOTE CONTROL MECHANISM . . . . .	180	2	6G, 14A
LOCK REMOTE CONTROL TENSIONER . . . . .	220	2	2R SERIES
PILLAR POST (CENTER) SEAL . . . . .	198	3	6G, 14A
REPAIR PANELS . . . . .	237	1	ALL PASSENGER
TOP AND BOTTOM OF, LEAKS. . . . .	198	2	6G
TOP AND BOTTOM, SEAL. . . . .	198	2	6G, 14A
TRIM PANEL SEAL . . . . .	181	2	6G, 14A

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>D</b>			
DOOR OPENING, WEATHERSEALS, REAR . . . . .	208	1	7g5, 15AS
NEATHERSTRIP . . . . .	207	6	7GS, 15AS
WEATHERSTRIP WATER LEAK . . . . .	206	2	6G, 7G 14A, 15A
DOOR WINDOW, BIND . . . . .	207	4	7g5, 15AS
BIND IN LOWER RUN . . . . .	206	5	66.76: 14A, 15A
LEAKS . . . . .	204	4	14AY, 15AY
DOUBLE VISION, DIAGNOSING CLAIMS . . . . .	199	3	
DOYLE VAC-IT CLEANER . . . . .	224	6	
DRAIN, DOOR HANDLE . . . . .	182	3	6G
BODY, LOCATION OF . . . . .	172	3	6G, 14A
ASSEMBLIES BEFORE RETURN TO FACTORY . . . . .	237	3	
DRIP MOULDING, SEALING . . . . .	181	2	6G, 14A
DRIVEN PLATE, CLUTCH . . . . .	216	4	2R5 2R10
FACINGS . . . . .	223	3	M16, 2R16, 2R17
DRIVER-S COMPARTMENT, WATER LEAKS IN . . . . .	206	2	6G, 7G; 14A, 15A
DRIVER'S HEIGHT, ADJUSTMENTS FOR . . . . .	193	9	14A, 14AY
DRIVING STABILITY . . . . .	217	6	6G-8G; 14A- 16A
DUKANESERVICE CONTROL SYSTEM . . . . .	233	4	
DURABAKE PAINT BAKING OVENS . . . . .	233	3	
DUST LEAK, DOOR (TOP AND BOTTOM) . . . . .	198	2	6G
ODOR DRAIN . . . . .	198	1	6G, 14A
<b>2 R - SERIES</b> . . . . .	218	8	2R SERIES
2R SERIES (AMENDED) . . . . .	228	3	2R SERIES
DUSTPLATE . . . . .	213	1	2R SERIES
DUST, WATER, AND AIR LEAKS . . . . .	198	1-4	6 G, 14A
CONVERTIBLES . . . . .	201	3	6g5, 14a5
DYNAMOMETER, CLAYTON VEHICLE ANALYZER . . . . .	235	6	
OTIS PROVING STAND . . . . .	226	4	
<b>E</b>			
ELECTRIC CLOCK, SERVICE STATIONS . . . . .	241	5	
WARRANTY, SERVICE STATIONS . . . . .	207	6	
ELECTRIC IMPACT TOOL . . . . .	208	6	
ELECTRIC SHOCK . . . . .	177	2	6G: 14A REGALS
ELECTRICAL, BATTERY, PREVENTIVE MAINTENANCE CHECKS . . . . .	171	1	
CIRCUIT BREAKER (CONVERTIBLES) . . . . .	207	3	6GS, 7GS; 14a5, 15a5
DISTRIBUTOR . . . . .	230	1	9G
GASOLINE GAGE IS 2-WIRE SYSTEM . . . . .	237	5	2R SERIES
HARTMAN CHARGER ANALYZER . . . . .	189	4	
HORN BUTTON LOOSE . . . . .	178	1	6G, 14A
J9 AND J7 SPARK PLUG . . . . .	228	2	
ELECTRONIC BALANCER, CHANGEOVER KIT . . . . .	218	10	
ELIMINATION OF CLUTCH CHATTER . . . . .	239	3	6G, 7G, 8G, 9G
ENGINE, BEARING INSERTS USED . . . . .	179	2	3G-6G; 3A- 14A
CONNECTING RODS AND BEARING INSERTS . . . . .	178	2	M SERIES
CRANKCASE BREATHER KIT AGAINST SLUDGE . . . . .	235	2	COMMANDER ENGINES
CRANKSHAFT BEARING, MAIN . . . . .	172	1	2G- 5G; 12A: M5, M15, M16
CRANKSHAFT REAR BEARING OIL SEAL . . . . .	216	2	6G-8G; 14A- 16A.
CYLINDER BLOCK, CHAMPI ON-TYPE . . . . .	234	1	M SERIES, 2R SERIES
CYLINDER BLOCK DOWEL PILOT HOLE LOCATION . . . . .	197	4	9G; 2R5, 2R10, 2R15
CYLINDER HEAD CAP SCREW TIGHTENING PROCEDURE . . . . .	187	1	6G, 7G: 14A, 15A
CYLINDER HEAD GASKETS, KEEP TIGHT . . . . .	172	1	
CYLINDER HEAD, HIGH ALTITUDE . . . . .	176	2	6G
GOVERNOR INSTALLATION . . . . .	200	2	6G, 7G
MANIFOLD HEAT VALVE PLUG . . . . .	176	2	46-66: M5, M15
MOUNTING INSULATORS AND WASHERS, APPROVED . . . . .	172	7	6 G
OIL LEAK AT FRONT . . . . .	182	3	6G
OIL PAN ASSEMBLIES . . . . .	226	2	2R5, 2R10, 2R15
OIL PAN, NEW MODEL INFORMATION . . . . .	227	3	9G, 17A
OIL STRAINER SUPPORT . . . . .	230	3	17A
OIL VISCOSITY RECOMMENDATIONS . . . . .	215	1	
ROUGH IDLE . . . . .	178	3	6G, 14A
SUPPORT FASTENING STUDS . . . . .	203	5	M5, M15A, M16
TAG, OO NOT START, FORM w1189 . . . . .	183	2	6G, 14A, M SERIES
TUNE UP, SETTING OCTANE SELECTOR . . . . .	169	3	
TURNING PLUG, COMMANDER . . . . .	203	4	7A-15A
VALVE LIFTERS AND ADJUSTING SCREWS . . . . .	188	2	6G, M5, M15A

REFERENCE	BUL. NO.	PAGE NO.	MODEL
<b>E-CONT'D</b>			
ENGINE ASSEMBLY. <b>STRIPPED</b> . COMMANDER TYPE . . . . .	224	1	7A- 15A: K5.K15.L5.M16. 2R 15.2R 17
COMMANDER TYPE . ORDER DATA . . . . .	204	2	
GENERATOR BRACKET ON COMMANDER- TYPE . . . . .	235	4	7A- 17A: K5.K15.L5.M16. 2R16.2R17.2R16A.2R17A 11A. 12A
MOUNTING SCREWS . . . . .	225	2	
SHOULD RECEIVE SERVICE ADJUSTMENTS . . . . .	197	4	
ENGINE DIAGNOSIS. PROB-O-PHONE. . . . .	215	4	
ENGINE OIL. DETERGENT. . . . .	215	1	
VISCOSITY RECOMMENDATIONS . . . . .	215	1	6G.8G . 14A- 16A. M SERIES. 2R SERIES
EUTECTIC WELDING CABINETS. . . . .	216	6	
EXECUTONE INTERCOM SYSTEMS . . . . .	223	4	
EXHAUST. INTERFERENCE. TAIL PIPE-RIGHT REAR BRANE PIPE. . . . .	235	3	9G. 17A
LINE-TAANSMISSION NOISE . . . . .	180	2	
EXHAUST VALVES. NON-CORRODING TYPE . . . . .	235	2	9G. 17A: 2R
EXHAUST VENTILATION. SYSTEMS FOR SERVICE DEPARTMENTS MONOXIVENT. . . . .	192	3	
	223	4	
NATIONAL SYSTEM OF VENTILATION . . . . .	204	6	
<b>F</b>			
FALCON GRAY FORMULA . . . . .	230	2	9G. 17A
FAN. BELT PULLEY. SMALLER DRIVER . . . . .	178	1	M5. M15. M15A
FIVE BLADE FOR CHAMPION ENGINES . . . . .	236	2	
SIX BLADE. CORRECT PART NUMBER. . . . .	203	1	M SERIES
FENDER. FRONT. REINFORCEMENT BOLTS AT REAR . . . . .	234	7	17AY
REAR. REINFORCEMENT . . . . .	234	8	9G. 17A
REAR. WELT FOR PICK-UP MODELS . . . . .	220	2	2R5. 2R10. 2R15
FENDIX UNDERCOATING. . . . .	188	1	
FIESTA TAN FORMULA . . . . .	230	2	9G. 17A
FILTER. CLIMATIZER. REMOVE FOR INCREASED HEAT FLOW . REMOVED IN PRODUCTION . . . . .	179	4	14A
	182	1	6G. 14A
FINISH. PAINT FORMULAS . . SEE PAINT FORMULAS			
<b>F</b> RESTONE WARRANTY. PROCEDURES . . . . .	171	5	
FIRST AID CHECKS. RADIO. . . . .	214	3	
<b>F</b> FITTED BLOCK . . . . . DEFINED . . . . .	240	3	
FLARING TOOL FOR DOUBLE FLARING. . . . .	204	6	
FLEET ACCOUNT SERVICE. . . . .	204	2	
FLEXI FONE INTERCOM SYSTEM. . . . .	233	4	
FLOAT LEVEL GAGE . . . . .	206	6	2R SERIES
FLOCK SPRAYING (DEVILBISS) . . . . .	233	3	
FLOOR MATS AND CARPETS INSTALLATION . . . . .	234	2	9G. 17A
FLOOR PAN. RIGHT. LEAK AT. . . . .	198	1	6G. 14A
FLOOR-TANK INTERFERENCE. . . . .	177	3	6G. 14A
FLUSHMASTER. SLUDGE AND CARBON REMOVAL . . . . .	193	9	
FOREST GREEN ENAMEL. . . . .	203	4	M SERIES
FORM H353 DISCONTINUED . . . . .	197	6	M SERIES
<b>FRAM</b> FILTER. INSTALLATION CAUTION. . . . .	171	7	5G
INSTALLATION REVISED. . . . .	179	2	6G
FRONT . . FOR FRONT DOOR SEE DOOR. FRONT: FOR FRONT SEAT SEE SEAT. FRONT: FOR FRONT SPRING SEE SPRING. FRONT: FOR FRONT WHEEL SEE WHEEL. FRONT. ALSO SEE ENTRIES BELOW BEGINNING WITH "FRONT".			
FRONT END ALIGNMENT. . . . .	217	3	6G-8G . 14A- 16A ALL PASSENGER CARS
FRONT FENDER . . SEE FENDER. FRONT. . . . .			
FRONT SUSPENSION SYSTEM. FREE. . . . .	217	2	
NOISE IN. . . . .	234	5	17A
FUEL SYSTEM. ACCELERATING PUMP PISTON AND SPRINGS. . .	230	1	14A- 16A
CARBURETOR. . . . .	230	2	17A
CARBURETOR VACUUM STEP-UP JET . . . . .	229	2	2R16A. 2R17A
GASOLINE FILLER PIPE RESTRICTION. . . . .	235	4	<b>9G</b> . 17 A
GAGE SYSTEM. 2-WIRE . . . . .	237	5	2R
GAGE TANK UNIT COVER. . . . .	220	2	8G. 16A
GASOLINE PIPE TO FUEL PUMP CONNECTOR. . . . .	234	8	17A
GASOLINE TANK TO FLOOR PAN PAD. NOISE SUPPRESSOR. . .	228	2	8G. 16A
HAND THROTTLE CONTROL . . . . .	203	4	M SERIES



REFERENCE	BUL. NO.	PAGE NO.	MODEL
<b>F-Cont'd.</b>			
FUEL SYSTEM * CONT'D.			
MILEAGE TESTER (GAUTHIER) . . . . .	207	8	
PUMP, REMOVE AND INSTALL. CORRECTION IN TIME. . . . .	213	1	15A
PUMP (VACUUM TYPE) IN 14A CYLINDER BLOCK. . . . .	208	2	14A
PUMP (VACUUM TYPE) INSTALLATION . . . . .	208	6	7G
PUMP (VACUUM TYPE) REPAIR KITS. . . . .	206	5	7G 15A: 2R SERIES
PUMP (VACUUM TYPE), SERVICE TOOLS . . . . .	203	8	15A
SETTING OCTANE SELECTOR FOR ECONOMY . . . . .	169	3	
TANK INTERFERENCE WITH FLOOR. . . . .	177	3	6G., 14A
ZENITH CARBURETOR . . . . .	203	5	M5 M15A
FUEL-VACUUM PUMP. IN 14A CYLINDER BLOCK. . . . .	203	2	
INSTALLATION. . . . .	208	6	76
1950 MODEL DATA . . . . .	227	6	9G. 17A
REPAIR KITS . . . . .	206	5	7G. 15A. 2R SERIES
REPAIRS.. . . .	222	1	
SERVICE TOOLS . . . . .	203	8	15A
FUSES. NUMBER OF . . . . .	169	2	4G.5G: 12A: 8C
OVERDRIVE SOLENOID CONTROL RELAY. . . . .	180	2	6G. 14A
FUTURFORM CAR WASHER . . . . .	235	5	
<b>G</b>			
GAGE, GASOLINE, TANK UNIT COVER. . . . .	220	2	8G. 16A
GALA BROWN ENAMEL. . . . .	197	3	
GASKETS, CYLINDER HEAD, KEPT TIGHT . . . . .	172	1	
GASOLINE ECONOMY, SETTING OCTANE SELECTOR. . . . .	169	3	
GASOLINE SYSTEM ■ SEE FUEL SYSTEM . . . . .			
GAUTHIER GASOLINE MILEAGE TESTER . . . . .	207	8	
GEARSHIFT. LEVER CAP GASKET. 4-SPEED . . . . .	218	7	2R SERIES
RATTLES . . . . .	207	4	7G. 15A
SHIFTING. . . . .	191	2	14A
WIRES CONTACTING MECHANISM. . . . .	173	2	6G
GENERATOR. EARLY CUT-IN. . . . .	209	2	66.76: 14A. 15A
HIGH OUTPUT . . . . .	203	3	14A. 15A
GET THE NEW OWNER OFF TO A GOOD START. . . . .	207	2	
GLASS, CLAIMS. . . . .	175	1	
REPLACEMENT OF ONE-PIECE WINDSHIELD . . . . .	216	4	6G-8G: 14A-16A
REPLACEMENT SOURCES . . . . .	209	1	
GLYCOL BASES FOR ANTIFREEZES . . . . .	199	2	
GOVERNOR. DISCONTINUED . . . . .	235	4	9G. 17A
INSTALLATION. . . . .	200	2	6G. 7G
GREASE LEAKS, AT SPEEDOMETER CABLE . . . . .	177	1	6G. 14A
GREASE SEAL, REAR WHEEL, 2R10. . . . .	215	4	
GROVE GREEN FORMULA. . . . .	230	2	9G. 17A
GUARANTEE POLICY. WILLARD BATTERY. . . . .	201	1	
<b>H</b>			
H350. PREPARATION OF VEHICLE FOR DELIVERY. . . . .	183	1	
H353. FORM DISCONTINUED. . . . .	197	6	M SERIES
HAND THROTTLE CONTROL. . . . .	203	4	M SERIES
HARTMAN RAPID BATTERY CHARGER-ANALYZER . . . . .	189	4	
HEADER LOCK SHAFT REPLACEMENT. . . . .	216	4	7GS. 15AS
HEADLAMP. AIMING SCREEN. . . . .	197	7	
CHROME RIMS . . . . .	237	2	9G. 17A
CHROME RIMS . . . . .	240	3	17A
RIMS LOOSE. . . . .	235	3	9G. 17A
ROBOT TESTER. . . . .	192	3	
HEAT INDICATOR MARKING REVISED . . . . .	234	8	9G. 17A
HEAVY DUTY ■ SEE CLUTCH LINKAGE. SPRINGS, RADIATOR, OR OTHER PARTS FURNISHED AS HEAVY DUTY. . . . .			
HIGH ALTITUDE EQUIPMENT. . . . .	176	2	6G
HIGH OUTPUT GENERATOR. . . . .	203	3	14A. 15A
HIGH SPOT, STEERING GEAR . . . . .	222	5	2R
HILL HOLDER. INSTALLATION. . . . .	180	1	M SERIES
REPAIR KIT. . . . .	215	2	
VALVE AND LEVER ASSEMBLY. . . . .	236	6	2R SERIES

REFERENCE	BUL. NO.	PAGE NO.	MODEL
<b>H-CONT'd.</b>			
HM-925-17, 18.19 FRONT SPRING UNLOADER. . . . .	175	2	6G, 14A
HOLD-DOWN BRACKETS. REMOVE . . . . .	227	8	9G, 17A
HOOD. HINGE SUPPORT, LEAK AT . . . . .	198	5	6G, 14A
HINGE WATER LEAK. . . . .	206	3	6G, 7G; 14A, 15A
LATCH. TO OPEN IF CABLE BROKEN. . . . .	182	1	6G, 14A
LOCK RELEASE, SERVICING . . . . .	191	2	6G, 14A
HORN, BUTTON LOOSE, OUT OF POSITION. . . . .	178	1	6G, 14A
BUTTON RATTLE . . . . .	201	1	6G, 14A
SHOCK AT RING . . . . .	177	2	6G, 14A REGALS
HOW TO GET THE BEST RESULTS FROM CLIMATIZER. . . . .	179	3	6G, 14A
HOW TO MAKE PILOT STUDS. . . . .	197	5	
HUB AND DRUM. WHEEL, AND TIRE RUN-OUT SPECIFICATIONS	197	4	6G, 7G; 14A, 15A
REAR WHEEL. . . . .	239	4	2R10
HUB COVER RETAINING SPRING . . . . .	237	2	G-9G; 10A-17A; 6C-8C
HYDROMETERS AND ANTIFREEZES. . . . .	199	1	
HYDROVAC. BRAKE BOOSTER. . . . .	199	5	M16
INSTALLATION OF B-(EQUIPPED TRUCKS . . . . .	226	2	M SERIES
TESTING . . . . .	213	1	2R SERIES
HYPOID TYPE 2-SPEED VACUUM SHIFT REAR AXLE . . . . .	189	2	M16
HY-POWER. BRAKE BOOSTER UNIT . . . . .	229	4	2R16A, 2R17A
DIAGNOSIS CHART . . . . .	229	7	2R16A, 2R17A
<b>I</b>			
IDLE. ROUGH. . . . .	178	3	6G, 14A
IDLE LEVER, STEERING . . . . .	201	4	6G
IGNITION. SEE ALSO DISTRIBUTOR, SPARK PLUGS			
OCTANE SELECTOR SETTINGS. . . . .	169	3	
SPARK PLUG LIST . . . . .	172	1	
TIMING LIGHT (PEERLESS) . . . . .	207	8	
TIMING WITH NEON LIGHT. . . . .	224	1	
INGERSOLL-RAND IMPACT TOOL . . . . .	208	6	
INFRA-RED PAINT BAKING OVENS (DURABAKE). . . . .	233	3	
INSTALLATION OF SWAY BAR ANCHOR BOLTS. . . . .	197	5	14AS, 14AY
INSTALLATION OF VACUUM BOOSTER PUMP ON CERTAIN M5			
AND M15A TRUCKS . . . . .	200	2	M5, M15A
INSTALLATION PUSH BUTTON STARTER . . . . .	199	4	M SERIES
INSTRUMENT PANEL. NOISES FROM. . . . .	236	2	9G, 17A
SPECIAL STEERING POST SUPPORT TO. . . . .	179	2	14A
INSULATOR. STEERING KNUCKLE SUPPORT ARM. . . . .	170	3	2G-5G
INTERCOMMUNICATION SYSTEMS . . . . .	223	4	
IROQUOIS BLUE. ENAMEL. . . . .	200	1	7G, 15A
ENAMEL. . . . .	209	2	2R SERIES
<b>J</b>			
J207-22 DIFFERENTIAL CARRIER, SIDE CARRIER BEARING			
REPLACER. . . . .	170	5	
J505-SCT CARBURETOR REPAIR KIT . . . . .	170	5	
J505-SD CARBURETOR TOOL KIT. . . . .	206	6	
J553-5 REAR SPRING SHACKLE BUSHING REMOVER AND			
REPLACER. . . . .	170	5	
J1294-4 ADAPTER FOR J1294 STEERING KNUCKLE BUSHING			
AND BEARING INSERTER. . . . .	175	3	6G
J1308-8 TRANSMISSION SHIFT ROD ADJUSTING GAGE. . . . .	175	2	6G, 14A, M5
J2027 REAR AXLE SHAFT OUTER SEAL LOCATOR . . . . .	175	2	6G
J2031 STEERING KNUCKLE PIN TO UPPER SUPPORT ARM			
DRIVER. . . . .	175	2	6G, 14A
J2032 REAR AXLE SHAFT OUTER SEAL LOCATOR . . . . .	175	3	14A, M5
J2033 STEERING BELL CRANK NEEDLE BEARING REMOVER AND			
REPLACER. . . . .	175	2	14A
J2034 VALVE STEM GUIDE REMOVER AND REPLACER. . . . .	175	2	6G, 14A, M SERIES
J2035 COMPANION FLANGE HOLDING TOOL. . . . .	175	2	6G, 14A, M SERIES
J2036 CAMSHAFT BEARING REMOVER AND REPLACER SET. . . . .	175	2	6G, 14A, M5
J2037 REAR AXLE PINION SHAFT BEARING OIL SEAL DRIVER			
DRIVER . . . . .	175	2	6G, 14A
J2038 TRANSMISSION REAR FLANGE OIL SEAL DRIVER . . . . .	175	2	6G, 14A, M5
J2039 TRANSMISSION THRUST YOKE . . . . .	175	2	14A, M5

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>J-Cont ' D.</b>			
J2042 STEERING KNUCKLE BUSHING AND BEARING REMOVER AND REPLACER. . . . .	175	2	14A
J2043 STEERING KNUCKLE SUPPORT ARM SPREADER (LARGE END). . . . .	175	2	6G, 14A
J2044 STEERING KNUCKLE SUPPORT ARM SPREADER (SMALL END). . . . .	175	2	6G, 14A
J2046 COMPANION FLANGE PULLER. . . . .	175	2	6G, 14A, M SERIES
J2200 STEERING ARM BALL BOLT PULLER. . . . .	211	5	
J2679 REMOTE CONTROL STARTER SWITCH. . . . .	211	5	
J2827 REAR WHEEL BEARING LOCK NUT CLINGING TOOL . .	213	2	
J2975 WHEEL BEARING NUT WRENCH . 2-3/8" HEX. . . . .	213	2	
J4477 STEERING KNUCKLE BUSHING AND BEARING REMOVER AND REPLACER. . . . .		8	
JACK. UPPER SUPPORT BRACKET FOR SHAFT. . . . .	234	5	9G, 17A
JOYCE-CRIDLAND TWO-POST LIFTS. JOYCESTICK CONTROL. .	233	4	
<b>K</b>			
KEEP TIRE GAGES ACCURATE . . . . .	180	2	
KENT-MOORE TOOL AND EQUIPMENT CATALOG. . . . .	211	5	
KEYS, MODIFYING LOCK CYLINDERS TO FIT. . . . .	235	4	
KING-PIN AND STEERING KNUCKLE. . . . .	224	3	M5
KMO-570 WHEEL BEARING NUT WRENCH . 2-7/8" HEX. . . .	213	2	
KMO-630 TRANSMISSION SNAP RING PLIERS. . . . .	211	5	
KMO-733 FLOAT LEVEL GAGE . . . . .	206	6	2R SERIES
KNOCKS- SOUND UNDERCOATING. . . . .	206	6	
KNUCKLE AND KING.PIN . STEERING . . . . .	224	3	M5
<b>L</b>			
LATHE . ARMATURE . BY JOHNSON . . . . .	203	8	
LEAK (AIR. WATER. OR DUST) BRAKE PEDAL COVER . . . .	198	1	6G, 14A
CAB FLOOR BONDERIZING HOLES . . . . .	218	9	2R SERIES
CAB TOOL COMPARTMENTS . . . . .	218	8	2R SERIES
CONVERTIBLES. . . . .	201	3	6G, 14A
CONVERTIBLE TOP HEADER. . . . .	207	5	6G, 14A
COWL. FRONT SEAT COMPARTMENT. . . . .	198	4	6G, 14A
DEFROSTER DISTRIBUTION TUBE . . . . .	218	9	2R SERIES
DOOR AND CAB LOWER SILL . . . . .	218	9	2R SERIES
DOOR CENTER PILLAR POST. TRIM PANEL . . . . .	198	2	6G, 14A
DOOR CENTER SECTION . . . . .	198	2	6G, 14A
DOOR DRAIN. . . . .	198	1	6G, 14A
DOOR FRONT PILLAR POST. . . . .	218	8	2R SERIES
DOOR HINGE POCKET . . . . .	218	8	2R SERIES
DOOR OPENINGS . . . . .	218	9	2R SERIES
DOOR. TOP AND BOTTOM. . . . .	198	2	6G, 14A
DOOR WINDOWS AND VENTILATORS . . . . .	204	4	14AY, 15AY
DRIP MOULDINGS. . . . .	198	4	6G, 14A
DRIVER'S COMPARTMENT. . . . .	206	2	6G, 7G; 14A, 15A
GEARSHIFT AND HAND BRAKE LEVERS . . . . .	218	9	2R SERIES (4-SPEED)
HOOD HINGE SUPPORT. . . . .	198	5	6G, 14A
LUGGAGE COMPARTMENT FLOOR PAN . . . . .	198	6	6G, 14A
LUGGAGE COMPARTMENT TOP CORNERS . . . . .	198	6	6G, 14A
MATERIALS TO CORRECT. . . . .	206	3	
PEDALS AND STEERING POST. . . . .	218	9	2R SERIES
REAR SEAT COMPARTMENT. 2-DOOR SEDANS. . . . .	198	6	6G, 14A
RIGHT FLOOR PAN . . . . .	198	1	6G, 14A
TRUNK . . . . .	198	7	6G
VARIOUS BODY LEAKS CORRECTED. . . . .	198	1-7	6G, 14A
VENTILATOR WINDOW WEATHERSEAL . . . . .	198	3	6G, 14A
WINDSHIELD RUBBER WEATHERSTRIP. . . . .	198	5	6G, 14A
LEAK (OIL AND GREASE). CLUTCH HOUSING. . . . .	182	3	6G
CLUTCH RELEASE SHAFT RETAINER . . . . .	234	7	6G-9G; 14A-17A
FRONT OF ENGINE . . . . .	182	3	6G
SPEEDOMETER CABLE . . . . .	177	1	6G, 14A
TRANSMISSION. . . . .	187	4	6G
2-SPEED REAR AXLE . . . . .	222	5	2R

REFERENCE	BUL.NO .	PAGE NO.	MODEL
<b>L-Cont'd.</b>			
LET'S RESTORE SERVICE ROUTINES. BY DON O. WILSON . . .	189	1	
LICENSE PLATE BRACKET. FRONT. CORRECT MOUNTING . . .	186	1	6G
LIFT. ELECTRIC (WALKER) . . . . .	213	2	
LIFT. JOYCE-CRIDLAND TWO.POST . . . . .	233	4	
LIFT. TRUCKS. POINTS TO CONSIDER BEFORE PURCHASE . .	170	5	M SERIES
LIGHTS. HEADLAMP RIMS CHROMED. . . . .	237	2	9G. 17A
LOOSE HEAD LAMP RIMS CHROMED. . . . .	235	3	9G. 17A
TAIL LAMP SUPPORT BRACKET . . . . .	218	7	2R SERIES
LINCOLN SERVICE MERCHANDISERS. . . . .	220	4	
LINING. BRAKE. USE SAME FRONT AND REAR . . . . .	179	3	
LOCATION OF CYLINDER BLOCK DOWEL PILOT HOLES . . . .	197	4	6G.7G: 14A.15A
LOCK. LEFT FRONT <b>door</b> . INSTALLATION. . . . .	171	4	3G.4G. 5G; 11a.12A
MODIFYING CYLINDERS TO FIT OWNER'S KEYS . . . .	235	4	
REMOTE CONTROL MECHANISM. . . . .	180	2	6G. 14A
SHAFT REPLACEMENT ON CONVERTIBLES . . . . .	216	4	7G. 15A
LOOSE ASH TRAY . . . . .	187	3	14AY
LUBRICANT LEAK AT 2-SPEED AXLE VENT. . . . .	200	2	M SERIES
LUBRICANTS. APPROVED FOR ROSS STEERING GEARS . . . .	204	5	
TRANSMISSION AND DIFFERENTIAL GEARS . . . . .	208	5	
LUBRICATION. ARO EQUIPMENT . . . . .	191	3	
CHASSIS SPRINGS . . . . .	204	3	
FRAM OIL FILTER INSTALLATION CAUTIONS . . . . .	171	7	5G
FRAM FILTER INSTALLATION REVISED. . . . .	179	2	6G
LARGE CAPACITY OIL PUMP . . . . .	176	1	2 G - 5 M5; M15
LARGE CAPACITY OIL PUMP FOR SERVICE . . . . .	179	2	3A-12A; J SERIES:
			M SERIES
UNIVERSAL JOINTS. USE LOW PRESSURE ONLY . . . . .	197	5	
LUGGAGE COMPARTMENT. BODY BOLT CAP . . . . .	177	3	6G. 14A
FLOOR PAN LEAK. . . . .	198	6	6G. 14A
LID. WASHERS ELIMINATE DIMPLES. . . . .	240	3	
LID HANDLE. NEW PAWL STOP. . . . .	237	3	9G. 17A
LOCK. OPENS WHEN LOCKED . . . . .	182	2	6G
TOP CORNERS. LEAK . . . . .	198	6	6G. 14A
WATER LEAKS . . . . .	172	6	6G
LUSTRE PRODUCTS CORPORATION. . . . .	233	3	
<b>M</b>			
MANIFOLD HEAT VALVE PLUG . . . . .	176	2	4G-6G; M5, M15
MARK ON STEERING WHEEL . . . . .	213	1	15A
MASTER CYLINDER. BRAKE. HOLE COVER WATER LEAKS . .	206	3	6G.7G: 14A.15A
PIPE CLIP. . . . .	208	6	2R SERIES
MASTER MECHANIC AWARD PROGRAM. REQUIREMENTS. . . .	203	1	
MATERIALS FOR CORRECTION OF WATER. DUST. OR AIR LEAKS . . . . .	206	3	
MATS AND CARPETS. INSTALLATION . . . . .	234	2	9G. 17 A
MELODY BLUE ENAMEL . . . . .	200	1	7G. 15A
MERCHANDISER. DOUBLE DUTY (DISPLAY CORP.). . . . .	235	5	
LINCOLN . . . . .	220	4	
MIDLAND HY-POWER BRAKE BOOSTER UNIT. SEE UNDER " BRAKES" OR UNDER ..HY.POWER.. . . . .			
MIDSHIP BEARING AND PARTS: SEE UNDER " PROPELLER SHAFT. . . . .			
MILEAGE. GASOLINE USAGE TESTER (GAUTHIER) . . . . .	207	8	
MIRACLE RIDE DEMONSTRATION . . . . .	232		
MIRROR. REAR VIEW. LOCATION OF . . . . .	173	2	6G
MODIFICATION OF TRANSMISSION SYNCHRONIZER RING PROTECTOR . . . . .	201	4	15A
MONOXIVENT EXHAUST ELIMINATION . . . . .	223	4	
MOTOPHONE. ACCURATE DIAGNOSIS AIDED BY . . . . .	195	4	
MOTOR TUNE-UP (ANALYSIS) EQUIPMENT (ALLEN) . . . . .	203	8	
M SERIES TRUCKS. DATA FOR PURCHASING LIFTS . . . . .	170	6	M SERIES
<b>N</b>			
NATIONAL SYSTEM OF GARAGE VENTILATION. . . . .	204	6	
NELSON AUTOMAT1C TIRE INFLATOR . . . . .	239	6	

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>NCONTd.</b>			
<b>NOISE</b> FRONT SEAT . . . . .	195	3	6G. 14A
INSTRUMENT PANEL . . . . .	236	2	9G. 17A
PAD STOPS AT TANK AND FLOOR PAN . . . . .	228	2	8G. 16A
REAR SEAT . . . . .	195	1	6G. 14A
SUPPRESSION AT SEAT BACK . . . . .	226	4	2R
TRANSMISSION-EXHAUST LINE . . . . .	180	2	14A
NOROL UNIT .. SEE HILL HOLDER . . . . .			
<b>N</b>			
.001" UNDERSIZE CONNECTING ROD BEARING INSERTS . . . . .	186	3	6G. 14A
OAKITE NO. 70, CAR WASHING . . . . .	209	4	
OCTANE SELECTOR, ADJUSTMENT PROCEDURE . . . . .	169	3	
OIL BAFFLES, VALVE SPRING CHAMBER CHAMPION ENGINE. . . . .	209	1	
OIL BATH AIR CLEANER, EFFECT OF OIL LEVEL ON GASOLINE CONSUMPTION . . . . .	230	2	
SERVICE INSTRUCTIONS . . . . .	169	2	
OIL CONTROL PISTON RING . . . . .	233	1	9G: 2R5.2R10. 2R15
OIL ENGINE, DETERGENTS IN . . . . .	215	1	
FILLER PIPE INSTALLATION COMMANDER ENGINES. . . . .	211	2	
FILTER, FRAM, INSTALLATION CAUTION. . . . .	171	7	5G
FILTER, FRAM, INSTALLATION REVISED. . . . .	179	2	6G
LEAK AT CLUTCH HOUSING. . . . .	182	3	6G
LEAK AT FRONT END OF CRANKSHAFT . . . . .	240	2	9G. 17A
LEAK AT FRONT OF ENGINE . . . . .	182	3	6G
LEVEL GAGES, OIL PANS . . . . .	236	6	2R SERIES
PAN ASSEMBLIES. . . . .	226	2	2R5, 2R10, 2R15
PAN BAFFLE ■ CRANKSHAFT INTERFERENCE. . . . .	234	7	9G: 2R5, 2R10, 2R15
PAN, LEVEL GAGES. . . . .	236	6	
PAN, NEW MODEL INFORMATION. . . . .	227	3	9G. 17A
PRESSURE. . . . .	200	2	M16
PUMP, DRIVER GEAR PULLER J2959. . . . .	213	2	
PUMP, LARGE CAPACITY. . . . .	170	3	7A- 12A
PUMP, LARGE CAPACITY. . . . .	176	1	2G-5G ; M5.MI5
PUMP, LARGE CAPACITY FOR SERVICE. . . . .	179	2	3A- 12A: J SERIES: M SERIES
PUMP, VACUUM BOOSTER, WINDSHIELD WIPER. . . . .	179	4	M SERIES
PUMP, WINDSHIELD WIPER VACUUM BOOSTER . . . . .	195	2	6G. 14A
PUMP, WINDSHIELD WIPER VACUUM BOOSTER CHECK VALVE ASSEMBLY. . . . .	193	3	6G.14A: M5.MI6
RECOMMENDATIONS . . . . .	215	1	
SLUDGE ■ CAUSE, PREVENTION, CURE. . . . .	231	2	
STRAINER SUPPORT. . . . .	230	3	17A
DLD IVORY ENAMEL FORMULA . . . . .	237	2	9G. 17A
DNE PIECE PROPELLER SHAFT. . . . .	240	5	M5.MI5A. 2R5,2R10 AND 2R15 MODEL TRUCKS
DPERADIO SERVICE CONTROL, INTERCOM SYSTEMS . . . . .	233	3	
OPERATION K-69, CORRECTION IN TIME . . . . .	213	1	15A
OPERATOR'S GUIDE DISCUSSED . . . . .	183	4	M SERIES
DRDERING REAR WHEEL BEARING WRENCH . . . . .	197	6	M15A, M16
OTIS PROVING STAND . . . . .	226	4	
DVERDRIVE, ADVANTAGES AND OPERATION . . . . .	193	2	
DIAGNOSIS CHART . . . . .	171	6	4G.5G: 11A.12A; 7C.8C (EXCEPT GOVERNOR CONTROLLED)
M5 TRUCK . . . . .	197	6	M5
HOUSING AND MAIN SHAFT. . . . .	218	1	7G, 8G ; 15A.16A
RELAY CONTROL . . . . .	212	4	7G, 8G ; 14A.15A
SOLENOIDS, ALTERNATE MAKE . . . . .	172	6	ALL EXCEPT 6G.8C
SOLENOID SHIELD INTERFERENCE. . . . .	178	3	6G. 14A
2-PIECE PROPELLER SHAFT . . . . .	237	4	2R10
WATER LEAK AT GOVERNOR OPENING COVER . . . . .	206	2	6G, 7G ; 14A. 15A
OVERSIZE RINGS AND PISTON .040'. . . . .	201	1	
3WNER, NEW, GET OFF TO A GOOD START. . . . .	207	2	
OWNER'S GUIDE DESCRIBED. . . . .	183	4	

REFERENCE	BUL.NO.	PAGE NO.	MODEL
P			
PACKAGE COMPARTMENT CARD DESCRIBED . . . . .	183	4	
PAINT DRYING OVENS (DURABAKE) . . . . .	233	3	
PAINT, FORMULAS . . . . .	171	6	5G
	177	3	6G, 14A
	197	3	6G,7G: 14A,15A
	199	2	7 G, 15A
	200	1	7G, 15A
	230	2	9 G, 17A
	237	2	9G, 17A
PAINT SERVICE PACKAGES FOR 1950 MODELS . . . . .	234	7	9G, 17A
PAINT SHOP DEVILBISS) . . . . .	204	6	
PAINT, SYMBOL LOCATION . . . . .	192	1	
PARKING BRAKE, APPLICATION . . . . .	211	1	6 G, 14A
CABLE PIN AND STEERING POST COLLAR INTERFERENCE . . . . .	203	4	7G, 15A
HANDLE TENSION ADJUSTMENT . . . . .	203	3	6G,7G; 14A,15A
RATCHET SPRING REPLACEMENT . . . . .	197	3	6G, 14A
RELEASE BUTTON ANTIRATTLE . . . . .	225	2	8G, 16A
PARKWAY GREEN ENAMEL . . . . .	200	1	7G, 15A
PAWL STOP FOR LUGGAGE COMPARTMENT LID HANDLE . . . . .	237	2	9G, 27A
PEACOCK GREEN ENAMEL . . . . .	203	2	7G, 15A
PEDAL, BRAKE, FREE TRAVEL . . . . .	203	2	6G,7G ; 14A,15A
HOLE COVER WATER LEAK . . . . .	206	3	6G, 7G ; 14A,15A
POSITIVE RETURN . . . . .	188	1	6 G, 14A
PEERLESS POWER TIMING LIGHT . . . . .	207	8	
PERFECT CIRCLE PISTON RINGS . SOME STRAIGHT TALK ABOUT PISTON RINGS . . . . .	236	8	
PETROLEUM BASE ANTIFREEZES . . . . .	199	1	
PHILCO AUTO RADIO, SERVICE STATION LIST . . . . .	237	6	
IDENTIFICATION OF TRUCK MODEL . . . . .	207	7	2R SERIES
SERVICE STATION COOPERATION . . . . .	214	4	
PICK-UP BOXES . . . . .	211	4	2R5, 2R10, 2R15
PILOT, CYLINDER HEAD AND GASKET . . . . .	195	2	14A
PILOT STUDS, HOW TO MAKE . . . . .	197	5	
PINION CHARTS, SPEEDOMETER . . . . .	224	5	
PISTON, AND RINGS .040' OVERSIZE . . . . .	201	1	
OIL CONTROL RING . . . . .	233	1	
RING REPLACEMENT AFTER REBORING . . . . .	170	2	3G-5G; M5,M15
PLASTAHIDE SERVICE COVERS PROTECT CARS, CUT COSTS . . . . .	188	4	
PLASTIGAGE OFFERS PUICK ACCURATE BEARING TOLERANCE MEASUREMENT . . . . .	199	5	
POLISHER-SANDER, ELECTRIC (LUSTRE) . . . . .	233	3	
POSITIVE BRAKE PEDAL RETURN . . . . .	188	1	6G, 14A
POWER TAKE-OFF DATA FOR TRU-STOPEQUIPPED M16 . . . . .	191	4	M16
FOR USE WITH WARNER T97 TRANSMISSION . . . . .	240	5	2R16A, 2R17A
2R16A-2R17A MODELS . . . . .	240	6	2R16A,2R17A
PREPARATION OF VEHICLE FOR DELIVERY, FORM H350 . . . . .	183	1	
PROB-O-PHONE AIDS DIAGNOSIS . . . . .	215	4	
PROPELLER SHAFT FLANGE DISC . . . . .	233	3	2R10
INCREASED SPLINE DIAMETER . . . . .	237	3	2R15, 2R16A, 2R17A
MIDSHIP BEARING SUPPORT CUSHIONS . . . . .	228	2	2R SERIES
1950 MODEL DATA . . . . .	227	7	9G, 17A
ONEPIECE . . . . .	240	5	M5,M15A, 2R5,2R10, 2R15
SUPPORT ASSEMBLY . . . . .	209	3	2R10,2R15,2R16,2R17
SUPPORT BEARING . . . . .	195	4	M15,28 , M15A,28 , M16
SUPPORT BEARING KIT . . . . .	211	3	M15A, M16
SUPPORT SCREN TENSION . . . . .	203	7	M SERI es
SUPPORT, SPACER FOR . . . . .	200	2	6G, 14A
2-PIECE FOR OVERDRIVE . . . . .	237	4	2R10
2-PIECE FOR 2R15-21 . . . . .	230	4	2R15- 21
VIBRATION, SINGLE SPEED AXLE . . . . .	201	2	M15A, M16
PROPER MOUNTING OF FRONT LICENSE PLATE BRACKET . . . . .	186	1	6 G
PROTECTIVE CAR UNDERCOATING . . . . .	188	1	
PUMP, OIL, LARGE CAPACITY . . . . .	170	3	7A- 12A
LARGE CAPACITY . . . . .	176	1	2G-5G: M5, M15
LARGE CAPACITY IN SERVICE . . . . .	179	2	3A-12A ; J SERIES
			M SERIES
WINDSHIELD WIPER VACUUM BOOSTER . . . . .	195	2	6G, 14A
PUMP, WATER, INLETHOSE REINFORCING CLIP . . . . .	170	4	M16
PUSH BUTTON STARTER, INSTALLATION . . . . .	199	4	M SERIES
SWITCH . . . . .	212	3	2R16, 2R16

REFERENCE	BUL .NO .	PAGE NO .	MODEL
<b>R</b>			
RADIATOR, HEAVY DUTY EQUIPMENT . . . . .	199	5	M SERIES
CORE REPAIRS DURING WARRANTY . . . . .	220	2	8G. 16A
CORE SERIAL LOCATION . . . . .	179	1	6G. 14A
CORE SUPPORT TO DASH TIE ROD ASSEMBLIES . . . . .	193	4	M16
SURGE TANK . . . . .	218	2	6G.7G. 2R SERIES
IADIO, ALIGNMENT OF MOUNTING BOLT HOLES . . . . .	234	1	9G. 17A
ANTENNA PADDER ADJUSTMENT . . . . .	220	2	8G. 16A
ANTENNA SERVICE . . . . .	214	4	
BENCH TEST . . . . .	214	2	
FIRST AID CHECKS . . . . .	214	3	
IOENTIFICATION . . . . .	207	7	2R SERIES
INSTALLATION . . . . .	214	2	
INTERFERENCE . . . . .	234	2	17A. 17AY
PHILCO SERVICE STATION LIST MAILED . . . . .	237	6	
REGISTRATION TAG DESCRIBED . . . . .	183	3	6G. 14A. M SERIES
SERVICE DATA . . . . .	171	3	
SERVICE GUIDE . . . . .	214	1-4	
SERVICE PROCEDURE . . . . .	214	3	
SERVICE STATIONS . . . . .	237	6	
RATTLE, FRONT DOOR GLASS . . . . .	173	1	6G
FRONT DOOR REMOTE CONTROL ADJUSTING LINK . . . . .	189	2	6G. 14A
FRONT SEAT ADJUSTER TIE BAR . . . . .	240	3	9G. 17A
HORN PUSH BUTTON . . . . .	201	1	6G. 14A
TRANSMISSION REMOTE CONTROL (GEARSHIFT LEVER) . . . . .	207	4	7G. 15A
REACH ROO ANO TIE ROD CLAMP POSITIONING . . . . .	234	6	9G. 17A
REAR AXLE, ASSEMBLY, WIDE TREAD . . . . .	203	6	M16
CODING . . . . .	211	2	2R SERIES
COMPANION FLANGE HOLDING TOOL J2035 . . . . .	175	2	6G. 14A. M SERIES
COMPANION FLANGE PULLER J2046 . . . . .	175	2	6G. 14A. M SERIES
DAMAGED ASSEMBLIES DO NOT MERIT FULL CLAIMS CREDIT . . . . .	197	6	M15A. M16
DIFFERENTIAL, CLEAN BEFORE SHIPPING . . . . .	224	2	
DIFFERENTIAL CLEANER . . . . .	228	3	
DIFFERENTIAL GEAR KITS . . . . .	228	1	6G-8G: 14A- 16A: 2R5
GEARSHIFT (2-SPEED) . . . . .	212	6	2R SERIES
HYPOID TYPE 2-SPEED VACUUM SHIFT . . . . .	189	2	M16
NO CREDIT FOR DAMAGED RETURNS . . . . .	237	3	2R
PINION SHAFT BEARING OIL SEAL DRIVER J2037 . . . . .	175	2	6G. 14A. M SERIES
RATIO CHANGE . . . . .	203	6	M15A
SHAFT OUTER SEAL LOCATOR J2027 . . . . .	175	2	66
SHAFT OUTER SEAL LOCATOR J2032 . . . . .	175	3	14A. M5
SPACER, REAR SPRING TO . . . . .	170	3	M15. M16
TIMKEN SERVICE PROCEDURES . . . . .	206	6	2R16. 2R17
2-SPEED AXLE CONTROL CABLE, PROTECTOR CONDUIT . . . . .	239	4	2R16A. 2R17A
2-SPEED REMOVAL TOOL . . . . .	226	2	2R SERIES
2-SPEED SELECTOR VALVE . . . . .	204	5	M SERIES
2-SPEED TAG W969 . . . . .	171	3	M16
?EAR BEARING OIL SEAL, CRANKSHAFT . . . . .	216	2	6G-8G; 14A- 16A. M SERIES 2 R SERIES
REAR BRAKE BACKING PLATE INSTALLATION . . . . .	177	1	M15. M15A. M16
REAR FENDER . . . SEE FENDER, REAR . . . . .			
REAR SEAT, LEAK INTO COMPARTMENT, 2-DOOR SEDANS . . . . .	198	6	6G. 14A
NOISE . . . . .	195	1	6G. 14A
REAR SPRING, AND FRONT SPRING . . . . .	195	3	M5
BOLTS . . . . .	170	4	4G, 5G; 12A: 8C: M5
DATA FOR CHECKING . . . . .	172	5	3G-5G
INCREASED U-BOLT TORQUE . . . . .	237	5	2R15. 2R16A. 2R17A
LUBRICATION DATA, CUSTOM CHAMPION . . . . .	239	1	9G
REBOUND CLIP KIT . . . . .	193	2	6G. 14A
SHACKLE AND BUSHING KITS . . . . .	233	1	PRIOR TO 8G. 16A
SPACER TO AXLE . . . . .	170	3	M15. M16
U-BOLT NUTS . . . . .	203	6	M5
?EAR VIEW MIRROR LOCATION . . . . .	173	2	6G
?EAR WHEEL, BEARING LOCK NUT CLINCHING TOOL J2827 . . . . .	213	2	
GREASE SEAL . . . . .	215	4	2R10
HUB AND DRUM ASSEMBLY . . . . .	239	4	2R10
RUN-OUT . . . . .	172	5	
REBOUND CLIP, REAR SPRING . . . . .	209	1	7G. 15A
REAR SPRING KIT . . . . .	193	2	6G. 14A

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>R-ConT-d.</b>			
RECOMMENOE TIRE PRESSURES . . . . .	191	3	6G. 14A
REFERENCE CARO. GLOVE COMPARTMENT. . . . .	183	4	
RELAY CONTROL. OVERDRIVE . . . . .	172	6	ALL EXCEPT 6G, 8C GOVERNOR CONTROLLED
RELEASE BEARING COLLAR SPRING. CLUTCH. . . . .	230	2	6G-8G: 14A-16A
RELEASE SHAFT GREASE RETAINER. CLUTCH. . . . .	215	2	7G. 15A. 2R SERIES
REMOVAL OF PROTECTIVE COATING ON WHITE SIDEWALL TIRES . . . . .	191	1	
REPOSITIONING TIRES AIDS SMOOTH RIDE . . . . .	193	7	M15A-20
RIDE . STIFF AND CHOPPY . . . . .	217	6	6G-8G: 14A-16A
RIGHT SHROUD VENTILATOR GASKET . . . . .	206	3	6G, 7G; 14A.15A
RIMS. NEW TYPE . . . . .	206	6	2R SERIES
RING GEAR HEATER. STARTER V91. . . . .	170	5	
RINGS ■ SEE PISTON RINGS. . . . .			
ROBOT HEADLIGHT TESTER . . . . .	192	3	
RODEO TAN ENAMEL . . . . .	199	2	7G. 15A
ROOF. PANEL EXTERNAL SEALER ELIMINATED . . . . .	225	2	PASSENGER
TRIM REINFORCING BOW. . . . .	213	2	2R SERIES
ROSS GEAR APPROVED LUBRICANTS. . . . .	204	5	
ROTO BEARING INSTALLATION. . . . .	208	4	
RUBY GLOW RED ENAMEL . . . . .	203	4	M SERIES
RUGLYDE RUBBER LUBRICANT NOW AT PARTS DEPOTS . . . . .	240	5	
RUN.OUT. REAR WHEEL. . . . .	172	5	
SPECIFICATIONS. WHEEL. TIRE. HUB. AND DRUM. . . . .	197	4	6G.7G: 14A 15A
RUST INHIBITOR TAG . . . . .	172	2	
RUST PREVENTIVE. REMOVAL FROM PARTS. . . . .	215	3	
<b>S</b>			
SAFETY LIGHTING SERVICE MANUAL . . . . .	239	6	
SALT' BASE ANTIFREEZES. . . . .	199	1	
SANDER-POLISHER. ELECTRIC (LUSTRE) . . . . .	233	3	
SANDER. PORTABLE ELECTRIC (STERLING) . . . . .	203	7	
SAVE OLD WATER PUMP GREASE CUPS. . . . .	191	1	
SEAL. FLOOR PAN TRANSMISSION CLEARANCE COVER . . . . .	211	5	2R SERIES (4- SPEED)
SEALER. DOLPHIN EYEBROW AND SYMBOLS. . . . .	181	2	6G. 14A
SEASONAL SERVICE. SPRING . . . . .	219		
SEAT. ADJUSTABLE TYPE: INSTALLATION. SERVICE . . . . .	236	4	2R SERIES
SEAT BACK NOISE SUPPRESSORS. . . . .	226	4	2R
SEAT. FRONT. ADJUSTER TIE BAR RATTLE . . . . .	240	3	9G; 17A
AOJUSTO-AIR CUSHION . . . . .	218	7	
ANTI-RATTLE SPRING. . . . .	239	5	2R SERIES
BACK OF ADDITIONAL SUPPORT. . . . .	177	4	6G 2-DOOR
BACK SLIPS PAST OUTER STOP. . . . .	177	5	6G 2-DOOR
CUSHION TRIM WEAR . . . . .	173	3	6G
SPUEAK AT OUTER STOP. . . . .	177	5	6G 2-DOOR
SEAT. REAR. LEAK INTO COMPARTMENT. . . . .	198	6	6G. 14A 2-DOOR
NOISE . . . . .	195	1	6G. 14A
SHELF SQUEAK . . . . .		3	9G 17A
SERVICE ADJUSTMENTS FOR VACUUM POWER BRAKE AND CLUTCH CONTROLS . . . . .	190	1-7	3G-6G
SERVICE BRAKES. ADJUSTMENT . . . . .	195	1	6G. 14A
PEDAL ADJUSTMENT. . . . .	203	2	6G, 7G; 14A.15A
SERVICE BULLETINS. HOW TO USE. . . . .	205		
SERVICE CONTROL. INTERCOM SYSTEM . . . . .	233	4	
SERVICE COVERS. HOW TO MAKE. . . . .	172	2	
PLASTAHIDE. . . . .	188	4	
SERVICE IS OUR BUSINESS. . . . .	200	1	
SERVICE MERCHANDISERS. A NOTE ON BUYING. . . . .	192	2	
KENT.MOORE . . . . .	213	2	
LINCOLN . . . . .	220	4	
SERVICE POLICY. DEALER. DESCRIBED. . . . .	183	3	
REVISED . . . . .	193	2	
SERVICE UNIFORMS (UNITOG) . . . . .	230	4	
SERVICING HOOD LOCK RELEASE. . . . .	191	2	6G. 14A
SHACKLE KIT. FRONT SPRING. . . . .	215	4	M15A. M16
SHAKE. AT HIGH SPEEDS. . . . .	217	6	6G-8G; 14A-16A
AT LOWSPEEDS . . . . .	217	6	6G-8G; 14A-16A



<b>S-Cont'd.</b>			
SHENANDOAH GREEN ENAMEL FORMULA . . . . .	237	2	9G. 17A
SHIELD. BRAKE PEDAL SPLASH . . . . .	188	2	6G. 14A. 14AY
SHIFT ROD ASSEMBLIES. TRANSMISSION REMOTE CONTROL . .	187	4	6G
SHOCK ABSORBERS . . . . .	227	8	9G. 17A
IDENTIFYING CHARACTERISTICS . . . . .	178	4	
IMPROVEMENT. INSTALLATION . . . . .	172	3	M SERIES
LINK BOLT SPACER . . . . .	192	2	6G. 14A
REFERENCES . . . . .	186	1	6G. 14A
SETTING CHANGED . . . . .	234	8	17A
	203	3	6G, 7G; 14A. 15A
	211	5	
SHOPMASTER. 2-POST LIFTS . . . . .	189	3	
SHOT INSERT KIT INSTALLATION . . . . .	217	2	6G. 7G. 14A. 15A
SHROUD VENTILATOR. GASKET. RIGHT. WATER LEAK . . . . .	206	3	6G. 7G. 14A. 15A
WATER LEAK . . . . .	203	3	6G. 7G. 14A. 15A
SILVER GRAY ENAMEL . . . . .	199	3	76. 15 A
SLUDGE. CARBON REMOVAL WITH FLUSH MASTER . . . . .	193	9	
CAUSE. PREVENTION. CURE . . . . .	231	2	
CRANKCASE BREATHER KIT FOR COMMANDER ENGINES . . . . .	235	2	
*SOLENOID. OVERDRIVE . ALTERNATE MAKE . . . . .	170	4	5G
RELAY FUSE . . . . .	180	2	6G 14 A
SHIELD INTERFERENCE . . . . .	178	3	6G. 14 A
SOUNDING TOOL. MOTOPHONE . . . . .	195	4	
PROB-OPHONE . . . . .	215	4	
*SPACER. REAR SPRING TO AXLE . . . . .	170	3	M15
SPARE TIRE BOLT . . . . .	224	2	
SPARK PLUGS. CHAMPION 500 COMPARATOR . . . . .	206	8	
CHAMPION J9 AND J7 . . . . .	228	2	
LIST BY MODELS . . . . .	172	1	
SPECIAL CONTROL FOR DISABLED DRIVERS. SERVICE . . . . .	190	1-7	3G-6G
SPECIFICATIONS ■■ SEE UNDER MAKE OF UNIT FOR WHICH SPECIFICATIONS ARE DESIRED . . . . .			
SPEEDOMETER ASSEMBLY . . . . .	239	4	2R SERIES
DRIVE GEAR . . . . .	236	5	2R SERIES
ERRATIC INDICATOR . . . . .	235	5	
GREASE LEAK AT CABLE . . . . .	177	1	6G. 14 A
MODIFICATION OF MOUNTING BRACKET . . . . .	237	4	2R
PINION CHARTS . . . . .	224	5	2R
SPLASH SHIELD. CLUTCH AND BRAKE PEDALS . . . . .	222	2	6G. 7G; 14A. 15A
SPRAYING EQUIPMENT. FLOCK (DEVILBISS) . . . . .	233	3	
SPRING LEAF BEARINGS (ROTO) . . . . .	208	4	
SPRING SEASONAL SERVICE . . . . .	219		
SPRINGS. DATA FOR CHECKING SAG. ETC.. FRONT AND REAR LUBRICATION . . . . .	172	4	3G-5G
PREVENTIVE MAINTENANCE SUGGESTIONS . . . . .	204	2	7G 15 A
REBOUND CLIP . . . . .	182	1	
REBOUND CLIP . . . . .	209	1	7G 15 A
SPRINGS AND SHOCK ABSORBERS . . . . .	227	8	9G. 17 A
SPRINGS. FRONT. HEAVY DUTY. USE WITH OVERSIZE TIRES . .	179	4	6G
LUBRICATION . . . . .	224	1	ALL PASSENGER
METAL-TO-METAL CONTACT . . . . .	171	2	M15
NEW TYPE . . . . .	220	3	2R5. 2R10
SHACKLE KITS . . . . .	215	4	M15A
SHOT INSERT KIT . . . . .	217	2	
STIFF DUE TO SHOCK ABSORBER . . . . .	203	3	
UNLOADER HM-925-17-18-19 . . . . .	175	2	
SPRINGS. REAR. BOLTS . . . . .	170	4	
BUSHING SPACERS FOR HEAVY DUTY USE . . . . .	188	4	
FRAME BUMPER AND SPRING PARTS . . . . .	223	2	
HEAVY DUTY REAR HANGERS . . . . .	187	2	
SHACKLE AND BUSHING KITS . . . . .	233	1	
REBOUND CLIP KIT . . . . .	193	2	
SHACKLE BUSHING REMOVER AND REPLACER . . . . .	170	5	
SPACER TO AXLE . . . . .	170	3	M15
U-BOLT NUTS . . . . .	203	6	
SQUEAK. BRAKE . . . . .	178	1	
OUTER SEAT STOP . . . . .	177	5	6G 2-DOOR
SEAT BACK SHELF . . . . .	240	3	9G. 17 A
STABILIZER BAR ANCHOR BOLTS. INSTALLATION OF . . . . .	197	5	14AS. 14AY
STABILIZER LINK. FRONT. INTERFERENCE . . . . .	234	8	17A

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>S-Cont'd.</b>			
STARTER. RING GEAR. HEATER V91. . . . .	170	5	
SWITCH. FASTENING CLIPS. . . . .	191	1	M SERIES
SWITCH. INSTALLING PUSH BUTTON . . . . .	199	4	M SERIES
SWITCH. INSTALLING PUSH BUTTON . . . . .	212	3	2R16, 2R17
SWITCH. REMOTE CONTROL J2679 . . . . .	211	5	
STEERING. ADJUSTMENTS . . . . .	193	8	14A
ADJUSTMENT AND DIAGNOSIS . . . . .	217	4	6G-8G- 14A- 16A
ARM BALL BOLT PULLER J2200 . . . . .	211	5	
BELL CRANK NEEDLE BEARING REMOVER AND REPLACER J2033 . . . . .	175	2	14A
CAMBER . . . . .	217	3	6G-8G; 14A, 16A
CASTER . . . . .	217	3	6G-8G: 14A- 16A
CASTER ADJUSTMENT NOT RECOMMENDED. . . . .	176	2	
CASTER SHIMS . . . . .	223	3	2R5
CASTER SPECIFICATION REVISED . . . . .	235	3	9G, 17A
CHANGES. SUMMARY OF. . . . .	233	2	2R5, 2R10
CHUCKLE IN STRAIGHT AHEAD POSITION . . . . .	217	5	6G-8G; 14A- 16A
CHUCKLE WHEN TURNING . . . . .	217	5	6G-8G; 14A- 16A
FRONT END ALIGNMENT . . . . .	217	3	6G-8G 14a- 16A
FRONT SUSPENSION SYSTEM. FREE. . . . .	217	2	6G-8G; 14A- 16A
FRONT WHEEL SHAKE AT LOW SPEED . . . . .	211	1	14A- 15A
GEAR. ARM STUD PLAIN WASHERS . . . . .	201	4	6 G
GEAR. ASSEMBLY ALIGNMENT . . . . .	223	3	FLAT FACED COWL TRUCK
GEAR. FRAME SPACER . . . . .	234	6	9G
GEAR. HIGH SPOT. . . . .	222	5	2R
GEAR. LUBRICANTS APPROVED BY ROSS. . . . .	204	5	
GEAR TA12. . . . .	233	3	2R5, 2R10
GEARSTOP. . . . .	236	3	9G
IDLER ARM BRACKET. . . . .	234	6	96
IDLER LEVER. . . . .	201	4	6G
IDLER LEVER. BUSHING SERVICE SET J1621 . . . . .	211	5	
KICKBACK . . . . .	217	5	6G-8G; 14A- 16A
KNUCKLE AND KING-PIN . . . . .	224	3	M 5
KNUCKLE BUSHING AND BEARING INSERTER ADAPTER J1294.4 . . . . .	175	3	6 G
KNUCKLE BUSHING AND BEARING REMOVER AND REPLACER J 2 0 4 2 . . . . .	175	2	14A
KNUCKLE BUSHING AND BEARING REMOVER AND REPLACER J4477 . . . . .	241	8	
KNUCKLE. CHANGE AS OF NOVEMBER 1949. . . . .	233	2	2R5, 2R10
KNUCKLE PIN TO UPPER SUPPORT ARM DRIVER J2031. . . . .	175	2	6G, 14A
KNUCKLE STOP SCREW ADJUSTMENT. . . . .	236	3	9G
KNUCKLE SUPPORT ARM INSULATOR. . . . .	170	3	2G-5G
KNUCKLE SUPPORT ARM SPREADER (LARGE END) J2043 . . . . .	175	2	6G, 14A
KNUCKLE SUPPORT ARM SPREADER (SMALL END) J2044 . . . . .	175	2	6G, 14A
POST. COLLAR AND PARKING BRAKE CABLE INTERFERENCE. REACH ROD. . . . .	203	4	7G, 15A
SPECIAL SUPPORT. . . . .	240	4	2R SERIES (LHC)
TIE RODS AND ENDS. . . . .	179	2	14A
TIE ROD AND REACH ROD CLAMP POSITIONING. . . . .	215	4	2R SERIES
TOE.IN . . . . .	234	6	9G, 17A
TOE.IN . ADJUSTMENT . . . . .	217	4	6G-8G: 14A- 16A
TURNING RADIUS INTERFERENCE. . . . .	203	2	6G, 7G; 14A, 15A
WHEEL. ADJUSTMENT . . . . .	182	2	6G
WHEEL. ELEVATION. . . . .	186	3	14A
WHEEL. LOWER POSITION . . . . .	234	5	9G, 17A
WHEEL. POSITION MARK. . . . .	223	2	8G
WHEEL SHAKE . . . . .	213	1	15A
STEEL MIST METALLIC FORMULA . . . . .	217	5	6G-8G; 14A- 16A
STEP. AUXILIARY FOR CAB BODY. . . . .	230	2	9G, 17A
STEWART-WARNER ELECTRONIC BALANCER. CHANGEOVER KIT. . . . .	229	2	2R16- 17
STRATTONHYDRAULIC SHOP CRANES. . . . .	218	10	
STRIPPED ENGINE - SEE ENGINE ASSEMBLY. STRIPPED. . . . .	228	3	
*STRIPPED ENGINE ASSEMBLY. DEFINED . . . . .	240	3	
STUDEBAKER-PHILCO RADIO . . . . . PERTAINING TO RADIOS. SEE UNDER **RADIO** . . . . .			
STUDEBAKER-PHILCO SERVICE GUIDE . . . . .	214		
SUPER-SOAK PARTS WASHER . . . . .	208	6	
SUN EQUIPMENT TRAINING SCHOOL . . . . .	233	3	

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>S-Contd.</b>			
SUPPORT BEARING ■■ SEE PROPELLER SHAFT SUPPORT BEARING . . . . .			
SURGE TANK INSTALLATION . . . . .	218	2	6G. 7G. 2R SERIES
SURF GRAY ENAMEL FORMULA . . . . .	237	2	
SWAYBAR ■■ SEE STABILIZER . . . . .			
SYNCHRONIZER RING PROTECTOR MODIFICATION . . . . .	201	4	15A
<b>T</b>			
TAGS. STICKERS. CARDS. PACKAGE COMPARTMENT BOOKLETS IN NEW CARS. TRUCKS . . . . .	183	1-4	6G. 14A. M SERIES
TAIL LAMP SUPPORT BRACKET POSITION . . . . .	218	7	2R SERIES
TAKE-OFF. POWER. . . . .	216	4	2R16. 2R16. 2R16A. 2R17A
TESTING EQUIPMENT TRAINING SCHOOL (SUN) . . . . .	233	3	
3-UP METAL PARTS CLEANER . . . . .	237	6	
THROTTLE. INSTALLATION OF HAND CONTROL . . . . .	241	7	2R SERIES
THROTTLE CONTROL BELL CRANK . . . . .	241	2	9G
INTERFERENCE. . . . .	215	3	2R SERIES
TIE RODS AND ENDS. CHANGES IN. . . . .	215	4	2R SERIES
TIE ROD AND REACH ROD CLAMP POSITIONING. . . . .	234	6	9G. 17A
TIMING. IGNITION. WITH NEON LIGHT. . . . .	224	1	
TIMKEN AXLE SERVICE PROCEDURES . . . . .	206	6	2R16. 2R17
TIRES. CROSS-CROSS TO EQUALIZE WEAR. . . . .	195	2	AL 1
FIRESTONE WARRANTY. MEANING AND PROCEDURE . . . . .	171	5	AL 1
GROOVING EQUIPMENT. . . . .	235	5	
KEEP PRESSURE GAGES ACCURATE. . . . .	180	2	ALL
PRESSURES. KEEP CORRECT . . . . .	208	4	
PRESSURES. RECOMMENDED. . . . .	191	3	6 G. 14A
PRESSURES. REVISED. . . . .	176	1	14A
REMOVAL OF PROTECTIVE COATING ON WHITE SIDEWALLS. . . . .	191	1	ALL
REPLACEMENT. NEW TYPE RIMS. . . . .	206	6	2R SERIES
REPOSITIONING AIDS SMOOTH RIDE. . . . .	193	7	M15A. 20
SPECIFICATIONS. RUN-OUT . . . . .	197	4	6G.7G: 14A. 15A
STRIKING CLIMATIZER DUCT. . . . .	173	3	6G
THUMP. LOW SPEED. . . . .	217	6	
USE HEAVY DUTY FRONT SPRINGS WITH OVERSIZE EQUIPMENT. . . . .	179	4	6G
T9A TRANSMISSION IDENTIFICATION . . . . .	222	6	2R16A
TOE-IN . . . . .	217	4	6G-8G: 14A- 16A
ADJUSTMENT. FRONT WHEEL . . . . .	203	2	6G.7G: 14A. 15A
TOOLS AND EQUIPMENT CATALOG. KENT.MOORE . . . . .	211	5	
TOOLS. SPECIAL REQUIREMENTS . . . . .	175	2	6 G. 14A
TOP. CONVERTIBLE FOLDING. CIRCUIT BREAKER. . . . .	207	3	6G, 7G; 14A. 15A
CROSS BRACES. KEEP ADJUSTED . . . . .	211	1	15a5
TORQUE CHART . . . . .	239	7	2R SERIES
TORQUE DATA. . . . .	171	3	5 G
	193	5	M5. M15. M15A
	193	6	M 16
	193	4	M SERIES
TORQUE WRENCHES. USE THEM CORRECTLY. . . . .	239	1	
TOURING SERVICE CUSTOMERS. . . . .	204	1	
TOWING INSTRUCTIONS FOR CARS EQUIPPED WITH AUTOMATIC DRIVE . . . . .	240	1	
TRAFFIC LANE MARKERS . . . . .	192	4	
<b>TRANSMISSION</b> AND DIFFERENTIAL GEAR LUBRICANTS . . . . .	208	5	ALL
CLEAN BEFORE SHIPMENT . . . . .	224	2	
CLEANER (DEE-TEE) . . . . .	228	3	
CLEARANCE COVER SEAL . . . . .	211	5	2 SERIES ( 4 SPEED)
EXHAUST LINE NOISE. . . . .	180	2	14A
4-SPEED. GEARSHIFT LEVER CAP GASKET . . . . .	218	7	2R SERIES
GEAR SHIFTING . . . . .	191	2	14A
INSPECTION COVER WATER LEAK . . . . .	206	3	6G.7G: 14A. 15A
LUBRICANT LEAKAGE . . . . .	187	4	6G
NEW PART NUMBER . . . . .	199	3	6G, 7G; 14A. 15A
OVERDRIVE . . . . .	197	6	M5
OVERDRIVE GOVERNOR OPENING WATER LEAK . . . . .	206	2	6G.7G: 14A. 1%
OVERDRIVE MAIN SHAFT AND HOUSING. . . . .	218	1	7 G. 8G. 15A. 16A
OVERDRIVE SOLENOID SHIELD INTERFERENCE. . . . .	178	3	6G. 14A

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>T-Cont. d.</b>			
TRANSMISSION * CONT'D.			
OVERDRIVE, 2-PIECE PROPELLER SHAFT FOR. . . . .	237	4	2R10
POWER TAKE-OFF INFORMATION FOR USE WITH WARNER T97. . . . .	240	5	2R16A. 2R17A
REAR FLANGE OIL SEAL DRIVER J2038 . . . . .	175	2	6G. 14A
REAR OIL SEAL INSTALLING DRIFT C579 . . . . .	170	5	ALL
REMOTE CONTROL GEARSHIFT LEVER RATTLE . . . . .	207	4	7 G 15A
REMOTE CONTROL SHIFT ROD ASSEMBLIES . . . . .	187	4	6G
SHIFT ROD ADJUSTING GAGE J1308-9. . . . .	175	2	6 G 14 A M5
SNAP RING PLIERS KMO-630. . . . .	211	5	
SYNCHRONIZER RING PROTECTOR MODIFICATION. . . . .	201	4	15A
THRUST YOKE J2039 . . . . .	175	2	14A. M5
THRUST YOKE J2040 . . . . .	175	2	6G
T9A IDENTIFIED. . . . .	222	6	2R16A
TRIM WEAR. FRONT SEAT CUSHION. . . . .	173	3	6 G
TRUCK INFORMATION CARD DISCONTINUED. . . . .	197	6	M SERIES
LIFTS. POINTS TO CONSIDER BEFORE PURCHASE . . . . .	170	5	M SERIES
OPERATOR'S GUIDE DESCRIBED. . . . .	183	4	M SERIES
SERIAL. RATING, ETC. . . . .	176	1	M 5 M15A. M16
TRUNK (SEE LUGGAGE COMPARTMENT). . . . .			
TULIP CREAM FORMULA. . . . .	197	3	
TURNING RADIUS INTERFERENCE. . . . .	182	2	6G
TUSCIN TAN BAKING ENAMEL . . . . .	239	4	2R SERIES
TWO-POST LIFTS . . . . .	189	3	ALL
TWO-SPEED AXLE. CONTROL CABLE. PROTECTOR CONDUIT . . . . .	239	4	2R16A. 2R17A
CONTROL CABLE. PROTECTOR CONDUIT. . . . .	239	4	2R16A. 2R17A
CONTROL VALVE (MIDLAND) . . . . .	236	6	2R SERIES
LUBRICANT LEAK. . . . .	222	5	2R
SELECTOR VALVE. . . . .	204	5	M SERIES
REMOVAL TOOL. . . . .	226	2	R SERIES
<b>U</b>			
-BOLT NUTS. REAR SPRINGS. . . . .	203	6	M 5
UNDERCOATING EQUIPMENT . . . . .	206	7	
KNOCKS-SOUND. . . . .	206	6	
UNDERSEAL (3 M) PROTECTIVE CAR COATING . . . . .	188	1	ALL
UNITOGSERVICE UNIFORMS. . . . .	240	5	
UNIVERSAL COVERED SPRING LUBRICATOR. . . . .	204	7	
UNIVERSAL JOINT USE ONLY PRESSURE ONLY IN LUBRICATING . . . . .	197	5	A L L
UPHOLSTERY. FRONT SEAT TEARING AT BOTTOM OF PANEL. . . . .	189	2	6G 14A
USE LOW PRESSURE ONLY IN LUBRIZATING UNIVERSAL JOINTS.. . . .	197	5	ALL
<b>V</b>			
V91 STARTER RING GEAR HEATER . . . . .	170	5	ALL
VACUUM BOOSTER, CHECK VALVE ASSEMBLY . . . . .	179	4	M SERIES
	193	3	6G. 14A: M5. M16
	195	2	6 G 14A
EQUIPMENT . . . . .	206	5	6G. 7G
INSTALLATION ON CERTAIN M5 AND M15A TRUCKS. . . . .	200	2	H5. M15A
VACUUM CLEANER. DOYLE VACUUM . . . . .	224	6	
VACUUM FUEL PUMP . . . . .	227	6	9G. 17A
INSTALLATION. . . . .	208	6	7G
REPAIR KITS . . . . .	206	5	
TOOLS. . . . .	203	8	15A
VACUUM POWER BRAKE AND CLUTCH CONTROLS, SERVICE ADJUSTMENTS (AMPUTEE EQUIPMENT) . . . . .	190	1-7	3G * 6G
VACUUM SHIFT REAR AXLE. HYPOID TYPE, TWO-SPEED . . . . .	189	2	M16
REMOVAL TOOL. . . . .	226	2	
VAL-LITE SIGNS (KENT-MOORE). . . . .	213	2	
VALVE DIAGNOSIS . . . . .	224	3	2R
LIFTERS AND ADJUSTING SCREWS. . . . .	188	2	6 G M5. M15A
NON-CORRODING EXHAUST . . . . .	235	2	9G. 17A: 2R
STEM GUIDE REMOVER AND REPLACER J2034 . . . . .	175	2	6 G 14A. M SERIES

REFERENCE	BUL N O.	PAGE NO.	MODEL
<b>V-Con T d .</b>			
VALVE . CONT'D.			
SPRING OIL BAFFLES (CHAMPION ENGINES) . . . . .	209	1	
TAPPET ADJUSTING GAGES . . . . .	203	7	ALL
VAN NORMAN BRAKE DRUM LATHE . . . . .	223	4	
VAPOR LOCK . . . . .	172	7	6 G
RETURN PARTS FOR CLAIMS CREDIT . . . . .	176	1	6G
VARSITY MAROON METALLIC BAKING ENAMEL . . . . .	203	2	7 G, 15A
VELVET BLACK PAINT FORMULA . . . . .	197	3	
VENTILATORS AND DOOR WINDOWS . WATER LEAKS IN . . . . .	204	4	14AY, 15AY
VIBROMATIC CLEANER . . . . .	225	2	
TY RECOMMENDATIONS. ENGINE OIL . . . . .	215	1	6G-8G, 14A- 16A, M SERIES. 2R SERIES
VOLTAGE AND CURRENT REGULATOR . . . . .	227	2	17A
<b>W</b>			
W969. TWO-SPEED REAR AXLE TAG . . . . .	183	2	M SERIES SO EQUIPPED
W1031. WARNING. WATER ONLY . . . . .	183	2	6 G, 14A, M SERIES
W1073. WARNING. ANTI FREEZE IN NEW CAR . . . . .	183	2	6G, 14A, M SERIES
W1189. DO NOT START ENGINE . . . . .	183	2	6G, 14A, M SERIES
WALKER ELECTRIC LIFT . . . . .	213	2	
WARRANTY, BATTERY, REGISTRATION CARD REQUIRED . . . . .	183	3	6G, 14A, M SERIES
CLOCK. BORG . . . . .	175	1	ALL
GENERAL . . . . .	198	1-7	6G,7G; 14A,15A
PHILCO REGISTRATION TAG REQUIRED FOR WARRANTY SERVICE . . . . .	183	3	6G, 14A, M SERIES
RADIO. FILL OUT TAG . . . . .	179	1	ALL
WASHER. FUTURFORM . . . . .	235	5	
WASHERS ELIMINATE TRUNK LID DIMPLES . . . . .	240	3	9G, 17A
WASHING CAR NO. 70) . . . . .	209	4	
WASHMOBILE CAR WASHER . . . . .	236	7	
WATER. DUST. AND AIR LEAKS . . . . .	198		6G, 14A
(CONVERTIBLES) . . . . .	201	3	6G, 14A
DOOR WINDOWS AND VENTILATORS . . . . .	204	4	14AY, 15AY
DRIVER'S COMPARTMENT . . . . .	206	2	6G,7G; 14A,15A
TOP AND BOTTOM OF DOORS . . . . .	198	2	6G
TOP. HEADER . . . . .	207	5	7 G, 14A
TRUNK . . . . .	198	7	6G
WATER PUMP GASKET LEAK . . . . .	230	1	6G,8G
GREASE CUPS. SAVE OLD . . . . .	191	1	ALL
INLET HOSE REINFORCING SPRING . . . . .	170	4	M16
WE-715S CARBURETOR . . . . .	222	4	8G
WEATHERSEALS, DOOR OPENING REAR (CONVERTIBLES) . . . . .	208	1	7G, 15A
WEATHERSTRIP, DOOR OPENING, LEAK AT . . . . .	206	2	6G,7G; 14A, 15A
DOOR OPENING CONVERTIBLES) . . . . .	207	6	7 G, 15A
WELDING, EUCTECTIC SUPPLIES . . . . .	216	6	
WET (OIL BATH) AIR CLEANER, SERVICE INSTRUCTIONS . . . . .	169	2	ALL
WHEEL ALIGNER, BEAN, S VIS UALNER . . . . .	206	8	
WHEEL ALIGNMENT . . . . .	191	9	ALL
WHEEL BALANCERS DESCRIBED . . . . .	197	8	
WHEEL BEARING. NUT WRENCH 2.3/8" HEX. J.2975 . . . . .	213	2	
WRENCH. REAR. ORDERING . . . . .	197	6	M15A, M16
WHEEL CASTER ADJUSTMENT NOT RECOMMENDED . . . . .	176	2	ALL
WHEEL DISCS. CLEANING, WHITEWALL PLASTIC . . . . .	172	2	5G, 6G, 14A
WHEELS, ELECTRONIC BALANCER CHANGEOVER KIT . . . . .	218	10	
WHEEL, REAR. GREASE SEAL . . . . .	215	4	2R10
WHEEL RUN-OUT . . . . .	172	5	ALL
WHEEL RUN-OUT SPECIFICATIONS . . . . .	197	4	6G,7G; 14A,15A
WHEEL SOCKET WRENCH . . . . .	180	1	6G, 14A
WHEEL, SPARE. BOLT TOO LONG . . . . .	224	2	8G, 16A
WHEEL, STEERING -- SEE STEERING WHEEL . . . . .			
WHEEL TURNING RADIUS INTERFERENCE STEERING TIE ROD ASSEMBLY . . . . .	182	2	6G
WHITE SIDEWALL TIRES, REMOVAL OF PROTECTIVE COATING ON . . . . .	191	1	
'WHITEWALL" PLASTIC WHEEL DISCS, CLEANING . . . . .	172	2	5G, 6G, 14A
WHY CLAIMS SETTLEMENTS BOG DOWN . . . . .		3	
WILCO SEALER GUN . . . . .	226	4	

REFERENCE	BUL.NO.	PAGE NO.	MODEL
<b>W-CONT'D</b>			
WILLARD BATTERY. GUARANTEE POLICY. . . . .	201	1	
REGISTRATION CARD DESCRIBED . . . . .	183	3	6G. 14A
WILSON. DON O.. "LET'S RESTORE SERVICE ROUTINES" . . .	189	1	
<b>WINDOW</b> , BIND IN DOOR (CONVERTIBLE) . . . . .	207	4	7G, 15A
BIND IN DOOR LOWER RUN. . . . .	206	5	6G, 7G; 4A, 15A
REGULATORS. . . . .	234	4	9G, 17A
<b>WINDSHIELD</b> LEAK AT RUBBER WEATHERSTRIP. . . . .	198	5	6G. 14A
ONE PIECE GLASS REPLACEMENT . . . . .	216	4	6G-8G; 4A- 16A
<b>WINDSHIELD WIPER</b> . ADJUSTMENTS. . . . .	224	4	2R
ARM TENSION . . . . .	221	2	
CABLE LINKAGES. . . . .	221	2	
DIAGNOSIS AND SERVICE . . . . .	221	1-	
MOTOR AND HOSE. . . . .	221	3	
OIL PUMP VACUUM BOOSTER . . . . .	179	4	M SERIES
OIL PUMP VACUUM BOOSTER . . . . .	195	2	6G. 14A
OIL PUMP VACUUM BOOSTER ASSEMBLY. . . . .	193	3	6G, 14A; M5, M16
VACUUM BOOSTER EQUIPMENT. . . . .	206	6	6G, 7G
SPEED OF BLADES . . . . .	221	2	
VACUUM SUPPLY . . . . .	221	3	
WIPER ■ SEE WINDSHIELD WIPER. . . . .			
WIRES CONTACTING GEARSHIFT MECHANISM . . . . .	173	2	6G
WIRING HARNESS DIRECTION SIGNAL AND FOG LAMP			
EQUIPMENT . . . . .	241	3	9G, 17A
WORK RACK, MOBILE (LUSTRE) . . . . .	233	3	
<b>ZENITH</b> , CARBURETOR . . . . .	203	5	M5. M15A
CENTRAL DISTRIBUTORS. . . . .	199	7	M SERIES